



MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

ROADMASTER, INC.

5602 N.E. SKYPORT WAY


PORTLAND, OR 97218

1-800-669-9690

FAX (503) 288-8900

PARTS LIST:

- 1- MAIN BRACE (A) - Passenger side
- 1- MAIN BRACE (B) - Driver's side
- 1- SIDE BRACE (C) - Passenger side
- 1- SIDE BRACE (D) - Driver's side
- 1- CENTER BRACE (E) - Passenger side
- 1- CENTER BRACE (F) - Driver's side

KIT NO. 205-1**051198**

IMPORTANT: All brackets **must** be assembled with all the bolts left loose for final adjustment & positioning (before tightening) unless otherwise instructed. All bolts **must** be torqued for proper strength. If more than one bolt is used per fastening point, the diagram may only show one.

- Use flat washers over all slotted holes
- Use lock washers on all fasteners

ROADMASTER Limited Warranty, including One-Year Conditional Warranty Text and Product Registration Card, in Carton.

WARNING

- Do not use this document for custom fabrication as it may not show all parts or structural components.
- ROADMASTER will not be responsible for any damage or injury resulting from any modification or alteration.
- The owner must inspect all mounts and brackets before each use for cracks or other signs of fatigue. Also, inspect the fasteners for proper torque, according to the torque chart.
- The owner must check the manufacturer's instructions for the proper procedure(s) to prepare the vehicle for towing. Some vehicles must be equipped with a transmission lube pump, an axle disconnect, driveline disconnect or free-wheeling hubs before they can be towed. Failure to properly equip the vehicle will cause severe damage to the transmission.
- The installer must read the instructions and use all bolts and parts supplied.
- If the towed vehicle has been in an accident, it must be properly repaired before attaching the brackets. Do not install the brackets if any structural frame damage is found. Failure to repair the damage may result in loss of your towed vehicle.
- Some motorhome chassis have such a tight turning radius that you can damage your motorhome, towed vehicle or tow bar while turning sharply. Before getting on the road, test your turning radius in an empty parking lot. Damage that results from turning too sharply is not covered by warranty.
- The driver must not back up the motorhome with the towed vehicle attached or non-warranty damage will occur to your towing system or towed vehicle.
- The safety cables must connect the towing vehicle to the towed vehicle frame to frame, with the cables crossed. Refer to the cable instructions for proper routing.
- Make sure there is enough slack in the safety cables at the motorhome to allow for sharp turns.
- Use caution when handling the tow bar — if your hands, fingers or any part of your body are caught between moving components, they can be pinched, cut or otherwise injured.
- This bracket is designed for use with ROADMASTER tow bars and ROADMASTER adaptors. Using this bracket with other brands, without an approved ROADMASTER adaptor, may result in non-warranty damage or injury.
- Important! This bracket is only warranted for the original installation. Installing a used bracket on another vehicle is not recommended and will void the warranty.
- Upon final installation, the installer must inspect the bracket to ensure adequate clearance, particularly around hoses, AC lines, radiators, etc., or non-warranty damage will result.

**WARNING**

Failure to follow these instructions can result in property damage, personal injury or even death.

MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

ROADMASTER, INC. 5602 N.E. SKYPORT WAY PORTLAND, OR 97218 1-800-669-9690 FAX (503) 288-

KIT NO. 205-1

1. This bracket kit uses the existing EA unit attachment points and the lower unibody box channel as mounting points. To start the installation, remove two retainer bolts in the front of each EA unit. Save the bolts. Slide the EA unit forward and insert the upper brace into place between the retainer and the cowling. Now, line up the holes and bolt them together with the bolts that were removed. Be sure the braces are properly aligned.
2. Using the upper braces as templates, drill one 1/2" hole per side through the front and back of the lower box channel. Bolt through the channel and brace using a 1/2" x 4" bolt, plate washer, lock washer and nut. Make sure the large plate washer is behind the box channel.
3. Attach the front braces to the upper braces through the upper mounting hole with 1/2" x 1 1/2" bolts, lock washers and nuts. Bolt the small lower braces to both the upper and front braces through the lower holes with 1/2" x 1 3/4" bolts, lock washers and nuts.
4. Now, use the lower braces as templates to drill two 1/2" holes through the box channel.
5. Bolt through the lower braces and the box channel with 1/2" x 4" bolts, plate washers, lock washers and nuts.
6. Install the tow bar according to the manufacturer's instructions then tighten all bolts to the torque specifications below.

HARDWARE LIST:

- 2-1/2" X 1 1/2" BOLTS
- 2-1/2" X 1 3/4" BOLTS
- 4-1/2" X 4" BOLTS
- 4-1/2" PLATE WASHERS
- 2-1/2" FLAT WASHERS
- 8-1/2" LOCK WASHERS
- 8-1/2" NUTS
- 1-1/4 x 1 1 2 x 4 1/2 PASSENGER SIDE CENTER BRACE
- 1-1/4 x 1 1 2 x 4 1/2 DRIVER SIDE CENTER BRACE

051198

CAUTION:

**Installer must read instructions
and use all bolts and parts sup-**

FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN DEATH, ~~PHYSICAL~~ INJURY OR PROPERTY DAMAGE

BOLT TORQUE REQUIREMENTS

Note: The torque values represented below are intended as general guidelines. Torque requirements for specific applications may vary. Roadmaster does not warrant this information to be accurate for all applications and disclaims all liability for any claims or damages which may result from its use.

STANDARD BOLTS			METRIC BOLTS			METRIC BOLTS		
Thread Size	Grade	Torque	Thread Size	Grade	Plated/Unplated	Thread Size	Grade	Plated/Unplated
5/16	5	13 ft./lb.	8mm-1.0	8.8	20 ft./lb. 18 ft./lb.	12mm-1.25	8.8	70 ft./lb. 65 ft./lb.
3/8	5	23 ft./lb.	8mm-1.25	8.8	19 ft./lb. 18 ft./lb.	12mm-1.5	8.8	66 ft./lb. 61 ft./lb.
7/16	5	37 ft./lb.	10mm-1.25	8.8	38 ft./lb. 36 ft./lb.	12mm-1.75	8.8	65 ft./lb. 60 ft./lb.
1/2	5	56 ft./lb.	10mm-1.5	8.8	37 ft./lb. 35 ft./lb.	14mm-2.0	8.8	104 ft./lb. 97 ft./lb.
5/8	5	150 ft./lb.						

All illustrations and specifications contained herein are based on the latest information available at the time of publication approval. ROADMASTER, INC. reserves the right to make changes at any time without notice in material, specification and models or to discontinue models.