



## Combined RSS Application Guide

Following are the applications for the Roadmaster Suspension Solutions family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

Roadmaster Inc. 6110 NE 127th Ave. Vancouver, WA 98682 1-800-669-9690 Fax: 503-288-8900  
www.roadmasterinc.com

Model	Sub-Assembly	Year	Item #	Comments	Category	Notes
<b>BEAVER</b>						
MISC		89-94	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
MISC		89-94	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

<b>CADILLAC</b>						
ESCALADE		00-18	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	Rear	48

<b>CHEVROLET</b>						
1500 VAN		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN		95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN		95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C		95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C		95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C		97-18	1109-148	Rear sway bar 1" diameter.	Rear	
2500 CLASS C	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C	Van & Cutaway	77-18	590150-00	Rear replacement end link kit only.	Subcomponents	
2500 CLASS C	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
2500 CLASS C	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
2500 CLASS C	Van & Cutaway	97-18	590150-00	Rear replacement end link kit only.	Subcomponents	
2500 CLASS C	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
2500 CLASS C	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	Cutaway	95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
2500 CUTAWAY	Cutaway	95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	Van & Cutaway	97-18	1109-148	Rear sway bar 1" diameter.	Rear	
2500 CUTAWAY	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
2500 CUTAWAY	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
2500 CUTAWAY	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
2500 CUTAWAY	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
2500 CUTAWAY	Van & Cutaway	77-18	590150-00	Rear replacement end link kit only.	Subcomponents	
2500 CUTAWAY	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
2500 CUTAWAY	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
2500 CUTAWAY	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN		95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN		95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN	2500 & 3500 Passenger Van	97-18	1109-148	Rear sway bar 1" diameter.	Rear	
2500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN	Van	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
2500 VAN	Van	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
2500 VAN	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
2500 VAN	Van & Cutaway	77-18	590150-00	Rear replacement end link kit only.	Subcomponents	
2500 VAN	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C		95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CLASS C		95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CLASS C		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C	2500 & 3500 Passenger Van	97-18	1109-148	Rear sway bar 1" diameter.	Rear	
3500 CLASS C	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CLASS C	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C	Van & Cutaway	97-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
3500 CLASS C	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
3500 CLASS C	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
3500 CLASS C	Van & Cutaway	04-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 CLASS C	Van & Cutaway	97-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 CLASS C	Van & Cutaway	77-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 CLASS C	Van & Cutaway	08-18	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	Rear	
3500 CLASS C	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
3500 CLASS C	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CLASS C	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CUTAWAY		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CUTAWAY		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
3500 CUTAWAY	Cutaway	08-18	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	Rear	
3500 CUTAWAY	Cutaway	95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CUTAWAY	Cutaway	95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CUTAWAY	Van & Cutaway	97-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
3500 CUTAWAY	Van & Cutaway	97-18	1109-148	Rear sway bar 1" diameter.	Rear	
3500 CUTAWAY	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
3500 CUTAWAY	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
3500 CUTAWAY	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
3500 CUTAWAY	Van & Cutaway	97-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 CUTAWAY	Van & Cutaway	77-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 CUTAWAY	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
3500 CUTAWAY	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CUTAWAY	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 VAN		95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN		95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 VAN		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 VAN	2500 & 3500 Passenger Van	97-18	1109-148	Rear sway bar 1" diameter.	Rear	
3500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 VAN	Van & Cutaway	97-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
3500 VAN	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
3500 VAN	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
3500 VAN	Van & Cutaway	77-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 VAN	Van & Cutaway	08-18	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	Rear	
3500 VAN	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
3500 VAN	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
4500 CLASS C		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
4500 CLASS C		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
4500 CLASS C	Van & Cutaway	08-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
4500 CLASS C	Van & Cutaway	08-18	590150-00	Rear replacement end link kit only.	Subcomponents	
4500 CLASS C	Van & Cutaway	08-18	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	Rear	
4500 CLASS C	Van & Cutaway	97-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
4500 CLASS C	Van & Cutaway	08-18	590150-00	Rear replacement end link kit only.	Subcomponents	
4500 CUTAWAY		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
4500 CUTAWAY		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
4500 CUTAWAY	Cutaway	08-18	590150-00	Rear replacement end link kit only.	Subcomponents	
4500 CUTAWAY	Cutaway	08-18	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	Rear	
4500 CUTAWAY	Van & Cutaway	08-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
4500 CUTAWAY	Van & Cutaway	08-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
4500 CUTAWAY	Van & Cutaway	08-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	65,68
4500 CUTAWAY	Van & Cutaway	97-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
AVALANCHE		00-13	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	Rear	48
G30	CLASS C CUTAWAY	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
G30	CLASS C CUTAWAY	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
G30	Cutaway	75-96	1109-131	Front sway bar 1 3/8 diameter.	Front	
G30	Cutaway	75-96	1109-121	Rear sway bar 1 1/4 diameter.	Rear	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
G30	Cutaway	75-96	1109-131	Front sway bar 1 3/8 diameter.	Front	
G30	Cutaway	75-96	1109-121	Rear sway bar 1 1/4 diameter.	Rear	
KODIAK C4500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.	Front	
KODIAK C4500	Cutaway	03-10	TRAC 45-55	Front Trac Rod for diesel engines	Trac	54
KODIAK C4500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	Rear	57,59,62
KODIAK C4500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	Rear	57,59,62
KODIAK C4500	Cutaway	03-10	RBK5	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
KODIAK C4500	Cutaway	03-10	1109-174	FOR USE WITH GRANNING AIR RIDE ONLY! 1 5/8 diameter rear facing rear auxiliary bar.	Rear	
KODIAK C4500	Cutaway	03-10	590066-00	Replacement front end link kit only.	Subcomponents	
KODIAK C4500	Cutaway	03-10	590066-00	Replacement front end link kit only.	Subcomponents	
KODIAK C4500	Cutaway	03-10	590065-00	Replacement rear end link kit only.	Subcomponents	
KODIAK C4500	Cutaway	03-10	590065-00	Replacement rear end link kit only.	Subcomponents	
KODIAK C4500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.	Front	
KODIAK C4500	Cutaway	03-10	TRAC C45	Front Trac Rod for gas engines	Trac	
KODIAK C4500	Cutaway	03-10	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
KODIAK C5500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.	Front	
KODIAK C5500	Cutaway	03-10	TRAC 45-55	Front Trac Rod for diesel engines	Trac	54
KODIAK C5500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	Rear	57,59,62
KODIAK C5500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	Rear	57,59,62
KODIAK C5500	Cutaway	03-10	RBK5	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
KODIAK C5500	Cutaway	03-10	1109-174	FOR USE WITH GRANNING AIR RIDE ONLY! 1 5/8 diameter rear facing rear auxiliary bar.	Rear	
KODIAK C5500	Cutaway	03-10	590066-00	Replacement front end link kit only.	Subcomponents	
KODIAK C5500	Cutaway	03-10	590066-00	Replacement front end link kit only.	Subcomponents	
KODIAK C5500	Cutaway	03-10	590065-00	Replacement rear end link kit only.	Subcomponents	
KODIAK C5500	Cutaway	03-10	590065-00	Replacement rear end link kit only.	Subcomponents	
KODIAK C5500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.	Front	
KODIAK C5500	Cutaway	03-10	TRAC C45	Front Trac Rod for gas engines	Trac	
KODIAK C5500	Cutaway	03-10	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
P SERIES	P30/P32/P3500	69-07	1109-116	Stage 1 susp. Kit. 1 5/8 diam. Front bar w/ poly bushing kit for 1 3/4 stock rear bar. Coil spring IFS (not for widebody).	Front	
P SERIES	P30/P32/P3500	68-99	4109-109	Poly bushing kit for front 1 1/4 stock bar.	Subcomponents	
P SERIES	P30/P32/P3500	68-99	4109-106	Poly bushing kit for rear 1 3/4 stock bar.	Subcomponents	
P SERIES	P30/P32/P3500	98-06	RSSCP30	Replaces OEM dampener.	Reflex	
P SERIES	P30/P32/P3500	98-06	RSDP30	Replaces OEM dampener. No return-to-center feature.	Reflex	
P SERIES	P30/P32/P3500	81-06	RBK3	Coil spring IFS (not for widebody). The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSP30.	Reflex	
P72-P92		96-97	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
P72-P92		96-97	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SILVERADO 1500 PICK-UP	2 WHEEL DRIVE	98-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
SILVERADO 1500 PICK-UP	2 WHEEL DRIVE	98-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SILVERADO 1500 PICK-UP	Standard & HD	00-09	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD)	Rear	13,74
SILVERADO 1500 PICK-UP	Standard & HD	00-09	1109-176	Rear sway bar 1" diameter (2WD & 4WD).	Rear	
SILVERADO 1500 PICK-UP	STANDARD & HD	10-18	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	Rear	8
SILVERADO 1500 PICK-UP	Standard & HD	00-08	590045-00	For rear extended endlinks for vehicles with 4-inch lift kit installed.	Subcomponents	
SILVERADO 2500 PICK-UP	Standard & HD	00-09	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD)	Rear	13,74
SILVERADO 2500 PICK-UP	Standard & HD	00-09	1109-166	Front Sway bar 1 1/2 diameter factory replacement (2WD & 4WD) Duallys, 2500 & 3500.	Front	
SILVERADO 2500 PICK-UP	STANDARD & HD	10-18	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	Rear	8
SILVERADO 2500 PICK-UP	Standard & HD	00-09	590045-00	For rear extended endlinks for vehicles with 4-inch lift kit installed.	Subcomponents	
SILVERADO 3500 PICK-UP	Pickup Cab (except HD)	86-98	1109-137	Front sway bar 1 3/8 diameter (2WD) only.	Front	

Model	Sub-Assembly	Year	Item #	Comments	Category	Notes
SILVERADO 3500 PICK-UP	Standard & HD	00-07	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD) and dually.	Rear	13,74
SILVERADO 3500 PICK-UP	Standard & HD	00-09	1109-166	Front Sway bar 1 1/2 diameter factory replacement (2WD & 4WD) Duallys, 2500 & 3500.	Front	
SILVERADO 3500 PICK-UP	Standard & HD	00-07	590045-00	For rear extended endlinks for vehicles with 4-inch lift kit installed.	Subcomponents	
SILVERADO 3500 PICK-UP	Standard & HD	08-09	1109-171	Rear sway bar 1 1/4 diameter SRW (4WD) and Dually.	Rear	8
SILVERADO 3500 PICK-UP	STANDARD & HD	10-18	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	Rear	8
SUBURBAN	1500	92-99	1109-144	Rear sway bar 1 1/8 diameter (w/o factory bar).	Rear	11
SUBURBAN	1500	92-99	1109-142	Rear sway bar 1 1/8 diameter (w/ factory bar).	Rear	10
SUBURBAN	1500	00-13	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	Rear	48
SUBURBAN	2500	00-08	1109-160	Rear sway bar 1 1/4 diameter (leaf spring suspension).	Rear	12
TAHOE	1500	95-99	1109-144	Rear sway bar 1 1/8 diameter (w/o factory bar).	Rear	11
TAHOE	1500	00-18	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	Rear	48
TAHOE	1500	95-99	1109-142	Rear sway bar 1 1/8 diameter (w/ factory bar).	Rear	10
TAHOE	2500 XL	00-08	1109-160	Rear sway bar 1 1/4 diameter (leaf spring suspension).	Rear	12
W4500	Cutaway	08-09	1109-172	Rear sway bar 1 1/2 diameter for Tilt Cab Chassis.	Rear	

### COUNTRY COACH

INTRIGUE		94-98	RBK10	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
INTRIGUE		94-98	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### DODGE

4500	Cutaway	08-17	1129-131	Rear sway bar 1 1/2 diameter factory replacement.	Rear	
4500	Cutaway	08-12	1129-134	Front sway bar 1 5/8 diameter factory replacement.	Front	
4500	Cutaway	13-17	1129-138	Front sway bar 1 5/8 diameter factory replacement. Fits 2wd and 4wd.	Front	
5500	Cutaway	08-17	1129-131	Rear sway bar 1 1/2 diameter factory replacement.	Rear	
5500	Cutaway	08-12	1129-134	Front sway bar 1 5/8 diameter factory replacement.	Front	
5500	Cutaway	13-17	1129-138	Front sway bar 1 5/8 diameter factory replacement. Fits 2wd and 4wd.	Front	
B200	Cutaway	75-03	1129-111	Rear sway bar 1 3/8 diameter for cut-aways.	Rear	15
B200	Passenger Van	75-03	1129-107	Rear sway bar 1" diameter.	Rear	14
B250	Cutaway	75-03	1129-111	Rear sway bar 1 3/8 diameter.	Rear	15
B300	(conversion van only) 1 ton	75-03	1129-111	Rear sway bar 1 3/8 diameter.	Rear	15
B300	Cutaway	75-03	1129-111	Rear sway bar 1 3/8 diameter for cut-aways.	Rear	15
B300	Passenger Van	75-03	1129-107	Rear sway bar 1" diameter.	Rear	14
B350	Cutaway	75-03	1129-111	Rear sway bar 1 3/8 diameter.	Rear	15
DURANGO		04-08	1129-126	Rear sway bar 1" diameter factory replacement.	Rear	
M-300/M-500		73-81	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
M-300/M-500		73-81	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
RAM 1500 PICK-UP	RAM 1500 PICK-UP	09-19	1129-135	Rear sway bar 1 1/8 diameter factory replacement (4WD).	Rear	
RAM 1500 PICK-UP	RAM 1500 PICK-UP	96-02	590053-00	Poly bushing kit for front factory bar.	Subcomponents	
RAM 1500 PICK-UP	RAM 1500 PICK-UP	03-08	1129-124	Rear sway bar 1 1/4 diameter (4WD) fits single only.	Rear	73
RAM 2500 PICK-UP		03-08	RBK20	Replaces OEM dampener. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSB.	Reflex	64
RAM 2500 PICK-UP		03-08	RSSB	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	64
RAM 2500 PICK-UP	RAM 2500 PICK-UP	96-02	1129-122	Rear sway bar 1 1/4 diameter (4WD).	Rear	17
RAM 2500 PICK-UP	RAM 2500 PICK-UP	03-13	1129-124	Rear sway bar 1 1/4 diameter (4WD) will fit single and dually.	Rear	16, 69, 73
RAM 2500 PICK-UP	RAM 2500 PICK-UP	96-02	590052-00	Poly bushing kit for front factory bar.	Subcomponents	
RAM 2500 PICK-UP	RAM 2500 PICK-UP	99-02	1129-136	Front sway bar 1 1/2 diameter factory replacement.	Front	
RAM 2500 PICK-UP	RAM 2500 PICK-UP	14-19	1129-135	Rear sway bar 1 1/8 diameter factory replacement (4WD).	Rear	
RAM 3500 PICK-UP	RAM 3500 PICK-UP	96-02	1129-122	Rear sway bar 1 1/4 diameter (4WD).	Rear	17
RAM 3500 PICK-UP	RAM 3500 PICK-UP	03-06	1129-124	Rear sway bar 1 1/4" diameter (4WD) will fit single and dually.	Rear	16,69, 73
RAM 3500 PICK-UP	RAM 3500 PICK-UP	10-17	1129-124	Rear sway bar 1 1/4 diameter (4WD) will fit single and dually.	Rear	69, 73
RAM 3500 PICK-UP	RAM 3500 PICK-UP	07-09	1129-130	Rear sway bar 1 3/8 diameter for dually and single rear wheel.	Rear	
RAM 3500 PICK-UP	RAM 3500 PICK-UP	07-08	1129-133	Rear sway bar 1 3/8 diameter for (2WD) Dually pickup only.	Rear	
RAM 3500 PICK-UP	RAM 3500 PICK-UP	03-06	1129-137	Rear sway bar 1 1/4 diameter (2WD) will fit single and dually.	Rear	

Model	Sub-Assembly	Year	Item #	Comments	Category	Notes
RAM 3500 PICK-UP	RAM 3500 PICK-UP	10-14	1129-130	Rear sway bar 1 3/8 diameter for Dually Pick-ups only.	Rear	
RAM 3500 PICK-UP	RAM 3500 PICK-UP	03-08	RBK20	Replaces OEM dampener. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSB.	Reflex	64
RAM 3500 PICK-UP	RAM 3500 PICK-UP	03-08	RSSB	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	64
RAM PROMASTER		14-17	1129-143	Rear swaybar 1-1/8	Rear	
RAM PROMASTER		14-17	1129-143	Rear swaybar 1-1/8	Rear	
SPRINTER 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	Rear	63
SPRINTER 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	Rear	63
SPRINTER 2500	2500	08-17	1209-128	Rear swaybar 1 1/8 diameter factory replacement. Includes 2wd and 4wd.	Rear	70
SPRINTER 2500	2500	08-17	1209-128	Rear swaybar 1 1/8 diameter factory replacement.	Rear	70
SPRINTER 2500	2500	08-17	590064-00	Vehicles without a factory swaybar will require this axle mount kit in order to install 1209-128.	Subcomponents	
SPRINTER 2500	2500	08-17	590064-00	Vehicles without a factory swaybar will require this axle mount kit in order to install 1209-128.	Subcomponents	
SPRINTER 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	Rear	63
SPRINTER 3500	3500	08-18	1209-120	Rear sway bar 1 3/8 diameter factory replacement.	Rear	63
SPRINTER 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	Rear	63
SPRINTER 3500	3500	08-18	1209-120	Rear sway bar 1 3/8 diameter factory replacement.	Rear	63
SPRINTER 3500	3500	07-18	1209-131	Rear Aux sway bar 1 1/2 diameter retains factory bar.	Rear	71
SPRINTER 3500	3500	04-06	1209-132	Rear Aux sway bar 1 1/2 diameter retains factory bar.	Rear	

<b>FORD</b>						
E250		09-17	1139-176	Front sway bar 1 3/8 diameter for RVs.	Front	
E250		87-17	RBK24	For V8 models with OEM steering dampener. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E250		09-17	1139-189	Front sway bar 1 3/8 diameter for Emergency Vehicle chassis.	Front	
E250		87-17	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E250	Class C	92-10	1139-115	Front sway bar 1 3/8 diameter.	Front	22
E250	Class C	92-10	590233-00	Front replacement end link kit only.	Subcomponents	
E250	Cutaway	92-10	1139-115	Front sway bar 1 3/8 diameter.	Front	22
E250	Cutaway	92-10	590233-00	Front replacement end link kit only.	Subcomponents	
E250	V8 WITHOUT OEM STEERING DAMPENER	87-16	RBK2	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E250	V8 WITHOUT OEM STEERING DAMPENER	87-16	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E250	VAN	92-10	1139-115	Front sway bar 1 3/8 diameter.	Front	22
E250	VAN	92-10	590233-00	Front replacement end link kit only.	Subcomponents	
E350		75-91	1139-100	Front sway bar 1 3/8 diameter.	Front	18
E350		09-18	1139-176	Front sway bar 1 3/8 diameter for RVs.	Front	
E350		87-18	RBK24	For V10 models. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E350		09-18	1139-189	Front sway bar 1 3/8 diameter for Emergency Vehicle chassis.	Front	
E350		87-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E350		87-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E350	Van	75-06	1139-134	Rear sway bar 1 1/8 diameter for auto chains.	Rear	24
E350	Van	75-06	1139-109	Rear sway bar 1 3/8 diameter.	Rear	21
E350	Class C	92-10	1139-115	Front sway bar 1 3/8 diameter.	Front	22
E350	Class C	75-18	1139-117	Rear sway bar 1 1/2 diameter. For models without auto chains.	Rear	
E350	Class C	92-10	590233-00	Front replacement end link kit only.	Subcomponents	
E350	Class C	75-17	1139-198	Rear sway bar 1 1/2 diameter. For models with auto chains.	Rear	
E350	Cutaway	75-91	1139-100	Front sway bar 1 3/8 diameter motorhomes cut-aways.	Front	18
E350	Cutaway	92-10	1139-115	Front sway bar 1 3/8 diameter.	Front	22
E350	Cutaway	75-18	1139-117	Rear sway bar 1 1/2 diameter motorhomes cut-aways. For models without auto chains.	Rear	
E350	Cutaway	75-09	1139-108	Rear sway bar 1 3/8 diameter (w/ automatic chains). Rear facing.	Rear	20
E350	Cutaway	75-09	590108-00	Rear replacement end link kit only.	Subcomponents	
E350	Cutaway	92-10	590233-00	Front replacement end link kit only.	Subcomponents	
E350	Cutaway	75-17	1139-198	Rear sway bar 1 1/2 diameter motorhomes cut-aways. For models with auto chains.	Rear	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
E350	V8 WITHOUT OEM STEERING DAMPENER	87-16	RBK2	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E350	V8 WITHOUT OEM STEERING DAMPENER	87-16	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E350	VAN	92-10	1139-115	Front sway bar 1 3/8 diameter.	Front	22
E350	VAN	00-18	1139-178	Rear sway bar 1 1/2 diameter (2WD) Class B Motorhome.	Rear	
E350	VAN	92-10	590233-00	Front replacement end link kit only.	Subcomponents	
E450		97-08	1139-115	Front sway bar 1 3/8 diameter.	Front	22
E450		97-18	1139-147	Rear sway bar: 1 1/2 diameter. For applications without auto chains.	Rear	27
E450		97-18	1139-147	Rear sway bar: 1 1/2 diameter. For applications without auto chains.	Rear	27
E450		87-18	RBK24	For V10 models. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E450		09-18	1139-176	Front sway bar 1 3/8 diameter for RVs.	Front	
E450		97-18	1139-163	Rear sway bar: 1 5/8 diameter. This bar is for use by emergency vehicles without auto chains only.	Rear	27
E450		97-17	590147-00	Rear replacement end link kit only.	Subcomponents	
E450		97-17	590147-00	Rear replacement end link kit only.	Subcomponents	
E450		97-08	590233-00	Front replacement end link kit only.	Subcomponents	
E450		97-18	1139-197	Rear sway bar: 1 1/2 diameter. For applications with auto chains.	Rear	27
E450		97-18	1139-197	Rear sway bar: 1 1/2 diameter. For applications with auto chains.	Rear	27
E450		97-18	1139-199	Rear sway bar: 1 5/8 diameter. This bar is for use by emergency vehicles with auto chains only.	Rear	27
E450		09-18	1139-189	Front sway bar 1 3/8 diameter for Emergency Vehicle chassis.	Front	
E450		87-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E450		87-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E450	V8 WITHOUT OEM STEERING DAMPENER	87-16	RBK2	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E450	V8 WITHOUT OEM STEERING DAMPENER	87-16	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E450 CLASS A		87-18	RBK24	For V10 models with OEM steering dampener and Thor Axis and Vegas models only. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E450 CLASS A		09-18	1139-176	Front sway bar 1 3/8 diameter for Thor Axis and Vegas models only.	Front	
E450 CLASS A		97-18	1139-163	Rear sway bar: 1 5/8 diameter. This bar is for use by emergency vehicles without auto chains and Thor Axis and Vegas models only.	Rear	27
EXCURSION		00-05	1139-155	Front sway bar 1 1/2 diameter.	Front	29
EXCURSION		00-05	1139-154	Rear sway bar 1 3/8 diameter.	Rear	
EXCURSION	4WD	00-05	RBK16	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSB.	Reflex	
EXCURSION	4WD	00-05	RSSB	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
EXPEDITION		97-03	1139-150	Rear sway bar 1 1/8 diameter.	Rear	
F150 PICK-UP		04-06	1139-152	Rear sway bar 1 1/8 diameter (4WD).	Rear	
F150 PICK-UP		08-16	1139-177	Rear sway bar 1 1/8 diameter (2WD & 4WD).	Rear	
F250 PICK-UP		11-16	1139-180	Front sway bar 1 3/8 diameter factory replacement (4WD) pickup and cab chassis SRW and dually.	Front	
F250 PICK-UP		99-03	1139-155	Front sway bar 1 1/2 diameter (4WD).	Front	29
F250 PICK-UP		99-03	1139-153	Rear sway bar 1 3/8 diameter F250 & F350 factory replacement bar. No Dually. If no factory swaybar present, see note 28.	Rear	28
F250 PICK-UP		99-07	1139-165	Rear sway bar 1 1/2 diameter F250 & F350 (dually).	Rear	33
F250 PICK-UP		08-16	1139-173	Rear sway bar 1 3/8 diameter factory replacement (4WD & 2WD). No factory bar, please see note 66.	Rear	66
F250 PICK-UP		04-07	1139-170	Rear sway bar 1 3/8 diameter.	Rear	
F250 PICK-UP		04-07	1139-158	Front sway bar 1 3/8 diameter, (4WD) with coil spring only.	Front	
F250 PICK-UP		05-08	1139-156	Super Duty front sway bar 1 3/8 diameter sway bar (2WD) only. To replace factory bar.	Front	
F250 PICK-UP		08-10	1139-174	Super Duty front sway bar 1 3/8 diameter factory replacement (2WD & 4WD) pickup, cab chassis SRW and dually.	Front	
F250 PICK-UP	4WD	99-07	RBK16	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSB.	Reflex	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
F250 PICK-UP	4WD	99-07	RSSB	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F350		05-08	1139-156	Front sway bar 1 3/8 diameter, (2WD) only. To replace factory bar.	Front	
F350		08-10	1139-174	Front sway bar 1 3/8 diameter factory replacement (4WD) pickup, cab chassis SRW and dually.	Front	
F350	Cutaway	99-12	1139-160	Rear sway bar 1 1/2 diameter. Factory replacement. Round axle tubes. (2WD & 4WD).	Rear	31
F350	Cutaway	04-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	Front	30
F350 PICK-UP		12-13	1139-168	Front sway bar 1 3/8 diameter factory replacement (2WD) cab chassis.	Front	
F350 PICK-UP		04-07	1139-158	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	Front	
F350 PICK-UP		04-07	1139-170	Rear sway bar 1 3/8 diameter.	Rear	
F350 PICK-UP		11-16	1139-180	Front sway bar 1 3/8 diameter factory replacement (4WD) pickup, cab chassis, SRW and dually.	Front	
F350 PICK-UP		99-07	1139-165	Rear sway bar 1 1/2 diameter F250 & F350 (dually).	Rear	33
F350 PICK-UP		99-03	1139-153	Rear sway bar 1 3/8 diameter F250 & F350 factory replacement bar. No Dually. If no factory swaybar present, see note 28.	Rear	28
F350 PICK-UP		99-03	1139-155	Front sway bar 1 1/2 diameter (4WD).	Front	29
F350 PICK-UP		05-08	1139-156	Front sway bar 1 3/8 diameter, (2WD) only. To replace factory bar.	Front	
F350 PICK-UP		08-16	1139-173	Rear sway bar 1 3/8 diameter factory replacement (4WD & 2WD). No factory bar, please see note 66.	Rear	66
F350 PICK-UP		08-10	1139-174	Front sway bar 1 3/8 diameter factory replacement (4WD) pickup, cab chassis SRW and dually.	Front	
F350 PICK-UP	4WD	99-07	RBK16	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSB.	Reflex	
F350 PICK-UP	4WD	99-07	RSSB	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F350 PICK-UP	Dually	17-18	1139-193	Rear anti-sway bar for dually models only.	Rear	
F450		08-10	1139-171	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.	Front	
F450		08-10	590055-00	Front and rear polyurethane bushings to replace factory rubber bushings.	Subcomponents	
F450		08-10	1139-171	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.	Front	
F450		08-11	1139-175	Rear sway bar 1 1/2 diameter. Fits (4WD) SRW & Dually Pickups.	Rear	
F450		08-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	Rear	32
F450	Cutaway	86-98	1139-123	Rear sway bar 1 1/2 diameter w/ factory sway bar.	Rear	23
F450	Cutaway	04-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	Front	30
F450	Cutaway	99-06	1139-160	Rear sway bar 1 1/2 diameter. Cab chassis. Factory replacement. Round axle tube.	Rear	31
F450 PICK-UP		11-19	1139-179	Front sway bar 1 1/2 inch diameter bar.	Front	
F450 PICK-UP		08-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	Rear	32
F450 PICK-UP		08-11	1139-175	Rear sway bar 1 1/2 diameter. Fits (4WD) SRW & Dually Pickups.	Rear	
F450 PICK-UP		17-19	1139-190	Rear factory replacement swaybar 1-1/2" diameter bar.	Rear	
F53 CLASS A		00-18	4139-300	Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 3/8 OEM bar.	Subcomponents	
F53 CLASS A		17-18	RBK25	24,000lb GVW and heavier ONLY. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
F53 CLASS A		17-18	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F53 CLASS A	V10	06-18	1139-145	Rear sway bar AUX 1 1/2 inch for coaches between 18,001-21,999 lbs. GVWR with <a href="http://roadmasterinc.com/img/1139-145_sm.jpg" target="_blank">shock mounts with two holes and parallel to the ground</a>. No Thor Outlaw.	Rear	
F53 CLASS A	V10	17-18	RBK22	For coaches with V10 engines. Will not work with 24,000 and/or 26,000 lb GVW coaches. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	1
F53 CLASS A	V10	99-05	TRAC V-10B	For coaches with V10 engines.	Trac	
F53 CLASS A	V10	99-16	RBK9	For coaches with V10 engines. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
F53 CLASS A	V10	88-05	1139-144	Rear 1 3/4" Heavy Duty Aux for motorhomes 34 feet and over. No Thor Outlaw.	Rear	52
F53 CLASS A	V10	99-16	RBK22	For coaches with V10 engines. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	1
F53 CLASS A	V10	05-18	1139-146	Rear sway bar aux 1 1/2". For motorhomes under 33 feet and 18,000 lbs GVWR. No Thor Outlaw.	Rear	



<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
F53 CLASS A	V10	06-18	TRAC F550	For 16,000-18,000 GVW coaches WITHOUT a front OEM track bar.	Trac	
F53 CLASS A	V10	17-18	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	1
F53 CLASS A	V10	99-16	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	1
F53 CLASS A	V10	99-16	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F53 CLASS A	V8	88-98	TRAC F53	For coaches with V8 engines.	Trac	
F53 CLASS A	V8	89-99	RBK4	For coaches with V8 engines. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
F53 CLASS A	V8	89-99	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F53 CLASS A	V8 and V10	88-18	4139-127	Front poly bushing kit for OEM bar. 1 5/8 OEM bar.	Subcomponents	3
F53 CLASS A	V8 and V10	92-18	4139-125	Rear poly bushing kit for OEM bar, some endlink parts may not be used. 1 1/2 OEM bar.	Subcomponents	3
F53 CLASS A	V8 and V10	88-05	1139-143	Rear sway bar aux 1 1/2". For motorhomes 33 feet and under. No Thor Outlaw.	Rear	52
F53 CLASS A	V8 and V-10	98-11	1139-140	Front sway bar 1 3/4 diameter. Front factory replacement.	Front	
F53 CLASS A	V8 AND V-10	12-18	1139-148	Front sway bar 1 3/4 diameter. Front factory replacement. For coaches 24,000 lbs GVWR and over.	Front	
F53 CLASS A	V8 AND V-10	06-18	1139-149	Rear sway bar AUX 1 5/8 for coaches over 22,000 lbs GVWR. No Thor Outlaw.	Rear	52
F53 CLASS A	V8 and V-10	12-18	1139-140	Front sway bar 1 3/4 diameter. Front factory replacement for coaches up to 23,999 lbs GVWR.	Front	
F550 CLASS A		00-18	4139-300	Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 3/8 OEM bar.	Subcomponents	
F550 CLASS A		17-18	RBK25	24,000lb GVW and heavier ONLY. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
F550 CLASS A		17-18	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F550 CLASS A	V10	99-05	TRAC V-10B	For coaches with V10 engines.	Trac	
F550 CLASS A	V10	06-18	1139-145	Rear sway bar AUX 1 1/2 inch for coaches between 18,001-21,999 lbs. GVWR with <a href="http://roadmasterinc.com/img/1139-145_sm.jpg" target="_blank">shock mounts with two holes and parallel to the ground</a>. No Thor Outlaw.	Rear	
F550 CLASS A	V10	99-16	RBK9	For coaches with V10 engines. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
F550 CLASS A	V10	88-05	1139-144	Rear 1 3/4" Heavy Duty Aux for motorhomes 34 feet and over. No Thor Outlaw.	Rear	52
F550 CLASS A	V10	99-16	RBK22	For coaches with V10 engines. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	1
F550 CLASS A	V10	05-18	1139-146	Rear sway bar aux 1 1/2". For motorhomes under 33 feet and 18,000 lbs GVWR. No Thor Outlaw.	Rear	
F550 CLASS A	V10	17-18	RBK22	For coaches with V10 engines. Will not work with 24,000 and/or 26,000 lb GVW coaches. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	1
F550 CLASS A	V10	06-18	TRAC F550	For 16,000-18,000 GVW coaches WITHOUT a front OEM track bar.	Trac	
F550 CLASS A	V10	99-16	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	1
F550 CLASS A	V10	17-18	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	1
F550 CLASS A	V10	99-16	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F550 CLASS A	V8	88-98	TRAC F53	For coaches with V8 engines.	Trac	
F550 CLASS A	V8	89-99	RBK4	For coaches with V8 engines. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
F550 CLASS A	V8	89-99	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F550 CLASS A	V8 and V10	88-18	4139-127	Front poly bushing kit for OEM bar. 1 5/8 OEM bar.	Subcomponents	3
F550 CLASS A	V8 and V10	92-18	4139-125	Rear poly bushing kit for OEM bar, some endlink parts may not be used. 1 1/2 OEM bar.	Subcomponents	3
F550 CLASS A	V8 and V10	88-05	1139-143	Rear sway bar aux 1 1/2". For motorhomes 33 feet and under. No Thor Outlaw.	Rear	52
F550 CLASS A	V8 and V-10	98-11	1139-140	Front sway bar 1 3/4 diameter. Front factory replacement.	Front	
F550 CLASS A	V8 AND V-10	12-18	1139-148	Front sway bar 1 3/4 diameter. Front factory replacement. For coaches 24,000 lbs GVWR and over.	Front	
F550 CLASS A	V8 AND V-10	06-18	1139-149	Rear sway bar AUX 1 5/8 for coaches over 22,000 lbs GVWR. No Thor Outlaw.	Rear	52

Model	Sub-Assembly	Year	Item #	Comments	Category	Notes
F550 CLASS A	V8 and V-10	12-18	1139-140	Front sway bar 1 3/4 diameter. Front factory replacement for coaches up to 23,999 lbs GVWR.	Front	
F550 CLASS C		00-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	Rear	32
F550 CLASS C		08-10	1139-171	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.	Front	
F550 CLASS C		11-18	1139-179	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.	Front	
F550 CLASS C		00-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	Rear	32
F550 CLASS C		17-18	1139-190	Rear factory replacement swaybar 1-1/2" diameter bar.	Rear	
F550 CLASS C	Cutaway	04-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	Front	30
F550 TRUCK		00-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	Rear	32
F550 TRUCK		11-19	1139-179	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.	Front	
F550 TRUCK		08-10	1139-171	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.	Front	
F550 TRUCK		00-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	Rear	32
F550 TRUCK		17-19	1139-190	Rear factory replacement swaybar 1-1/2" diameter bar.	Rear	
F550 TRUCK	Cutaway	04-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	Front	30
F650	Cutaway	09-12	1179-121	Front sway bar 1 1/2 diameter for Standard & LP Chassis 8,000lb & 10,000lb axle. Low Profile.	Front	
F650	Cutaway	09-12	1179-110	Rear sway bar 1 5/8 diameter with Onspot chains only, will work with air brakes. LIMITED GROUND CLEARANCE.	Rear	67

<b>FREIGHTLINER</b>						
AIR SUSPENSION	SOLID FRONT AXLE	95-05	RBK14	Does not fit models with 150 gallon fuel tank. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
AIR SUSPENSION	SOLID FRONT AXLE	95-05	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
FL SERIES	FL50, FL60	91-02	1209-100	Front sway bar 1 1/2 diameter. 8000 lbs. axle only.	Front	38
FL SERIES	FL50, FL60	91-02	1209-101	Rear sway bar 1 1/2 diameter - Hendrickson air suspension only.	Rear	39
FL SERIES	FL50, FL60	91-02	1209-104	Rear sway bar 1 1/2 diameter - Hendrickson air suspension w/ chains only.	Rear	40
FL SERIES	FL50, FL60	91-02	1209-106	Rear sway bar 1 1/2 diameter airline suspension with rear mounting chains. With 5x4 u-bolt pattern.	Rear	42
FL SERIES	FL50, FL60	91-02	1209-106SP	Rear sway bar 1 1/2 diameter airline suspension with rear mount Onspot chains already on. With 5x4 u-bolt pattern.	Rear	
FL SERIES	FL50, FL60	91-02	1209-107	Rear sway bar 1 1/2 diameter airline suspension without front mounting chains.	Rear	43
FL SERIES	FL50,FL60	91-02	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
FL SERIES	FL50,FL60	91-02	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
FL SERIES	FL70	91-02	1209-112	Rear sway bar 1 1/2 diameter - Hendrickson air only. With 6x4 u-bolt pattern.	Rear	
FL SERIES	FL70	91-02	1209-113	Rear sway bar 1 1/2 diameter airline suspension. With 6x4 u-bolt pattern. Will not fit models with optional center fuel tank.	Rear	44
FRED		07-08	1209-129	Front sway bar 1 3/4 diameter factory replacement.	Front	61
FRED		07-08	1209-130	Rear sway bar auxiliary 1 1/2 diameter.	Rear	61
FRED		07-08	TRAC FRED	Wayne asked to have this removed from the fit guide in 2010 for reasons that were not documented. It was obsoleted on 9/26/18 per David Robinson, due to low sales and zero stock. KS	Trac	
M2		03-17	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
M2		03-16	1209-106	Rear sway bar 1-1/2" diameter. For vehicles with Airliner suspension (combination air suspension/leaf springs) and 5" x 4" axle U-bolt pattern only. For use with automatic tire chains mounted behind rear axle.	Rear	42
M2		03-15	1209-106SP	Rear sway bar 1-1/2" diameter. For vehicles with Airliner suspension (combination air suspension/leaf springs) and 5" x 4" axle U-bolt pattern only. For use with previously-installed OnSpot automatic tire chains mounted behind rear axle.	Rear	44
M2		03-16	1209-107	Rear sway bar 1-1/2" diameter. For vehicles with Airliner suspension (combination air suspension/leaf springs) and 5" x 4" axle U-bolt pattern only. No automatic tire chains.	Rear	43
M2		03-16	1209-113	Rear sway bar 1-1/2" diameter. For vehicles with Airliner suspension (combination air suspension/leaf springs) and 6" x 4" axle U-bolt pattern only. Will not fit models with optional center fuel tank.	Rear	44
M2		03-16	1209-116	Front sway bar 1 1/2 diameter 8000lbs axle. Will not fit w/ Mercedes engine auxillary cooling package.	Front	46

Model	Sub-Assembly	Year	Item #	Comments	Category	Notes
M2		03-17	TRAC FM2	Front Trac bar	Trac	
M2		03-17	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SPRINTER 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	Rear	63
SPRINTER 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	Rear	63
SPRINTER 2500	2500	08-17	1209-128	Rear swaybar 1 1/8 diameter factory replacement. Includes 2wd and 4wd.	Rear	70
SPRINTER 2500	2500	08-17	590064-00	Vehicles without a factory swaybar will require this axle mount kit in order to install 1209-128.	Subcomponents	
SPRINTER 3500	3500	08-18	1209-120	Rear sway bar 1 3/8 diameter factory replacement.	Rear	63
SPRINTER 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	Rear	63
SPRINTER 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	Rear	63
SPRINTER 3500	3500	07-18	1209-131	Rear Aux sway bar 1 1/2 diameter retains factory bar.	Rear	71
STERLING		05-06	1209-119	Front sway bar 1 1/2 diameter.	Front	
XC CHASSIS	Air Suspension Only	95-98	1209-105	Rear sway bar 1 1/2 diameter (for chassis w/ long 3/4 diameter u-bolts).	Rear	5,41
XC CHASSIS	Air Suspension Only	99-03	1209-115	Rear sway bar 1 1/2 diameter (for chassis w/ short 7/8 diameter u-bolts).	Rear	5,45
XC CHASSIS	Air suspension only	04-14	1169-236	Rear sway bar 1-3/4. No V-Ride rear axle. Per Eric Jason, removed from fit guide on 3/26 due to proprietary design claim by Source Manufacturing. KS	Rear	
XC CHASSIS	Air suspension only	06-14	1209-136	Front sway bar 1-3/4	Front	
XC CHASSIS	SOLID FRONT AXLE	06-18	RBK18	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
XC CHASSIS	SOLID FRONT AXLE	06-18	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
XC CHASSIS V-RIDE		16-18	RBK18	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
XC CHASSIS V-RIDE		16-18	1209-140	Rear anti-sway bar 2-1/8-inch diameter bar.	Rear	
XC CHASSIS V-RIDE		16-18	1209-139	Front anti-sway bar 2-inch diameter bar.	Front	
XC CHASSIS V-RIDE		16-18	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### GILLIG

DIESEL MODELS		94-06	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
DIESEL MODELS		94-06	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
GAS MODELS		86-94	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
GAS MODELS		86-94	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### GMC

1500 VAN		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN		95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN		95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C		04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
2500 CLASS C	2500 & 3500 Passenger Van	97-18	1109-148	Rear sway bar 1" diameter.	Rear	
2500 CLASS C	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C	Van & Cutaway	77-18	590150-00	Rear replacement end link kit only.	Subcomponents	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
2500 CLASS C	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
2500 CLASS C	Van & Cutaway	97-17	590150-00	Rear replacement end link kit only.	Subcomponents	
2500 CLASS C	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
2500 CLASS C	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	2500 & 3500 Passenger Van	97-18	1109-148	Rear sway bar 1" diameter.	Rear	
2500 CUTAWAY	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	Van & Cutaway	97-18	590150-00	Rear replacement end link kit only.	Subcomponents	
2500 CUTAWAY	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
2500 CUTAWAY	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
2500 CUTAWAY	Van & Cutaway	04-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
2500 CUTAWAY	Van & Cutaway	04-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
2500 CUTAWAY	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
2500 CUTAWAY	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
2500 CUTAWAY	Van & Cutaway	77-17	590150-00	Rear replacement end link kit only.	Subcomponents	
2500 CUTAWAY	Van & Cutaway	04-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
2500 CUTAWAY	Van & Cutaway	04-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
2500 CUTAWAY	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
2500 CUTAWAY	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
2500 CUTAWAY	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN		95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN		95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN	2500 & 3500 Passenger Van	97-18	1109-148	Rear sway bar 1" diameter.	Rear	
2500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
2500 VAN	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
2500 VAN	Van & Cutaway	77-17	590150-00	Rear replacement end link kit only.	Subcomponents	
2500 VAN	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
2500 VAN	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C		95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CLASS C		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CLASS C		95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C	2500 & 3500 Passenger Van	97-18	1109-148	Rear sway bar 1" diameter.	Rear	
3500 CLASS C	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CLASS C	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
3500 CLASS C	Van & Cutaway	07-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
3500 CLASS C	Van & Cutaway	77-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 CLASS C	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
3500 CLASS C	Van & Cutaway	97-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
3500 CLASS C	Van & Cutaway	08-18	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	Rear	
3500 CLASS C	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
3500 CLASS C	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CLASS C	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CUTAWAY		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CUTAWAY		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CUTAWAY	Cutaway	95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CUTAWAY	Cutaway	77-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 CUTAWAY	Cutaway	97-18	1109-148	Rear sway bar 1" diameter.	Rear	
3500 CUTAWAY	Cutaway	95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CUTAWAY	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CUTAWAY	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CUTAWAY	Van & Cutaway	08-18	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	Rear	
3500 CUTAWAY	Van & Cutaway	04-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
3500 CUTAWAY	Van & Cutaway	97-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
3500 CUTAWAY	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
3500 CUTAWAY	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
3500 CUTAWAY	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
3500 CUTAWAY	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
3500 CUTAWAY	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
3500 CUTAWAY	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
3500 CUTAWAY	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
3500 CUTAWAY	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
3500 VAN		95-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN		95-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 VAN		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 VAN	2500 & 3500 Passenger Van	97-18	1109-148	Rear sway bar 1" diameter.	Rear	
3500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN	STEERING BOX OUTSIDE FRAME	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 VAN	Van & Cutaway	77-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 VAN	Van & Cutaway	97-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
3500 VAN	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
3500 VAN	Van & Cutaway	04-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
3500 VAN	Van & Cutaway	97-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
3500 VAN	Van & Cutaway	08-18	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	Rear	
3500 VAN	Van & Cutaway	97-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
3500 VAN	WITH DUAL CROSS MEMBERS	04-13	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN	WITH DUAL CROSS MEMBERS	04-13	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
4500 CLASS C		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
4500 CLASS C		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
4500 CLASS C	Van & Cutaway	08-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
4500 CLASS C	Van & Cutaway	08-18	590150-00	Rear replacement end link kit only.	Subcomponents	
4500 CLASS C	Van & Cutaway	97-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
4500 CLASS C	Van & Cutaway	08-18	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	Rear	
4500 CLASS C	Van & Cutaway	08-18	590150-00	Rear replacement end link kit only.	Subcomponents	
4500 CUTAWAY		13-18	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
4500 CUTAWAY		13-18	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
4500 CUTAWAY	Cutaway	04-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
4500 CUTAWAY	Van & Cutaway	04-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
4500 CUTAWAY	Van & Cutaway	97-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
4500 CUTAWAY	Van & Cutaway	04-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
4500 CUTAWAY	Van & Cutaway	08-18	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	Rear	
4500 CUTAWAY	Van & Cutaway	08-18	590150-00	Rear replacement end link kit only.	Subcomponents	
4500 CUTAWAY	Van & Cutaway	08-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
4500 CUTAWAY	Van & Cutaway	08-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
4500 CUTAWAY	Van & Cutaway	08-18	590150-00	Rear replacement end link kit only.	Subcomponents	
G30	CLASS C CUTAWAY	71-95	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
G30	CLASS C CUTAWAY	71-95	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
G30	Cutaway	75-96	1109-131	Front sway bar 1 3/8 diameter.	Front	
G30	Cutaway	75-96	1109-121	Rear sway bar 1 1/4 diameter.	Rear	
G30	Cutaway	75-96	1109-131	Front sway bar 1 3/8 diameter.	Front	
G30	Cutaway	75-96	1109-121	Rear sway bar 1 1/4 diameter.	Rear	
KODIAK C4500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.	Front	
KODIAK C4500	Cutaway	03-10	1109-158	Front sway bar 1 5/8" diameter.	Front	
KODIAK C4500	Cutaway	03-10	TRAC 45-55	Front Trac Rod for diesel engines	Trac	54
KODIAK C4500	Cutaway	03-10	RBK5	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
KODIAK C4500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	Rear	57,59,62
KODIAK C4500	Cutaway	03-10	1109-174	FOR USE WITH GRANNING AIR RIDE ONLY! 1 5/8 diameter rear facing rear auxiliary bar.	Rear	
KODIAK C4500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	Rear	57,59,62
KODIAK C4500	Cutaway	03-10	590065-00	Replacement rear end link kit only.	Subcomponents	
KODIAK C4500	Cutaway	03-10	590065-00	Replacement rear end link kit only.	Subcomponents	
KODIAK C4500	Cutaway	03-10	590066-00	Replacement front end link kit only.	Subcomponents	
KODIAK C4500	Cutaway	03-10	590066-00	Replacement front end link kit only.	Subcomponents	
KODIAK C4500	Cutaway	03-10	TRAC C45	Front Trac Rod for gas engines	Trac	
KODIAK C4500	Cutaway	03-10	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
KODIAK C5500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.	Front	
KODIAK C5500	Cutaway	03-10	1109-158	Front sway bar 1 5/8" diameter.	Front	
KODIAK C5500	Cutaway	03-10	TRAC 45-55	Front Trac Rod for diesel engines	Trac	54
KODIAK C5500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	Rear	57,59,62
KODIAK C5500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	Rear	57,59,62
KODIAK C5500	Cutaway	03-10	RBK5	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
KODIAK C5500	Cutaway	03-10	1109-174	FOR USE WITH GRANNING AIR RIDE ONLY! 1 5/8 diameter rear facing rear auxiliary bar.	Rear	
KODIAK C5500	Cutaway	03-10	590065-00	Replacement rear end link kit only.	Subcomponents	
KODIAK C5500	Cutaway	03-10	590065-00	Replacement rear end link kit only.	Subcomponents	
KODIAK C5500	Cutaway	03-10	590066-00	Replacement front end link kit only.	Subcomponents	
KODIAK C5500	Cutaway	03-10	590066-00	Replacement front end link kit only.	Subcomponents	
KODIAK C5500	Cutaway	03-10	TRAC C45	Front Trac Rod for gas engines	Trac	
KODIAK C5500	Cutaway	03-10	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
P SERIES	P30/P32/P3500	98-06	RSSCP30	Replaces OEM dampener.	Reflex	
P SERIES	P30/P32/P3500	69-07	1109-116	Stage 1 susp. Kit. 1 5/8 diam. Front bar w/ poly bushing kit for 1 3/4 stock rear bar. Coil spring IFS (not for widebody).	Front	
P SERIES	P30/P32/P3500	68-99	4109-109	Poly bushing kit for front 1 1/4 stock bar.	Subcomponents	
P SERIES	P30/P32/P3500	68-99	4109-106	Poly bushing kit for rear 1 3/4 stock bar.	Subcomponents	
P SERIES	P30/P32/P3500	98-06	RSDP30	Replaces OEM dampener. No return-to-center feature.	Reflex	
P SERIES	P30/P32/P3500	81-06	RBK3	Coil spring IFS (not for widebody). The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSP30.	Reflex	
P72-P92		96-97	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
P72-P92		96-97	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SIERRA 1500 PICK-UP	2 WHEEL DRIVE	98-04	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
SIERRA 1500 PICK-UP	2 WHEEL DRIVE	98-04	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SIERRA 1500 PICK-UP	Standard & HD	00-09	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD)	Rear	13,74
SIERRA 1500 PICK-UP	Standard & HD	00-09	1109-176	Rear sway bar 1" diameter (2WD & 4WD).	Rear	
SIERRA 1500 PICK-UP	Standard & HD	00-08	590045-00	For rear extended endlinks for vehicles with 4-inch lift kit installed.	Subcomponents	
SIERRA 1500 PICK-UP	STANDARD & HD	10-18	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	Rear	8
SIERRA 2500 PICK-UP	Standard & HD	00-09	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD)	Rear	13,74
SIERRA 2500 PICK-UP	Standard & HD	00-09	1109-166	Front Sway bar 1 1/2 diameter factory replacement (2WD & 4WD) Duallys, 2500 & 3500.	Front	
SIERRA 2500 PICK-UP	Standard & HD	00-09	590045-00	For rear extended endlinks for vehicles with 4-inch lift kit installed.	Subcomponents	
SIERRA 2500 PICK-UP	STANDARD & HD	10-18	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	Rear	8
SIERRA 3500 PICK-UP	Pickup Cab (except HD)	86-98	1109-137	Front sway bar 1 3/8 diameter (2WD) only.	Front	
SIERRA 3500 PICK-UP	Standard & HD	08-09	1109-171	Rear sway bar 1 1/4 diameter SRW (4WD) and Dually.	Rear	8
SIERRA 3500 PICK-UP	Standard & HD	00-09	1109-166	Front Sway bar 1 1/2 diameter factory replacement (2WD & 4WD) Duallys, 2500 & 3500.	Front	
SIERRA 3500 PICK-UP	Standard & HD	00-07	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD) and dually.	Rear	13,74
SIERRA 3500 PICK-UP	Standard & HD	00-07	590045-00	For rear extended endlinks for vehicles with 4-inch lift kit installed.	Subcomponents	
SIERRA 3500 PICK-UP	STANDARD & HD	10-18	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	Rear	8
SUBURBAN	1500	00-13	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	Rear	48
SUBURBAN	2500	00-08	1109-160	Rear sway bar 1 1/4 diameter (leaf spring suspension).	Rear	12
W4500	Cutaway	08-09	1109-172	Rear sway bar 1 1/2 diameter for Tilt Cab Chassis.	Rear	
YUKON	1500	00-18	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	Rear	48
YUKON	1500	95-99	1109-144	Rear sway bar 1 1/8 diameter (w/o factory bar).	Rear	11
YUKON	1500	95-99	1109-142	Rear sway bar 1 1/8 diameter (w/ factory bar).	Rear	10
YUKON	2500 XL	00-08	1109-160	Rear sway bar 1 1/4 diameter (leaf spring suspension).	Rear	12

### INTERNATIONAL

42/43/4400 SERIES		03-19	1179-110	Rear sway bar 1 5/8 diameter with Onspot chains only, will work with air brakes. LIMITED GROUND CLEARANCE.	Rear	67
42/43/4400 SERIES		03-19	590060-00	Rear axle plate kit for applications without Onspot chains.	Subcomponents	
42/43/4400 SERIES	Low Profile and Standard Chassis	03-19	1179-121	Front sway bar 1 1/2 diameter for Standard & LP Chassis 8,000lb & 10,000lb axle. Low Profile.	Front	
4700 LP SERIES		89-02	1179-100	Front sway bar 1 1/2 diameter.	Front	
4700 LP SERIES		89-02	1179-101	Rear sway bar 1 1/2 diameter with Navistar factory air ride only.	Rear	
DURASTAR		03-19	1179-110	Rear sway bar 1 5/8 diameter with Onspot chains only, will work with air brakes. LIMITED GROUND CLEARANCE.	Rear	67
DURASTAR	Low Profile and Standard Chassis	03-19	1179-121	Front sway bar 1 1/2 diameter for Standard & LP Chassis 8,000lb & 10,000lb axle. Low Profile.	Front	
TERRASTAR		12-15	1179-124	Front bar.	Front	
TERRASTAR		12-16	1179-112	Rear bar. Have to purchase 590060-00 if not using auto chains.	Rear	

### JEEP

RUBICON		04-08	1129-132	Rear sway bar 1 1/8 diameter factory replacment.	Rear	
---------	--	-------	----------	--	------	--

### JOHN DEERE

MOTORHOME CHASSIS		86-88	1169-144	Front sway bar 1 5/8 diameter.	Front	
MOTORHOME CHASSIS		86-94	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
MOTORHOME CHASSIS		86-94	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### MAGNUM

BEAVER COACHES		94-06	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
----------------	--	-------	------	--	--------	--

Model	Sub-Assembly	Year	Item #	Comments	Category	Notes
BEAVER COACHES		94-06	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SAFARI VELVET RIDE		98-07	RBK10	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
SAFARI VELVET RIDE		98-07	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SAFARI WITH LEAF SPRINGS		94-07	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
SAFARI WITH LEAF SPRINGS		94-07	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### MERCEDES-BENZ

M2		03-17	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
M2		03-17	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SPRINTER 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	Rear	63
SPRINTER 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	Rear	63
SPRINTER 2500	2500	08-17	1209-128	Rear sway bar 1 1/8 diameter factory replacement. Includes 2wd and 4wd.	Rear	70
SPRINTER 2500	2500	08-17	1209-128	Rear sway bar 1 1/8 diameter factory replacement. Includes 2wd and 4wd.	Rear	70
SPRINTER 2500	2500	08-17	590064-00	Vehicles without a factory swaybar will require this axle mount kit in order to install 1209-128.	Subcomponents	
SPRINTER 2500	2500	08-17	590064-00	Vehicles without a factory swaybar will require this axle mount kit in order to install 1209-128.	Subcomponents	
SPRINTER 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	Rear	63
SPRINTER 3500	3500	08-18	1209-120	Rear sway bar 1 3/8 diameter factory replacement.	Rear	63
SPRINTER 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	Rear	63
SPRINTER 3500	3500	08-18	1209-120	Rear sway bar 1 3/8 diameter factory replacement.	Rear	63
SPRINTER 3500	3500	07-18	1209-131	Rear Aux sway bar 1 1/2 diameter retains factory bar.	Rear	71
SPRINTER 3500	3500	04-06	1209-132	Rear Aux sway bar 1 1/2 diameter retains factory bar.	Rear	

### MONACO

LAPALMA	Diesel Engine Only	05-10	1259-108	Rear sway bar 1 1/2 diameter.	Rear	
LAPALMA	DIESEL ENGINE ONLY	05-10	1259-109	Rear sway bar 1 3/4 diameter. For 33 feet and longer.	Rear	

### NAVISTAR

42/43/4400 SERIES		03-19	1179-110	Rear sway bar 1 5/8 diameter with Onspot chains only, will work with air brakes. LIMITED GROUND CLEARANCE.	Rear	67
42/43/4400 SERIES		03-19	590060-00	Rear axle plate kit for applications without Onspot chains.	Subcomponents	
42/43/4400 SERIES	Low Profile and Standard Chassis	03-19	1179-121	Front sway bar 1 1/2 diameter for Standard & LP Chassis 8,000lb & 10,000lb axle. Low Profile.	Front	
4700 LP SERIES		89-02	1179-101	Rear sway bar 1 1/2 diameter with Navistar factory air ride only.	Rear	
4700 LP SERIES		89-02	1179-100	Front sway bar 1 1/2 diameter.	Front	
DURASTAR		03-19	1179-110	Rear sway bar 1 5/8 diameter with Onspot chains only, will work with air brakes. LIMITED GROUND CLEARANCE.	Rear	67
DURASTAR	Low Profile and Standard Chassis	03-19	1179-121	Front sway bar 1 1/2 diameter for Standard & LP Chassis 8,000lb & 10,000lb axle. Low Profile.	Front	
TERRASTAR		12-16	1179-124	Front bar.	Front	
TERRASTAR		12-16	1179-112	Rear bar. Have to purchase 590060-00 if not using auto chains.	Rear	

### NEWELL

NON-IFS		78-90	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
NON-IFS		78-90	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### NISSAN

TITAN PICK-UP		07-12	1189-101	Rear sway bar 1 1/8 diameter.	Rear	
---------------	--	-------	----------	-------------------------------	------	--

### OSHKOSH

K-LINE		80-95	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
K-LINE		80-95	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
M-LINE		80-95	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	



<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
M-LINE		80-95	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
TORSION SUSPENSION		94	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
TORSION SUSPENSION		94	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
Z-LINE		80-95	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
Z-LINE		80-95	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### ROADMASTER

AIR RIDE		00-17	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
AIR RIDE		00-17	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
MONACO	EXCEPT DANA SPICER FRONT AXLE	00-17	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
MONACO	EXCEPT DANA SPICER FRONT AXLE	00-17	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
STRAIGHT AXLE LEAF SPRING		00-09	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
STRAIGHT AXLE LEAF SPRING		00-09	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### SPARTAN

EC200	P-LINE	93-07	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
EC200	P-LINE	93-07	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
EXP CHASSIS		00-04	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
EXP CHASSIS		00-04	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
MC 2000	Air Suspension Only	96-06	1149-125	Front sway bar 1 5/8 diameter.	Front	37
MC 2000	Air Suspension Only	96-03	1149-1055	Front sway bar 1 5/8 diameter.	Front	
MC 2000	Air Suspension Only	95-03	1149-106	Rear sway bar 1 5/8 diameter.	Rear	2,58
MOUNTAIN MASTER	NON INDEPENDENT FRONT SUSPENSION	93-07	RBK7	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
MOUNTAIN MASTER	NON INDEPENDENT FRONT SUSPENSION	93-07	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
N-LINE		91-07	RBK7	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
N-LINE		91-07	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
VERST CHASSIS	Air Suspension Only	97-03	1149-118	Rear sway bar 1 1/2 diameter No bar connecting air bags.	Rear	39
VERST CHASSIS	Air Suspension Only	04-06	1149-119	Rear sway bar 1 1/2 diameter. No bar connecting air bags.	Rear	36
VERST CHASSIS	Air Suspension Only	95-03	1149-106	Rear sway bar 1 5/8 diameter. 4" square tube connecting air bags.	Rear	2,58
VERST CHASSIS	Air Suspension Only	97-03	1149-118	Rear sway bar 1 1/2 diameter No bar connecting air bags.	Rear	35
VERST CHASSIS	AIR SUSPENSION ONLY	07-08	1149-121	Rear sway bar 1 1/2 diameter. No bar connecting air bags. Jacks located to rear of cross member.	Rear	56
WC SERIES		99-06	RBK7	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
WC SERIES		99-06	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### STERLING

4500	Cutaway	08-12	1129-131	Rear sway bar 1 1/2 diameter factory replacement.	Rear	
4500	Cutaway	08-12	1129-134	Front sway bar 1 5/8 diameter factory replacement.	Front	
5500	Cutaway	08-12	1129-134	Front sway bar 1 5/8 diameter factory replacement.	Front	
5500	Cutaway	08-12	1129-131	Rear sway bar 1 1/2 diameter factory replacement.	Rear	

### TOYOTA

TUNDRA PICK-UP		07-12	1189-102	Rear sway bar 1.0 diameter.	Rear	
----------------	--	-------	----------	-----------------------------	------	--

### WORKHORSE

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
3500 CLASS C	Cutaway	07-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
3500 CLASS C	Cutaway	07-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 CUTAWAY	Cutaway	07-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 CUTAWAY	Van & Cutaway	07-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
3500 CUTAWAY	Van & Cutaway	07-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
3500 CUTAWAY	Van & Cutaway	07-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
3500 CUTAWAY	Van & Cutaway	07-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
3500 VAN	Cutaway	07-18	1109-150	Rear sway bar 1 3/8 diameter.	Rear	68
3500 VAN	Cutaway	07-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
3500 VAN	Cutaway	07-18	590150-00	Rear replacement end link kit only.	Subcomponents	
3500 VAN	Cutaway	07-08	590061-00	Chassis built before June of 2007 will require this axle mounting bracket kit when installing 1109-150.	Subcomponents	
3500 VAN	Van & Cutaway	07-18	1109-149	Front sway bar 1 1/2 factory replacement.	Front	
4500 CLASS C	Cutaway	07-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
4500 CUTAWAY	Van & Cutaway	07-18	1109-175	Rear sway bar 1 1/2 diameter.	Rear	68
P SERIES	P30/P32/P3500	00-05	RSSCP30	Replaces OEM dampener.	Reflex	
P SERIES	P30/P32/P3500	00-05	RSDP30	Replaces OEM dampener. No return-to-center feature.	Reflex	
P SERIES	Spreader bar	00-05	1109-200	Front sway bar stiffener; widetrack only.	Subcomponents	
P SERIES	WITHOUT OEM STEERING DAMPENER	00-05	RBK3	Coil spring IFS (not for widebody). The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSP30.	Reflex	
R SERIES	NON-INDEPENDENT FRONT SUSPENSION	03-07	RBK13	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
R SERIES	NON-INDEPENDENT FRONT SUSPENSION	03-07	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
W SERIES CHASSIS	W16, W18, W20, W22, W24	00-12	TRAC W-22	Front Trac Bar. Fits gas models only. Will not fit W20D models.	Trac	
W SERIES CHASSIS	W16,W18	06-12	RBK12	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
W SERIES CHASSIS	W16,W18	06-12	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
W SERIES CHASSIS	W16/W18	05-09	1259-115	Front sway bar 1 5/8 diameter.	Front	
W SERIES CHASSIS	W16/W18	05-09	1259-118	Rear sway bar 1 1/2 diameter.	Rear	51
W SERIES CHASSIS	W16/W18	05-09	1259-116	Combination front sway bar 1 5/8 diameter and front Trac Bar.	Trac	
W SERIES CHASSIS	W20, W22, W2	00-09	590063-00	Axle bracket kit for Vacationer and La Palma models only.	Subcomponents	
W SERIES CHASSIS	W20, W22, W24	00-09	1259-105	Front sway bar 1 5/8 diameter.	Front	72
W SERIES CHASSIS	W20, W22, W24	00-09	1259-108	Rear sway bar 1 1/2 diameter.	Rear	55
W SERIES CHASSIS	W20, W22, W24	00-09	590054-00	Supplemental brackets for use when Ride Rite air bags are present. Welded application.	Subcomponents	
W SERIES CHASSIS	W20, W22, W24 Chassis	00-09	1259-106	Front sway bar 1 5/8 diameter. Front trac bar combination.	Trac	
W SERIES CHASSIS	W20,W22,W24	00-12	RBK13	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
W SERIES CHASSIS	W20,W22,W24	00-12	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
W SERIES CHASSIS	W20D	09-10	1259-107	Front bar 1 5/8 diameter.	Front	
W SERIES CHASSIS	W22 & W24	00-09	1259-109	Rear sway bar 1 3/4 diameter. For 33 feet and longer.	Rear	55

## Application Guide Notes Key

- 1 · Modification may be required.
- 2 · Welding required.
- 3 · 1992 to mid-1995 have IPD-style bars with rubber bushings. Mid-1995 on have IPD-style bars with urethane bushings.
- 4 · 18,000 lbs. GVWR and under.
- 5 · Will not fit Newmar motorhomes.
- 6 · Not for Oshkosh X, V, M or T line chassis (check with manufacturer for your model using VIN#).
- 7 · 1991 and older require factory retro fit conversion kit.
- 8 · Will Work with air bags.
- 9 · With autochains and with and without air brake.
- 10 · Will fit 1992-99 models with 4WD. For vehicles with factory sway bar for Suburban and 4 door Tahoe/Yukon – not for 2 door models.
- 11 · Will fit 1999 models. For vehicles without factory bar. For Suburban and 4-door Tahoe/Yukon. Not for 2 door models.
- 12 · For 2000-on GMC Yukon XL and Chevy Suburban (leaf springs 2500/3500 series) not for regular Yukon or Tahoe (coil springs – 1500 series).
- 13 · For 2000-on Chevy/GMC 2500, 2500HD and 3500 (fits both single and dual rear wheels) pickups. Both gas and Duramax diesels. Will work with airbags.
- 14 · Fits 80-2003 3/4 ton and 1 ton vans.
- 15 · For 1975-03 Motor home chassis can be used on heavily loaded 1 ton vans.
- 16 · 2003-06 Dodge 4WD pickups 2500 and 3500 models, both single and dual rear wheels. For stock ride height vehicles. May not fit with 5th wheel hitch.
- 17 · 1996-02 4WD 2500 and 3500 pickups. Not designed for 2WD.
- 18 · For 1975-91 only. Not for E150.
- 19 · Fits 1975-2006 Motor homes and emergency vehicles. Will still work on 2005 gas E-series van cutaways.
- 20 · For E350 DRW (dual rear wheels/cutaway) chassis 1975-2003 with automatic chains. Nor for use on diesel or V-10 models.
- 21 · For 1975-2003 Ford E350 vans without chains. Type 2 Ambulance or Class B Motor home.
- 22 · 1992-2006 also fits E-Super Duty, sometimes called E450. This kit has offset endlinks for tie rod clearance. Does not fit E250 or E150.
- 23 · For 1988-91 F53 motor home chassis. Not for 1992 or newer motor homes. Also F450 pickup cab/chassis. 1986-97 to replace factory sway bar if not factory bar, additional parts will be needed (see Ford Dealer).
- 24 · For 1992 models and newer vans (Type 2 Ambulance/Class B Motor Homes) except Powerstroke diesels and V-10 models. The exhaust is in the way! Kit could be mounted if customer is willing to modify exhaust.
- 25 · For V-8 chassis and V-10 chassis with GVWR of 18,000lbs or less. The 4th digit of the VIN is L or M. GVWR is found on chassis data plate/sticker. These axle U-bolts are spaced 5-inch wide by 5.25-inch front to rear (Dana 80 axle). Will work with a tag axle if the drive axle has leaf springs.
- 26 · For 1998-on F53 with V-10 engine and GVWR greater than 18,000 lbs. The 4th digit of VIN is N. GVWR is found on chassis data plate/sticker. U-bolt spacing is 5-inch wide by 6.25-inch front to back (Dana S135 rear axle). Will work with a tag axle if the drive axle has leaf springs.
- 27 · Will work on the new 6 liter diesel engine for E450 chassis 1997-on. Mounts to axle same as factory bar.
- 28 · For 1999-2003 F250/350 pickup single rear wheels with factory sway bar (both 2WD and 4WD). <br> If the vehicle does not have a factory bar, you need endlink kit 590230-00.<br> If a 4" lift kit is installed, you will need endlink kit 590039-00. Will not fit 2004 or any dual rear wheels. Bar mounts under differential, not over differential like stock sway bar.
- 29 · Front sway bar kit for 2000-04 Ford F250-F350 trucks with straight axle (all 4WD models and F450 with front leaf springs, and F550 2WD models). Replaces factory sway bar. Must have factory sway bar. Will not fit 2005-on with coil spring front suspension. Updated to exclude 1999 models. Will fit 1999 model when factory bar is present (added 1/2-inch hardware for 99 model year)
- 30 · Front sway bar kit for 2005-on Ford F450-F550 4WD trucks with coil spring axle. Replaces factory sway bar. Must have factory sway bar. Will only fit cabin chassis, not for pickups.
- 31 · Rear sway bar kit replaces factory sway bar. For F350 commercial cab/chassis (only Dana 80 rear end with shock bracket welded to axle). Will not fit any pickup. On F450 confirm Dana 80 axle (round axle tubes). If axle tubes are square (Dana 120) use kit #1139-161.

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
32				Rear sway bar for 2000-08 F550 cab/chassis. Replaces factory bar. Also fits F450 with Dana 120 axle (square axle tubes).		
33				Rear sway bar for 1999-2007 F250 and F350 2WD and 4WD pickups with dual rear wheels and factory sway bar. Designed to replace factory sway bar. If a 4-inch lift kit is installed, you will need endlink kit 590038-00.		
34				For chassis with true air brakes with air canister on the axle. Some chassis have air assist brakes or air over hydraulic brakes, these are not true air brakes.		
35				Rear sway bar kit for Spartan Verst, air suspension. 1996-on 1.5-inch diameter. Will not fit Renegade made by Harney Coach. Leveling jacks are in the way.		
36				For Spartan Verst air suspension. 2004-on.		
37				Fits Mountain Master M11 Verst Chassis.		
38				For FL series chassis with 8,000lbs front axle and 19.5inch rims or 126" wheel height. Normally used on FL50 or FL60 series low profile trucks (most ambulance chassis). This will not work with the new Cat diesel engine introduced in 2000.		
39				For FL50 & FL60 ambulance chassis with Hendrickson air ride rear suspension. Will not work with chains (use 1209-104).		
40				For Freightliner FL50/FL60 chassis with automatic chains. Proven to fit with Onspot. Arms of bar face towards rear of truck for Hendrickson suspension only.		
41				For chassis up to 1998 and some 1999 and newer with long 3/4-inch diameter. U-bolts on rear axle. Have customer or shop measure u-bolt diameter. For chassis with short 7/8-inch diameter U-bolts (most of 1999-on) use kit 1209-115. If the rear suspension does not have U-bolts (late 2003 and up), use kit 1169-236.		
42				For 2000 and newer FL50/FL60/M2 vehicles with Airliner suspension. If vehicle has Hendrickson rear air suspension, use 1209-101 for vehicles without automatic tire chains, or 1209-104 for vehicles with automatic tire chains. Not for Class A motorhomes.		
43				Front-facing sway bar. Not for use with automatic tire chains. If vehicle is equipped with automatic tire chains, use 1209-106.		
44				Rear-facing sway bar.		
45				For most 1999-2003 Freightliner XC. This kit is for chassis with short 7/8-inch diameter bolts on rear axle. NOTE: sometime in 2003, Freightliner suspension changed to a style with No U- bolts. Have customer/shop measure U-bolt diameter. For chassis with 3/4-inch diameter U-bolts (mostly up to 1998) use kit 1209-105. If the rear suspension does not have U-bolts (late 2003 and up), use kit 1169-236.		
46				Will not work on chassis with Mercedes Benz engines that have auxiliary cooling package, if standard cooling, it is okay.		
47				Update of kit 1259-106 now fits all years for Rear W22 Workhorse chassis. Also fits W20 chassis.		
48				Fits GM 1/2 ton SUV chassis; coil springs only.		
49				Will not fit with auto chains		
50				Only fits vehicles with gas tanks that are rear of the axle.		
51				Currently does not work with Super Hitch		
52				This kit uses a flat plate that is held in place by the leaf spring U-bolts on the rear axle. Check to ensure there is enough exposed U-bolt below the nut to accommodate the factory nut and washer once our 1/2-inch thick plate is installed above them. If you do not have enough exposed U-bolt, order one of our U-bolt replacement kits.  For U-bolts with a square top, order kit 590050-00. For U-bolts with a round top, order kit 590050-10.		
53				If superhitch is installed, the 590051-00 bracket kit is needed		
54				For use with Duramax diesel only.		
55				When air bags have been added you will need the 590054-00 adapter kit which requires welding.		
56				For Spartan Mountain Master Verst air suspension chassis Tuthill 240AR with jacks located to the rear of the cross member.		
57				Will work with Kelderman air ride, Will work with Link Ultra ride.		
58				Chassis must have 3" square beam connecting the 2 airbags located underneath.		
59				Rear Leaf Spring hanger brackets may be bolted or riveted on. When riveted, install time will increase. Manufacture codes can be found under the driver side visor: EV8 = Rivets ; EV9 = Bolts.		
60				Will not work with air bags.		
61				Must have factory swaybars.		
62				When installing with Link UltraRide or Kelderman Air Ride kits, two B315 endlinks will be need to be ordered separately.		
63				2007 Model year vehicles manufactured in or after June may have 2008 Chassis. Please confirm before ordering.		
64				Will work with other model years that have the inverted Y front steering system with factory dampener.		
65				Will work with automatic tire chains.		

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
66				When no factory bar is present, customer will need to purchase kit 590170-00.		
67				For Applications Without onspot chains use 1179-110 and 590060-00.		
68				Chassis built before June of 2007 will require an additional axle mounting bracket kit part 590061-00.		
69				Will NOT fit with Goose Neck Hitch.		
70				If unit has no sway-bar from factory you will need mount kit 590064-00 (Factory mount kit).		
71				Some Airstream chassis have a propane tank inside the frame between the frame and drive line the 1209-131 will not fit with this model (please check before ordering).		
72				Vacationer and La Palma models will require axle bracket kit 590063-00.		
73				Note: this kit will not work on vehicles with factory-equipped air suspension systems.		
74				If a 4-inch lift kit is installed, you will need endlink kit 590045-00.		