



RoadMaster 2000-1 electric brake wiring schematic

Towing and Suspension Solutions

All specifications are subject to change without notice.

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 800-669-9690 Fax: 360-735-9300 www.roadmasterinc.com

Use the following wiring schematic when wiring your vehicle for towing the dolly.

