

Instructions

1. Locate the mounting post (Fig.1) that came with your BrakeMaster. If needed, order part number 450596. Now, secure the post to the center of the seat adapter using the included 3/8" x ³/₄" bolt and 3/8" lock washer. If the hole is countersunk, use the Allen head bolt and lock washer included with this kit.

2. Unscrew the two 18mm head front seat bolts. The mounting post on the seat adapter is slightly offset, to line up with the vehicle's brake pedal. Check the alignment of the mounting post to the brake pedal, then slide the seat adapter over the seat track, and over the front seat bolt holes. Bolt the seat adapter in place, using the factory bolts you removed earlier. Tighten the bolts.



Failure to follow these instructions can result in property damage, personal injury or even death.