1-800-669-9690 SEAT ADAPTER KIT #88338 INSTALLATION INSTRUCTIONS



5878-01

ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE





Instructions

1. Locate the mounting post (Fig.1) that came with your BrakeMaster. If needed, order part number 450596. Now, secure the post to the seat adapter using the included 3/8" x 34" bolt and 3/8" lock washer. If the hole is countersunk, use the Allen head bolt and lock washer included with this kit.

 $\mathbf{2.}$ Remove the all-weather liner, if the vehicle is so equipped (Fig.2). Then, push the driver's seat back as far as it will go.

3. Remove the two 14mm (head) seat track bolts (Fig.3). Then, place the two supplied 1" x .188 wall x 1" pipe spacers over the holes you just exposed. Place the seat adapter over the pipe spacers and bolt it into place on each side using the supplied 10mm x 1.25 x 70mm bolt, 10mm lock washer and 3/8" flat washer (Fig.4). Note: Ensure that the side of the seat adapter with the slotted hole is installed closest to the driver's side door.

4. Attach the BrakeMaster to the brake pedal and to the seat adapter. Adjust the length of the air cylinder assembly, per the BrakeMaster installation instructions, ensuring that the BrakeMaster is pulling back on the brake pedal so the pedal is only depressed when the brakes are engaged at the motorhome. Failure to adjust the assembled length of the BrakeMaster may result in severe brake system damage and/or complete failure of the brakes.

Parts List

- (1) 3/8" lock washer (1) 3/8" x 3/4" bolt
- (2) 1" x 1" pipe spacers

(2) 3/8" flat washers

- (2) 10mm x 1.25 x 70mm bolt
- (2) 10mm lock washers





