



Combined Application Guides

Reflex Steering Stabilizers, Davis TruTrac Bars, and Anti-Sway Bars

Reflex Steering Stabilizers Application Guide

Following are the applications for the Roadmaster Reflex Steering Stabilizers family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| Model | Sub-Assembly | Year | Comments | Item # | Notes | Drilling Time | Wt. |
|----------------------|----------------------------|-------|---|---------|------------------------------|---------------|-----|
| BEAVER | | | | | | | |
| MISC | | 89-94 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | 1 |
| CHEVROLET/GMC | | | | | | | |
| G30 | CLASS C CUTAWAY | 71-95 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK1 | No Bracket Only | | 1 |
| 1500/2500/3500 VANS | STEERING BOX OUTSIDE FRAME | 71-95 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK1 | No Bracket Only | | 1 |
| P SERIES | P30/P32/P3500 | 81-99 | REFLEX STEERING STABILIZER (RSDP30 UNIT NEEDED) | RBK3 | No Bracket Only | | 1 |
| P SERIES | P30/P32/P3500 | 81-99 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSP30) WITHOUT OEM DAMPER | RBK3 | No Bracket Only | | 1 |
| 3500 | CLASS C CUTAWAY | 95-04 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK15 | No Bracket Only | | 1 |
| 1500/2500/3500 VAN | | 95-04 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK15 | No Bracket Only | | 1 |
| 3500 CLASS C CUTAWAY | WITH DUAL CROSS MEMBERS | 04-08 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK17 | No Bracket Only | | 1 |
| 1500/2500/3500 VAN | WITH DUAL CROSS MEMBERS | 04-08 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK17 | No Bracket Only | | 1 |
| P72-P92 | | 96-97 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | 1 |
| CHEVROLET/GMC | | | | | | | |
| KODIAK | C4500/C5500 | 03-10 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK5 | No Bracket Only | | 1 |
| CHEVROLET/GMC | | | | | | | |
| 1/2 TON PICKUP | 2 WHEEL DRIVE | 98-04 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK15 | No Bracket Only | | 1 |
| P SERIES | P30/P32/P3500 | 98-06 | REFLEX STEERING STABILIZER RSDP30 (REPLACEMENT DAMPER ONLY) | RSDP30 | No Bracket Only | | 1 |
| P SERIES | P30/P32/P3500 | 98-06 | REFLEX STEERING STABILIZER RSSCP30 (REPLACEMENT FOR OEM DAMPER) WITH RETURN TO CENTER FEATURE | RSSCP30 | No Bracket Only | | 1 |
| COUNTRY COACH | | | | | | | |
| INTRIGUE | | 94-98 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK10 | No Bracket Only | | 1 |
| DODGE | | | | | | | |
| Pickup | 2500 - 3500 2WD & 4WD | 03-08 | Replaces Factory Dampener (UNIT NEEDED RSSB) | RBK20 | 64 No Bracket Only | | 1.5 |
| M-300/M-500 | | 73-81 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK8 | No Bracket Only | | 1 |
| FORD | | | | | | | |
| E350 | WITH OEM DAMPER V8 | 89-08 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK11 | No Bracket Only | | 1 |
| E250 | WITH OEM DAMPER V8 | 87-08 | REFLEX STEERING STABILIZER (UNIT NUMBER NEEDED RSSC) | RBK11 | No Bracket Only | | 1 |

Reflex Steering Stabilizers Application Guide

Following are the applications for the Roadmaster Reflex Steering Stabilizers family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| Model | Sub-Assembly | Year | Comments | Item # | Notes | Drilling | Time | Wt. |
|--------------------------|------------------------|-------|--|--------|---------------------------|----------|------|-----|
| E450 | WITHOUT OEM DAMPER V-8 | 87-09 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK2 | No Bracket Only | | 1 | |
| E350 | V-10 | 87-08 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK11 | No Bracket Only | | 1 | |
| E450 | WITH OEM DAMPER V8 | 87-08 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK11 | No Bracket Only | | 1 | |
| FORD | | | | | | | | |
| F53 | V10 | 00-11 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK9 | No Bracket Only | | 1 | |
| E450 | V-10 | 87-11 | REFLEX STEERING STABILIZER (UNIT NUMBER NEEDED RSSC) | RBK11 | No Bracket Only | | 1 | |
| FORD | | | | | | | | |
| F53 | V8 | 89-07 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK4 | No Bracket Only | | 1 | |
| F250 | 4WD | 99-03 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSB) | RBK16 | No Bracket Only | | 1 | |
| E350 | WITHOUT OEM DAMPER V-8 | 87-09 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK2 | No Bracket Only | | 1 | |
| E250 | WITHOUT OEM DAMPER V-8 | 87-09 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSC) | RBK2 | No Bracket Only | | 1 | |
| EXCURSION | 4WD | 00-05 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSB) | RBK16 | No Bracket Only | | 1 | |
| F350 | 4WD | 99-03 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSB) | RBK16 | No Bracket Only | | 1 | |
| FREIGHTLINER | | | | | | | | |
| FL SERIES | FL50,FL60 | 91-02 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK8 | No Bracket Only | | 1 | |
| AIR SUSPENSION | SOLID FRONT AXLE | 06-08 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK18 | No Bracket Only | | 1 | 10 |
| AIR SUSPENSION | SOLID FRONT AXLE | 95-05 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) Note: does not fit models with 150 gallon fuel tank. | RBK14 | No Bracket Only | | 1 | |
| GILLIG | | | | | | | | |
| GAS MODELS | | 86-94 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | 1 | |
| DIESEL MODELS | | 94-06 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | 1 | |
| JOHN DEERE | | | | | | | | |
| MOTORHOME CHASSIS | | 86-94 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK8 | No Bracket Only | | 1 | |
| MAGNUM | | | | | | | | |
| BEAVER COACHES | | 94-06 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | 1 | |
| SAFARI WITH LEAF SPRINGS | | 94-07 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | 1 | |
| SAFARI VELVET RIDE | | 98-07 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK10 | No Bracket Only | | 1 | |
| NEWELL | | | | | | | | |
| NON-IFS | | | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | 1 | |
| OSHKOSH | | | | | | | | |
| TORSION SUSPENSION | | | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | 1 | |
| K-LINE | | | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK8 | No Bracket Only | | 1 | |
| M-LINE | | | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK8 | No Bracket Only | | 1 | |
| Z-LINE | | | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK8 | No Bracket Only | | 1 | |
| ROADMASTER | | | | | | | | |

Reflex Steering Stabilizers Application Guide

Following are the applications for the Roadmaster Reflex Steering Stabilizers family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| Model | Sub-Assembly | Year | Comments | Item # | Notes | Drilling | Time | Wt. |
|---------------------------|-------------------------------|-------------|--|---------------|---------------------------|-----------------|-------------|------------|
| AIR RIDE | | 00-09 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | 1 | |
| STRAIGHT AXLE LEAF SPRING | | 00-09 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK8 | No Bracket Only | | 1 | |
| MONACO ALL | EXCEPT DANA SPICER FRONT AXLE | 00-09 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | 1 | |
| SPARTAN | | | | | | | | |
| EXP CHASSIS | | 00-04 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | 1 | |
| EC200 | P-LINE | 93-07 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK6 | No Bracket Only | | | |
| MOUNTAIN MASTER NON-IFS | | 93-07 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK7 | No Bracket Only | | 1 | |
| N-LINE | | 91-07 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK7 | No Bracket Only | | 1 | |
| WC SERIES | | 99-06 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK7 | No Bracket Only | | 1 | |
| WORKHORSE | | | | | | | | |
| R SERIES | NON-IFS | 03-07 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK13 | No Bracket Only | | 1 | |
| P SERIES | P30/P32/P3500 | 00-05 | REFLEX STEERING STABILIZER RSDP30 (REPLACEMENT DAMPER ONLY) | RSDP30 | No Bracket Only | | 1 | |
| P SERIES | P30/P32/P3500 | 00-05 | REFLEX STEERING STABILIZER RSSCP30 (REPLACEMENT FOR OEM DAMPER)WITH RETURN TO CENTER FEATURE | RSSCP30 | No Bracket Only | | 1 | |
| P SERIES | WITHOUT OEM DAMPER | 00-05 | REFLEX STEERING STABILIZER UNIT NEEDED (RSSP30) | RBK3 | No Bracket Only | | 1 | |
| W SERIES CHASSIS | W18,W16 | 06-09 | REFLEX STEERING STABILIZER (UNIT NUMBER NEEDED RSSA) | RBK12 | No Bracket Only | | 1 | |
| W SERIES CHASSIS | W20,W22,W24 | 00-09 | REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) | RBK13 | No Bracket Only | | 1 | |

Davis TruTrac Application Guide

Following are the applications for the Roadmaster Davis TruTrac family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| <u>Model</u> | <u>Sub-Assembly</u> | <u>Year</u> | <u>Comments</u> | <u>Item #</u> | <u>Notes</u> | <u>Drilling</u> | <u>Time</u> | <u>Wt.</u> |
|--------------|---------------------|-------------|-----------------|---------------|--------------|-----------------|-------------|------------|
|--------------|---------------------|-------------|-----------------|---------------|--------------|-----------------|-------------|------------|

Davis TruTrac Application Guide

Following are the applications for the Roadmaster Davis TruTrac family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| <u>Model</u> | <u>Sub-Assembly</u> | <u>Year</u> | <u>Comments</u> | <u>Item #</u> | <u>Notes</u> | <u>Drilling</u> | <u>Time</u> | <u>Wt.</u> |
|--------------|---------------------|-------------|-----------------|---------------|--------------|-----------------|-------------|------------|
|--------------|---------------------|-------------|-----------------|---------------|--------------|-----------------|-------------|------------|

CHEVROLET/GMC

| | | | | | | | | |
|--------|------|-------|----------------|--------------|----|----|-----|----|
| Kodiak | 5500 | 03-09 | Front Trac Rod | TRAC 45-5500 | 54 | No | 1.5 | 27 |
| Kodiak | 4500 | 03-09 | Front Trac Rod | TRAC 45-5500 | 54 | No | 1.5 | 27 |

FORD

| | | | | | | | | |
|-----|-----|-------|----------------|------------|--|----|---|----|
| F53 | V8 | 88-98 | Front Trac Bar | TRAC F53 | | No | 1 | 25 |
| F53 | V10 | 98-05 | Front Trac Bar | TRAC V-10B | | No | 1 | 31 |

WORKHORSE

| | | | | | | | | |
|------------------|----------------------------|-------|----------------|-----------|--|----|---|----|
| W Series Chassis | W16, W18, W20, W22, W24 | 00-09 | Front Trac Bar | TRAC W-22 | | No | 1 | 28 |
|------------------|----------------------------|-------|----------------|-----------|--|----|---|----|

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| <u>Model</u> | <u>Sub-Assembly</u> | <u>Year</u> | <u>Comments</u> | <u>Item #</u> | <u>Notes</u> | <u>Drilling Time</u> | <u>Wt.</u> |
|--------------|---------------------|-------------|-----------------|---------------|--------------|----------------------|------------|
|--------------|---------------------|-------------|-----------------|---------------|--------------|----------------------|------------|

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| <u>Model</u> | <u>Sub-Assembly</u> | <u>Year</u> | <u>Comments</u> | <u>Item #</u> | <u>Notes</u> | <u>Drilling Time</u> | <u>Wt.</u> |
|--------------|---------------------|-------------|-----------------|---------------|--------------|----------------------|------------|
|--------------|---------------------|-------------|-----------------|---------------|--------------|----------------------|------------|

CLASS A

CHEVROLET/GMC

| | | | | | | | |
|----------|---------------|-------|--|----------|----|-----|----|
| P Series | P30/P32/P3500 | 68-99 | Stage 1 susp. Kit. 1 5/8 diam. Front bar w/ poly bushing kit for 1 3/4 stock rear bar. Coil spring IFS (not for widebody). | 1109-116 | No | 1.5 | 51 |
| P Series | P30/P32/P3500 | 68-99 | Poly bushing kit for rear 1 3/4 stock bar. | 4109-106 | No | 0.5 | 5 |
| P Series | P30/P32/P3500 | 68-99 | Poly bushing kit for front 1 1/4 stock bar. | 4109-109 | No | 0.5 | |

FORD

| | | | | | | | | |
|-----|------------------------|-------|--|----------|---|----|-----|---|
| F53 | Super Duty, V8 Engine | 92-98 | Front poly bushing kit for OEM bar. 1 5/8 OEM bar. | 4139-127 | 3 | No | 0.5 | 3 |
| F53 | Super Duty, V10 Engine | 92-98 | Front poly bushing kit for OEM bar. 1 5/8 OEM bar. | 4139-127 | 3 | No | 0.5 | 3 |

Class A

FORD

| | | | | | | | |
|-----|--------------------|-------|--------------------------------------|----------|----|---|----|
| F53 | V8 and V-10 Engine | 99-11 | 1 3/4 Front factory replacement bar. | 1139-140 | No | 1 | 50 |
|-----|--------------------|-------|--------------------------------------|----------|----|---|----|

CLASS A

FORD

| | | | | | | | |
|-----|--------------------------------|-------|--|----------|----|---|---|
| F53 | Triton F53 Chassis, V10 Engine | 98-06 | Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 1/2 OEM bar. | 4139-125 | No | 1 | 3 |
|-----|--------------------------------|-------|--|----------|----|---|---|

Class A

FORD

| | | | | | | | | |
|-----|--------------------------------|-------|---|----------|----|-----|---|----|
| F53 | Triton F53 Chassis, V10 Engine | 00-10 | Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 3/8 OEM bar. | 4139-300 | No | 1 | 3 | |
| F53 | TRITON F53 CHASSIS, V10 E | 88-11 | 1 1/2 AUX RR 2006 and on fits both GVWR 18,000 lbs over and under retains factory swaybar | 1139-143 | 52 | Yes | 2 | 85 |

CLASS A

FORD

| | | | | | | | | |
|-----|-----------------------|-------|--|----------|---|----|---|---|
| F53 | Super Duty, V8 Engine | 92-98 | Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 1/2 OEM bar. | 4139-125 | 3 | No | 1 | 3 |
|-----|-----------------------|-------|--|----------|---|----|---|---|

Class A

FREIGHTLINER

| | | | | | | | | |
|------------|---------------------|-------|--|----------|------|-----|-----|----|
| XC Chassis | Air Suspension Only | 99-03 | Rear sway bar 1 1/2 diameter (for chassis w/ short 7/8 diameter u-bolts) most '99-'03. | 1209-115 | 5,45 | Yes | 3.0 | 89 |
|------------|---------------------|-------|--|----------|------|-----|-----|----|

CLASS A

FREIGHTLINER

| | | | | | | | | |
|------------|---------------------|-------|---|----------|------|-----|-----|----|
| XC Chassis | Air Suspension Only | 95-98 | Rear sway bar 1 1/2 diameter (for chassis w/ long 3/4 diameter u-bolts) most up to '98. | 1209-105 | 5,41 | Yes | 2.5 | 89 |
| FRED | | 07-08 | 1 3/4" diameter factory replacement front swaybar. | 1209-129 | 61 | No | 1.5 | 54 |
| FRED | | 07-08 | 1 1/2" diameter auxiliary rear swaybar. | 1209-130 | 61 | Yes | 2.5 | 89 |

JOHN DEERE

| | | | | | | | | |
|------------|--|-------|-------------------------------|----------|--|-----|-----|----|
| John Deere | | 86-88 | 1-5/8 diameter front sway bar | 1169-144 | | Yes | 2.5 | 87 |
|------------|--|-------|-------------------------------|----------|--|-----|-----|----|

MONACO

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| Model | Sub-Assembly | Year | Comments | Item # | Notes | Drilling | Time | Wt. |
|----------------|---------------------|-------|---|-----------|-------|----------|------|-----|
| LaPalma | Diesel Engine Only | 05-10 | Rear sway bar 1.5 diameter. | 1259-108 | | Yes | 3 | |
| SPARTAN | | | | | | | | |
| Verst Chassis | Air Suspension Only | 04-06 | Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags. | 1149-119 | 36 | Yes | 2 | |
| Verst Chassis | | 07-08 | Rear sway bar 1 1/2 diameter No bar connecting air bags. Jacks located to rear of cross member. | 1149-121 | 56 | No | 2 | |
| Verst Chassis | Air Suspension Only | 97-03 | Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags. | 1149-118 | 35 | No | 2 | |
| Verst Chassis | Air Suspension Only | 04-06 | Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags. | 1149-119 | 36 | Yes | 2 | |
| Verst Chassis | Air Suspension Only | 97-03 | Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags. | 1149-118 | 39 | No | 2 | |
| Verst Chassis | Air Suspension Only | 95-03 | Rear sway bar 1 5/8 diameter (early chassis) w/ solid bar connecting air bags. | 1149-106 | 2, 58 | No | 2 | 81 |
| MC 2000 | Air Suspension Only | 95-03 | Rear sway bar 1 5/8 diameter. | 1149-106 | 2, 58 | No | 2 | 81 |
| MC 2000 | Air Suspension Only | 96-03 | Front sway bar 1 5/8 diameter (Holiday Rambler). | 1149-1055 | | Yes | 2.5 | 63 |
| MC 2000 | Air Suspension Only | 96-06 | Front sway bar 1 5/8 diameter. | 1149-125 | 37 | Yes | 2 | 74 |

Class A

TOYOTA

| | | | | | | | | |
|--------|--|-------|-----------------------------------|----------|--|----|---|----|
| Tundra | | 07-12 | 5.7 liter V8 4x4. 1 rear sway bar | 1189-102 | | No | 1 | 40 |
|--------|--|-------|-----------------------------------|----------|--|----|---|----|

CLASS A

WORKHORSE

| | | | | | | | | |
|------------------|-----------------------|-------|---|-----------|----|-----|-----|----|
| W Series Chassis | W16/W18 | 05-10 | Rear sway bar 1 1/2 diameter. | 1259-118 | 51 | Yes | 3 | |
| W Series Chassis | W16/W18 | 05-10 | Front sway bar 1 5/8 diameter. | 1259-115 | | Yes | 2 | 87 |
| W Series Chassis | W16/W18 | 05-10 | Combination front sway bar 1 5/8 diameter and front Trac Bar. | 1259-116 | | Yes | 3.5 | |
| W Series Chassis | W20, W22, W24 Chassis | 00-10 | Front sway bar 1 5/8 diameter. Front trac bar combination. | 1259-106 | | Yes | 3.5 | |
| W Series Chassis | W20, W22, W24 | 00-10 | Supplemental brackets for use when Ride Rite air bags are present. Welded application | 590054-00 | | No | 2 | 10 |
| P Series | | 00-05 | Front sway bar stiffener; widetrack only. | 1109-200 | | No | 1 | 25 |
| W Series Chassis | W20, W22, W24 | 00-10 | Front sway bar 1 5/8 diameter. | 1259-105 | | Yes | 2 | 87 |

Class A

WORKHORSE

| | | | | | | | | |
|------------------|---------------|-------|-----------------------------|----------|----|-----|---|--|
| W Series Chassis | W20, W22, W24 | 00-10 | Rear sway bar 1.5 diameter. | 1259-108 | 55 | Yes | 3 | |
|------------------|---------------|-------|-----------------------------|----------|----|-----|---|--|

CLASS C

CHEVROLET/GMC

| | | | | | | | | |
|--------|------------|-------|---|----------|--|-----|-----|----|
| G30 | Cut-away | 75-96 | Rear sway bar 1 1/4 diameter. | 1109-121 | | Yes | 1.5 | 41 |
| C3500 | Pickup Cab | 88-98 | Front sway bar 1 3/8 diameter 2WD only. | 1109-137 | | No | 1 | 32 |
| G30 | Cut-away | 75-96 | Front sway bar 1 3/8 diameter. | 1109-131 | | No | 1 | 37 |
| Kodiak | 4500, 5500 | 03-10 | Front sway bar 1 5/8 diameter. | 1109-158 | | No | 2 | 52 |

Class C

CHEVROLET/GMC

| | | | | | | | | |
|-----------|----------------|-------|----------------------------------|----------|--|----|-----|----|
| G4500 | Van & Cut-away | 08-12 | 1 1/2 front factory replacement | 1109-149 | | No | 1.5 | 85 |
| 2500/3500 | Van & Cut-away | 04-12 | 1 1/2 front factory replacement. | 1109-149 | | No | 1.5 | 85 |

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| <u>Model</u> | <u>Sub-Assembly</u> | <u>Year</u> | <u>Comments</u> | <u>Item #</u> | <u>Notes</u> | <u>Drilling</u> | <u>Time</u> | <u>Wt.</u> |
|--------------|---------------------|-------------|--------------------------|---------------|--------------|-----------------|-------------|------------|
| 2500/3500 | Van & Cut-away | 77-12 | 1 3/8" diameter rear bar | 1109-150 | 68 | No | 1.5 | 43 |
| G4500 | Van & Cut-away | 08-12 | 1 3/8" diameter rear bar | 1109-150 | 68 | No | 1.5 | 43 |

CLASS C

CHEVROLET/GMC

| | | | | | | | | |
|--------|------------|-------|---|----------|--------|----|-----|----|
| Kodiak | 4500, 5500 | 03-10 | 1 5/8 diameter rear facing rear auxillary bar | 1109-157 | 57, 59 | No | 2.5 | 55 |
|--------|------------|-------|---|----------|--------|----|-----|----|

Class C

CHEVROLET/GMC

| | | | | | | | | |
|-----------|----------------|-------|--------------------------|----------|----|-----|-----|----|
| 2500/3500 | Van & Cut-away | 77-12 | 1 1/2" diameter rear bar | 1109-175 | 68 | Yes | 1.5 | 50 |
| G4500 | Van & Cut-away | 08-12 | 1 1/2" diameter rear bar | 1109-175 | 68 | Yes | 1.5 | 50 |

DODGE

| | | | | | | | | |
|----------|------|-------|--|----------|--|----|---|----|
| Sprinter | 2500 | 08-12 | Rear swaybar 1 1/8 diameter factory replacement. | 1209-128 | | No | 1 | 25 |
|----------|------|-------|--|----------|--|----|---|----|

CLASS C

DODGE

| | | | | | | | | |
|----------|------|-------|--|----------|----|-----|-----|----|
| Sprinter | 3500 | 04-06 | Aux Rear Swaybar 1.5" diameter retains factory bar | 1209-132 | | Yes | 2.5 | 60 |
| Sprinter | 3500 | 08-09 | 1 3/8 diameter factory replacement | 1209-120 | 63 | No | 1 | 40 |
| B350 | | 75-03 | Rear sway bar 1 3/8 diameter. | 1129-111 | 15 | Yes | 1.5 | 48 |
| B250 | | 75-03 | Rear sway bar 1 3/8 diameter. | 1129-111 | 15 | Yes | 1.5 | 48 |
| Sprinter | 2500 | 02-07 | Rear sway bar 1 1/8 diameter | 1209-117 | 63 | No | 1 | 25 |

Class C

DODGE

| | | | | | | | | |
|----------|------|-------|--|----------|--|-----|-----|----|
| Sprinter | 3500 | 07-10 | Aux Rear Swaybar 1.5" diameter retains factory bar | 1209-131 | | Yes | 2.5 | 60 |
|----------|------|-------|--|----------|--|-----|-----|----|

CLASS C

DODGE

| | | | | | | | | |
|----------|------|-------|------------------------------|----------|----|----|---|----|
| Sprinter | 3500 | 04-07 | Rear sway bar 1 3/8 diameter | 1209-118 | 63 | No | 1 | 27 |
|----------|------|-------|------------------------------|----------|----|----|---|----|

Class C

FORD

| | | | | | | | | |
|------|------------|-------|---|----------|----|-----|-----|----|
| E450 | Super Duty | 97-12 | Rear sway bar 1 1/2 diameter. | 1139-147 | 27 | Yes | 1 | 47 |
| F450 | | 08-10 | Front bar 1.5 diameter 2WD & 4WD cab chassis F450-550 | 1139-171 | | No | 1 | 55 |
| E450 | Super Duty | 97-08 | Front sway bar: 1 3/8 diameter. | 1139-115 | 22 | No | 1.5 | 42 |

CLASS C

FORD

| | | | | | | | | |
|------|---------|-------|--------------------------------|----------|----|-----|-----|----|
| E250 | Class C | 92-10 | Front sway bar 1 3/8 diameter. | 1139-115 | 22 | No | 2 | 42 |
| E350 | Class C | 75-10 | Rear sway bar 1 1/2 diameter. | 1139-117 | 19 | Yes | 1.5 | 53 |
| E350 | Class C | 92-10 | Front sway bar 1 3/8 diameter. | 1139-115 | 22 | No | 2 | 42 |

Class C

FORD

| | | | | | | | | |
|------|---------------|-------|---------------------------------|----------|----|----|-----|----|
| E250 | VAN & PICK-UP | 92-10 | Front sway bar: 1 3/8 diameter. | 1139-115 | 22 | No | 1.5 | 42 |
|------|---------------|-------|---------------------------------|----------|----|----|-----|----|

CLASS C

FORD

| | | | | | | | | |
|------|--|-------|--------------------------------|----------|----|----|-----|----|
| E350 | | 75-91 | Front sway bar 1 3/8 diameter. | 1139-100 | 18 | No | 1.5 | 37 |
|------|--|-------|--------------------------------|----------|----|----|-----|----|

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| <u>Model</u> | <u>Sub-Assembly</u> | <u>Year</u> | <u>Comments</u> | <u>Item #</u> | <u>Notes</u> | <u>Drilling</u> | <u>Time</u> | <u>Wt.</u> |
|--------------|---------------------|-------------|-----------------|---------------|--------------|-----------------|-------------|------------|
|--------------|---------------------|-------------|-----------------|---------------|--------------|-----------------|-------------|------------|

Class C

FORD

| | | | | | | | | |
|------|------------|-------|--------------------------------|----------|----|----|---|----|
| E450 | Super Duty | 97-08 | Front sway bar 1 3/8 diameter. | 1139-115 | 22 | No | 2 | 42 |
|------|------------|-------|--------------------------------|----------|----|----|---|----|

Ford

| | | | | | | | | |
|------|------------|-------|--------------------------------|----------|--|----|---|----|
| E450 | Super Duty | 09-12 | Front sway bar 1 3/8 diameter. | 1139-176 | | No | 1 | 36 |
|------|------------|-------|--------------------------------|----------|--|----|---|----|

CLASS C

FREIGHTLINER

| | | | | | | | | |
|----------|------|-------|------------------------------|----------|----|----|---|----|
| Sprinter | 3500 | 04-07 | Rear sway bar 1 3/8 diameter | 1209-118 | 63 | No | 1 | 27 |
|----------|------|-------|------------------------------|----------|----|----|---|----|

Class C

Freightliner

| | | | | | | | | |
|----------|------|-------|---|----------|--|-----|-----|----|
| Sprinter | 3500 | 07-10 | Aux Rear Swaybar 1.5" diameter retains factory bar. | 1209-131 | | Yes | 2.5 | 60 |
|----------|------|-------|---|----------|--|-----|-----|----|

CLASS C

FREIGHTLINER

| | | | | | | | | |
|----------|------|-------|------------------------------|----------|----|----|---|----|
| Sprinter | 2500 | 02-07 | Rear sway bar 1 1/8 diameter | 1209-117 | 63 | No | 1 | 25 |
|----------|------|-------|------------------------------|----------|----|----|---|----|

Class C

WORKHORSE

| | | | | | | | | |
|------|----------|-------|--------------------------|----------|----|----|-----|----|
| 3500 | Cut-away | 07-12 | 1 3/8" diameter rear bar | 1109-150 | 68 | No | 1.5 | 43 |
|------|----------|-------|--------------------------|----------|----|----|-----|----|

| | | | | | | | | |
|------|----------|-------|----------------------------------|----------|--|----|-----|----|
| 3500 | Cut-away | 07-12 | 1 1/2 front factory replacement. | 1109-149 | | No | 1.5 | 85 |
|------|----------|-------|----------------------------------|----------|--|----|-----|----|

| | | | | | | | | |
|------|----------|-------|--------------------------|----------|----|-----|-----|----|
| 3500 | Cut-away | 07-12 | 1 1/2" diameter rear bar | 1109-175 | 68 | Yes | 1.5 | 50 |
|------|----------|-------|--------------------------|----------|----|-----|-----|----|

EV Type 1

CHEVROLET/GMC

| | | | | | | | | |
|-----------|----------------|-------|--------------------------|----------|----|----|-----|----|
| 2500/3500 | Van & Cut-away | 04-12 | 1 3/8" diameter rear bar | 1109-150 | 68 | No | 1.5 | 43 |
|-----------|----------------|-------|--------------------------|----------|----|----|-----|----|

| | | | | | | | | |
|-------|----------------|-------|--------------------------|----------|--------|-----|-----|----|
| G4500 | Van & Cut-away | 08-12 | 1 1/2" diameter rear bar | 1109-175 | 65, 68 | Yes | 1.5 | 50 |
|-------|----------------|-------|--------------------------|----------|--------|-----|-----|----|

EV TYPE 1

CHEVROLET/GMC

| | | | | | | | | |
|--------|------------|-------|--------------------------------|----------|--|----|---|----|
| Kodiak | 4500, 5500 | 03-10 | Front sway bar 1 5/8 diameter. | 1109-158 | | No | 2 | 52 |
|--------|------------|-------|--------------------------------|----------|--|----|---|----|

| | | | | | | | | |
|-------|------------------------|-------|---|----------|--|----|---|----|
| C3500 | Pickup Cab (except HD) | 86-98 | Front sway bar 1 3/8 diameter 2WD only. | 1109-137 | | No | 1 | 32 |
|-------|------------------------|-------|---|----------|--|----|---|----|

EV Type 1

CHEVROLET/GMC

| | | | | | | | | |
|-----------|----------------|-------|--------------------------|----------|----|-----|-----|----|
| 2500/3500 | Van & Cut-away | 04-12 | 1 1/2" diameter rear bar | 1109-175 | 68 | Yes | 1.5 | 50 |
|-----------|----------------|-------|--------------------------|----------|----|-----|-----|----|

| | | | | | | | | |
|-------|----------------|-------|--|----------|--|----|-----|--|
| G4500 | Van & Cut-away | 08-11 | 1 1/2" diameter Rear factory replacment. Not for use with Auto-Chains. | 1109-173 | | No | 1.5 | |
|-------|----------------|-------|--|----------|--|----|-----|--|

| | | | | | | | | |
|-------|----------------|-------|--------------------------|----------|--------|----|-----|----|
| G4500 | Van & Cut-away | 08-12 | 1 3/8" diameter rear bar | 1109-150 | 65, 68 | No | 1.5 | 43 |
|-------|----------------|-------|--------------------------|----------|--------|----|-----|----|

| | | | | | | | | |
|-------|----------------|-------|---------------------------------|----------|--|----|-----|----|
| G4500 | Van & Cut-away | 08-12 | 1 1/2 front factory replacement | 1109-149 | | No | 1.5 | 85 |
|-------|----------------|-------|---------------------------------|----------|--|----|-----|----|

EV TYPE 1

CHEVROLET/GMC

| | | | | | | | | |
|--------|------------|-------|--|----------|--|----|-----|----|
| Kodiak | 4500, 5500 | 03-10 | FOR USE WITH GRANNING AIR RIDE ONLY! 1 5/8 diameter rear facing rear auxillary bar | 1109-174 | | No | 2.5 | 60 |
|--------|------------|-------|--|----------|--|----|-----|----|

| | | | | | | | | |
|--------|------------|-------|---|----------|---------------|--|-----|----|
| Kodiak | 4500, 5500 | 03-10 | 1 5/8 diameter rear facing rear auxillary bar | 1109-157 | 57, 59, No 62 | | 2.5 | 55 |
|--------|------------|-------|---|----------|---------------|--|-----|----|

EV Type 1

CHEVROLET/GMC

| | | | | | | | | |
|-----------|----------------|-------|----------------------------------|----------|--|----|-----|----|
| 2500/3500 | Van & Cut-away | 04-12 | 1 1/2 front factory replacement. | 1109-149 | | No | 1.5 | 85 |
|-----------|----------------|-------|----------------------------------|----------|--|----|-----|----|

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| <u>Model</u> | <u>Sub-Assembly</u> | <u>Year</u> | <u>Comments</u> | <u>Item #</u> | <u>Notes</u> | <u>Drilling</u> | <u>Time</u> | <u>Wt.</u> |
|---------------------|-----------------------|-------------|--|---------------|--------------|-----------------|-------------|------------|
| DODGE | | | | | | | | |
| 4500-5500 | Chassis Cab | 08-12 | Rear swaybar kit 1.5" diameter factory replacement. | 1129-131 | | No | 2 | |
| EV TYPE 1 | | | | | | | | |
| FORD | | | | | | | | |
| F650 | Chassis Cab | 09-10 | Front swaybar 1.5" diameter for Standard & LP Chassis 8,000lb & 10,000lb axle. | 1179-121 | | No | 2.5 | |
| EV Type 1 | | | | | | | | |
| FORD | | | | | | | | |
| F550 | | 00-11 | Rear sway bar 1.5 diameter (to replace factory bar) square axle tubes. | 1139-161 | 32 | No | 1 | 38 |
| EV TYPE 1 | | | | | | | | |
| FORD | | | | | | | | |
| F450 | | 99-06 | Cab chassis rear sway bar 1.5 diameter (to replace factory bar) Round axle tube | 1139-160 | 31 | No | 1 | 37 |
| F650 | Chassis Cab | 09-10 | Rear sway bar 1 5/8 diameter (for trucks equipped w/ On Spot chains) Will work w/ air brakes. LIMITED GROUND CLEARANCE | 1179-110 | 67 | Yes | 2 | 90 |
| EV Type 1 | | | | | | | | |
| FORD | | | | | | | | |
| F450 | | 08-11 | Rear sway bar 1.5 diameter (to replace factory bar) square axle tubes | 1139-161 | 32 | No | 1 | 38 |
| F350 | Super Duty | 08-10 | 1 3/8" diameter factory replacement front swaybar super duty 4WD pickup and cab chassis SRW and dually. | 1139-174 | | No | 1 | 45 |
| F550 | | 08-10 | Front bar 1.5 diameter 2WD & 4WD cab chassis F450-550 | 1139-171 | | No | 1 | 55 |
| EV TYPE 1 | | | | | | | | |
| FORD | | | | | | | | |
| F550 | Cab Chassis | 04-07 | Front sway bar 1 3/8 diameter for coil spring only - 4WD only | 1139-157 | 30 | No | 1.5 | 48 |
| F450 | Cab Chassis | 04-07 | Front sway bar 1 3/8 diameter for coil spring only - 4WD only | 1139-157 | 30 | No | 1.5 | 48 |
| EV Type 1 | | | | | | | | |
| Ford | | | | | | | | |
| F550 | | 11 | Front bar 1.5 diameter 2WD & 4WD cab chassis F450-F550. | 1139-179 | | Yes | 1 | |
| EV TYPE 1 | | | | | | | | |
| FORD | | | | | | | | |
| F550 | Cab Chassis | 05-07 | Front sway bar 1 3/8 diameter for coil spring only - 4WD only. | 1139-157 | 30 | No | 1 | 48 |
| F450 | Super Duty Pickup Cab | 86-98 | Rear sway bar 1 1/2 diameter w/ factory sway bar. | 1139-123 | 23 | Yes | 2 | 35 |
| F350 | Cab Chassis | 05-07 | Front sway bar 1 3/8 diameter. For coil spring only - 4WD only. | 1139-157 | 30 | No | 1 | 48 |
| F350 | Cab Chassis | 99-08 | Rear sway bar 1.5 diameter (to replace factory bar) round axle tubes. 2WD & 4WD | 1139-160 | 31 | No | 1 | 37 |
| F350 | Cab Chassis | 04-07 | Front sway bar 1 3/8 diameter for coil spring only - 4WD only | 1139-157 | 30 | No | 1.5 | 48 |
| F350 | | 05-08 | Front 1 3/8 diameter sway bar. 2WD ONLY. To replace factory bar | 1139-156 | | No | 1 | 48 |
| EV Type 1 | | | | | | | | |
| Ford | | | | | | | | |
| F450 | | 11 | Front bar 1.5 diameter 2WD & 4WD cab chassis F450-F550. | 1139-179 | | Yes | 1 | |
| FREIGHTLINER | | | | | | | | |

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| Model | Sub-Assembly | Year | Comments | Item # | Notes | Drilling | Time | Wt. |
|-------|--------------|-------|---|----------|-------|----------|------|-----|
| M2 | | 03-11 | Rear sway bar 1 1/2 diameter - (front mount) Airliner w/o chains. | 1209-107 | 43 | Yes | 2.5 | 90 |

EV TYPE 1

FREIGHTLINER

| | | | | | | | | |
|-----------|------------|-------|---|------------|----|-----|-----|----|
| FL70 | | 91-02 | Rear sway bar 1 1/2 diameter - Hendrickson air only. With 6 x 4 u-bolt pattern. | 1209-112 | | Yes | 2.5 | 89 |
| FL Series | FL50, FL60 | 91-02 | Rear sway bar 1 1/2 diameter - (front mount) Airliner w/o chains. | 1209-107 | 43 | Yes | 2.5 | 90 |
| FL Series | FL50, FL60 | 91-02 | Onspot chains already on. Rear sway bar 1 1/2 diameter. Airliner 5x4 u-bolt pattern (rear mount). | 1209-106SP | | Yes | 2 | 90 |

EV Type 1

FREIGHTLINER

| | | | | | | | | |
|----|--|-------|---|------------|--|-----|---|----|
| M2 | | 03-11 | Onspot chains already on. Rear sway bar 1 1/2 diameter. Airliner 5x4 u-bolt pattern (rear mount). | 1209-106SP | | Yes | 2 | 90 |
|----|--|-------|---|------------|--|-----|---|----|

EV TYPE 1

FREIGHTLINER

| | | | | | | | | |
|-----------|------------|-------|--|----------|----|-----|-----|----|
| FL Series | FL50, FL60 | 91-02 | Rear sway bar 1 1/2 diameter - Airliner suspension (rear mount w/ chains). 5x4 u-bolt pattern. | 1209-106 | 42 | Yes | 2.5 | 90 |
|-----------|------------|-------|--|----------|----|-----|-----|----|

EV Type 1

FREIGHTLINER

| | | | | | | | | |
|----|--|-------|---|----------|----|-----|-----|----|
| M2 | | 03-11 | Rear sway bar 1 1/2 diameter w/ 6x4 u-bolt pattern. With Airliner air suspension. | 1209-113 | 44 | Yes | 2.5 | 94 |
|----|--|-------|---|----------|----|-----|-----|----|

EV TYPE 1

FREIGHTLINER

| | | | | | | | | |
|-----------|------------|-------|--|----------|----|-----|-----|----|
| FL70 | | 91-02 | Rear sway bar 1 1/2 diameter w/ 6x4 u-bolt pattern. With Airliner air suspension. | 1209-113 | 44 | Yes | 2.5 | 94 |
| M2 | | 03-08 | Front sway bar 1 1/2 diameter 8000lbs axle. Will not fit w/ Mercedes engine auxillary cooling package. | 1209-116 | 46 | No | 2 | 50 |
| FL Series | FL50, FL60 | 91-02 | Rear sway bar 1 1/2 diameter - Hendrickson air suspension w/ chains only. | 1209-104 | 40 | Yes | 2.5 | 89 |
| Sterling | | 05-06 | Front sway bar 1 1/2 diameter | 1209-119 | | No | 2 | 50 |
| FL Series | FL50, FL60 | 91-02 | Front sway bar 1 1/2 diameter - 8000 lbs. axle. | 1209-100 | 38 | No | 2 | 51 |
| FL Series | FL50, FL60 | 91-02 | Rear sway bar 1 1/2 diameter - Hendrickson air suspension only. | 1209-101 | 39 | Yes | 2.5 | 89 |

EV Type 1

FREIGHTLINER

| | | | | | | | | |
|----|--|-------|--|----------|----|-----|-----|----|
| M2 | | 03-11 | Rear sway bar 1 1/2 diameter - Airliner suspension (rear mount w/ chains). 5x4 u-bolt pattern. | 1209-106 | 42 | Yes | 2.5 | 90 |
|----|--|-------|--|----------|----|-----|-----|----|

EV TYPE 1

NAVISTAR/INTERNATIONAL

| | | | | | | | | |
|-------------------|--------------------------|-------|---|-----------|----|-----|-----|----|
| 43/4400 Series | Won't fit LP | 03-08 | Front sway bar 1 1/2 diameter 8,000 lbs axle. Will Not fit LP chassis | 1179-108 | | No | 2 | 63 |
| 32/43/4400 Series | | 03-10 | Rear sway bar 1 5/8 diameter (for trucks equipped w/ On Spot chains) Will work w/ air brakes. LIMITED GROUND CLEARANCE. | 1179-110 | 67 | Yes | 2 | 90 |
| 4700 LP Series | | 89-02 | Front sway bar 1 1/2 diameter. | 1179-100 | | No | 2 | 63 |
| 4700 LP Series | | 89-02 | Rear sway bar 1 1/2 diameter w/ Navistar factory air ride only. | 1179-101 | | Yes | 2.5 | 86 |
| 43/4400 Series | | 03-10 | Axle plate kit for applications without Onspot chains. | 590060-00 | | No | | 42 |
| 43/4400 Series | Won't fit LP | 03-08 | Front sway bar 1 1/2 diameter 10,000 lbs axle. Will Not Fit LP Chassis. | 1179-118 | | Yes | 2 | 63 |
| 32/43/4400 SERIES | Low Profile and Standard | 09-10 | Front swaybar 1.5" diameter for LP Chassis 8,000lb & 10,000lb axle. | 1179-121 | | No | 2.5 | |

EV Type 1

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| <u>Model</u> | <u>Sub-Assembly</u> | <u>Year</u> | <u>Comments</u> | <u>Item #</u> | <u>Notes</u> | <u>Drilling</u> | <u>Time</u> | <u>Wt.</u> |
|----------------------|---------------------|-------------|--|---------------|--------------|-----------------|-------------|------------|
| STERLING | | | | | | | | |
| 4500-5500 | Chassis Cab | 08-12 | Rear swaybar kit 1.5" diameter factory replacement | 1129-131 | No | | 2 | |
| Terrastar | | | | | | | | |
| Terrastar | | 12 | Front bar. | 1179-124 | No | | 2 | 73 |
| EV TYPE 3 | | | | | | | | |
| CHEVROLET/GMC | | | | | | | | |
| G30 | Cut-away | 75-96 | Front sway bar 1 3/8 diameter. | 1109-131 | No | | 1 | 37 |
| G30 Cut-away | Cut-away | 75-96 | Rear sway bar 1 1/4 diameter. | 1109-121 | Yes | | 1.5 | 41 |
| EV Type 3 | | | | | | | | |
| CHEVROLET/GMC | | | | | | | | |
| 2500/3500 | Van & Cut-away | 97-12 | 1 3/8" diameter rear bar | 1109-150 | 68 | No | 1.5 | 43 |
| 2500/3500 | Van & Cut-away | 97-12 | 1 1/2" diameter rear bar | 1109-175 | 68 | Yes | 1.5 | 50 |
| VAN | 2500 & 3500 | 97-12 | Rear sway bar 1 diameter | 1109-148 | | Yes | 1.5 | 30 |
| 2500/3500 | Van & Cut-away | 04-12 | 1 1/2 front factory replacement. | 1109-149 | | No | 1.5 | 85 |
| EV TYPE 3 | | | | | | | | |
| CHEVROLET/GMC | | | | | | | | |
| W4500 | Cab Chassis | 08-09 | Rear sway bar 1 1/2" diameter For Tilt Cab Chassis | 1109-172 | | No | 2 | 80 |
| DODGE | | | | | | | | |
| B200 | Cut-away | 75-03 | Rear sway bar 1 3/8 diameter for cut-aways. Not for Sprinter. | 1129-111 | 15 | Yes | 1.5 | 48 |
| B300 | Cut-away | 75-03 | Rear sway bar 1 3/8 diameter for cut-aways. Not for Sprinter. | 1129-111 | 15 | Yes | 1.5 | 48 |
| EV Type 3 | | | | | | | | |
| DODGE | | | | | | | | |
| 4500-5500 | Chassis Cab | 08-12 | 1 5/8" diameter front factory replacment. | 1129-134 | | No | 1 | 40 |
| EV TYPE 3 | | | | | | | | |
| FORD | | | | | | | | |
| E350 | Cut-away | 92-10 | Front sway bar 1 3/8 diameter. | 1139-115 | 22 | No | 1.5 | 42 |
| E350 | Cut-away | 75-91 | Front sway bar 1 3/8 diameter motorhomes cut-aways. | 1139-100 | 18 | No | 1.5 | 37 |
| E250 | Cut-away | 92-10 | Front sway bar 1 3/8 diameter. | 1139-115 | 22 | No | 1.5 | 42 |
| E350 | Cut-away | 75-10 | Rear sway bar 1 1/2 diameter motorhomes cut-aways. | 1139-117 | | Yes | 1.5 | 53 |
| EV Type 3 | | | | | | | | |
| Ford | | | | | | | | |
| E450 | Super Duty | 09-12 | Front sway bar 1 3/8 diameter. | 1139-176 | | No | 1 | 36 |
| EV TYPE 3 | | | | | | | | |
| FORD | | | | | | | | |
| E350 | Cut-away | 75-09 | Rear sway bar 1 3/8 diameter (w/ automatic chains). Rear facing. | 1139-108 | 20 | Yes | 1.5 | 44 |
| EV Type 3 | | | | | | | | |
| FORD | | | | | | | | |
| E450 | Super Duty | 97-12 | Rear sway bar: 1 1/2 diameter. | 1139-147 | 27 | Yes | 1 | 47 |
| STERLING | | | | | | | | |
| 4500-5500 | Chassis Cab | 08-12 | 1 5/8" diameter front factory replacment. | 1129-134 | | No | 1 | 40 |

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| <u>Model</u> | <u>Sub-Assembly</u> | <u>Year</u> | <u>Comments</u> | <u>Item #</u> | <u>Notes</u> | <u>Drilling Time</u> | <u>Wt.</u> |
|----------------------|---------------------|-------------|---|---------------|--------------|----------------------|------------|
| SUV | | | | | | | |
| CHEVROLET/GMC | | | | | | | |
| Tahoe | | 95-99 | Rear sway bar 1 1/8 diameter (w/o factory bar). | 1109-144 | 11 | No | 1.5 34 |
| Suburban | 2500 | 00-08 | Rear sway bar 1 1/4 diameter (leaf spring suspension). | 1109-160 | 12 | Yes | 1 28 |
| Yukon | | 95-99 | Rear sway bar 1 1/8 diameter (w/o factory bar). | 1109-144 | 11 | No | 1.5 34 |
| Avalanche | | 00-08 | Rear sway bar 1 1/8 diameter (w/ factory bar). | 1109-168 | 48 | No | 1 36 |
| Tahoe - Yukon | | 00-10 | Rear sway bar 1 1/8 diameter (w/ factory bar). | 1109-168 | 48 | No | 1 36 |
| SUBURBAN | | 00-08 | Rear sway bar 1 1/8 diameter (w/ factory bar). | 1109-168 | 48 | No | 1 36 |
| Tahoe - Yukon | | 95-99 | Rear sway bar 1 1/8 diameter (w/ factory bar). | 1109-142 | 10 | No | 1.5 23 |
| Yukon | 2500 XL | 00-08 | Rear sway bar 1 1/4 diameter (leaf spring suspension). | 1109-160 | 12 | Yes | 1 28 |
| Suburban | | 92-99 | Rear sway bar 1 1/8 diameter (w/o factory bar). | 1109-144 | 11 | No | 1.5 34 |
| Suburban | | 92-99 | Rear sway bar 1 1/8 diameter (w/ factory bar). | 1109-142 | 10 | No | 1.5 23 |
| Escalade | | 00-08 | Rear sway bar 1 1/8 diameter (w/ factory bar). | 1109-168 | 48 | No | 1 36 |
| DODGE | | | | | | | |
| Durango | | 04-08 | 1 Rear factory replacement bar. | 1129-126 | | No | 0.5 40 |
| FORD | | | | | | | |
| Excursion | | 00-05 | Front sway bar 1 1/2 diameter | 1139-155 | 29 | No | 1.5 40 |
| Expedition | | 97-03 | Rear sway bar 1 1/8 diameter | 1139-150 | | No | 1 23 |
| Excursion | | 00-05 | Rear sway bar 1.375 diameter | 1139-154 | | Yes | 1.5 45 |
| JEEP | | | | | | | |
| Rubicon | | 04-08 | Rear swaybar 1 1/8" diameter factory replacment. | 1129-132 | | No | 1.5 30 |
| VAN/PICK-UP | | | | | | | |
| CHEVROLET/GMC | | | | | | | |
| C/K 2500 | Standard & HD | 00-08 | Front Sway bar 1 1/2" diameter 2WD, 4WD, and Duallys, 2500, 3500 Factory replacement. | 1109-166 | | No | 1 45 |
| Silverado | | 00-08 | 4 extended endlinks for vehicles with 4 lift kit installed | 590045-00 | | No | 0.5 10 |
| Van/Pick-up | | | | | | | |
| CHEVROLET/GMC | | | | | | | |
| 2500/3500 | Van & Cut-away | 04-12 | 1 1/2" diameter rear bar | 1109-175 | 68 | Yes | 1.5 50 |
| Van | 3500 | 97-12 | Rear sway bar 1 diameter. | 1109-148 | | Yes | 1.5 30 |
| VAN/PICK-UP | | | | | | | |
| CHEVROLET/GMC | | | | | | | |
| C/K 3500 | Standard & HD | 00-07 | Rear sway bar 1 1/4 diameter (2WD, 4WD & dually) | 1109-167 | 13 | Yes | 1.5 40 |
| C/K 3500 | Standard & HD | 08-09 | Rear sway bar 1 1/4 diameter SRW 4X4 and Dually. | 1109-171 | 8 | No | 1.5 47 |
| Van/Pick-up | | | | | | | |
| Chevrolet/GMC | | | | | | | |
| C/K 2500 | Standard & HD | 10-12 | Rear sway bar 1 1/4 diameter (2wd & 4wd). | 1109-169 | 8 | Yes | 1.5 |
| CHEVROLET/GMC | | | | | | | |
| 2500/3500 | Van & Cut-away | 04-12 | 1 3/8" diameter rear bar | 1109-150 | 68 | No | 1.5 43 |
| VAN/PICK-UP | | | | | | | |
| CHEVROLET/GMC | | | | | | | |

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| Model | Sub-Assembly | Year | Comments | Item # | Notes | Drilling | Time | Wt. |
|----------|---------------|-------|---|----------|-------|----------|------|-----|
| C/K 2500 | Standard & HD | 00-09 | Rear sway bar 1 1/4 diameter (2WD & 4WD) | 1109-167 | 13 | Yes | 1.5 | 40 |
| C/K 3500 | Standard & HD | 00-09 | Front Sway bar 1 1/2" diameter 2WD, 4WD, and Duallys, 2500, 3500 Factory replacement. | 1109-166 | | No | 1 | 45 |
| C/K 1500 | Standard & HD | 00-08 | Rear sway bar 1 1/4 diameter (2WD & 4WD) | 1109-167 | 13 | Yes | 1.5 | 40 |

Van/Pick-up

CHEVROLET/GMC

| | | | | | | | | |
|-----------|----------------|-------|----------------------------------|----------|--|-----|-----|----|
| 2500/3500 | Van & Cut-away | 04-12 | 1 1/2 front factory replacement. | 1109-149 | | No | 1.5 | 85 |
| Van | 2500 | 97-12 | Rear sway bar 1 diameter. | 1109-148 | | Yes | 1.5 | 30 |

Chevrolet/GMC

| | | | | | | | | |
|----------|---------------|-------|---|----------|---|-----|-----|--|
| C/K 3500 | Standard & HD | 10-12 | Rear sway bar 1 1/4 diameter (2wd & 4wd). | 1109-169 | 8 | Yes | 1.5 | |
|----------|---------------|-------|---|----------|---|-----|-----|--|

VAN/PICK-UP

DODGE

| | | | | | | | | |
|------|-------------|-------|--|----------|--|-----|-----|----|
| 3500 | Pick-up Ram | 03-06 | Rear sway bar 1 1/4 diameter 03-06 (2WD) will fit single and dually. | 1129-137 | | Yes | 1.5 | 31 |
|------|-------------|-------|--|----------|--|-----|-----|----|

Van/Pick-up

Dodge

| | | | | | | | | |
|------|-------------|-------|---|----------|--|----|-----|----|
| 3500 | Pick-up Ram | 10-11 | Rear sway bar 1 3/8 for Dually Pick-ups only. | 1129-130 | | No | 1.5 | 41 |
|------|-------------|-------|---|----------|--|----|-----|----|

DODGE

| | | | | | | | | |
|------|-------------|-------|--|----------|--|----|---|----|
| 1500 | Pick-up Ram | 09-12 | Rear sway bar 1 1/8" diameter factory replacment. 4X4 Only | 1129-135 | | No | 1 | 25 |
|------|-------------|-------|--|----------|--|----|---|----|

Dodge

| | | | | | | | | |
|------|-------------|-------|--|----------|----|----|-----|----|
| 3500 | Pick-up Ram | 10-12 | Rear sway bar 1 1/4 diameter (4WD) fits single only. 1129-123 supersedes 1129-120. | 1129-120 | 69 | No | 1.5 | 31 |
|------|-------------|-------|--|----------|----|----|-----|----|

| | | | | | | | | |
|------|-------------|-------|--|----------|--------|----|-----|----|
| 2500 | PICK-UP RAM | 03-12 | Rear sway bar 1 1/4 diameter 03-on (4WD) will fit single and dually. 1129-123 supersedes 1129-120. | 1129-123 | 16, 69 | No | 1.5 | 31 |
|------|-------------|-------|--|----------|--------|----|-----|----|

VAN/PICK-UP

DODGE

| | | | | | | | | |
|------|-------------|-------|--|-----------|--|----|-----|----|
| 1500 | Pick-up Ram | 96-02 | Poly bushing kit for front factory bar | 590053-00 | | No | 0.5 | 10 |
|------|-------------|-------|--|-----------|--|----|-----|----|

| | | | | | | | | |
|------|-------------|-------|---|----------|--|----|-----|----|
| 3500 | Pick-up Ram | 07-09 | 4X4, Dually and single rear wheel, 1 3/8" diameter rear swaybar | 1129-130 | | No | 1.5 | 41 |
|------|-------------|-------|---|----------|--|----|-----|----|

| | | | | | | | | |
|----------|------|-------|------------------------------|----------|----|----|---|----|
| Sprinter | 3500 | 04-07 | Rear sway bar 1 3/8 diameter | 1209-118 | 63 | No | 1 | 27 |
|----------|------|-------|------------------------------|----------|----|----|---|----|

| | | | | | | | | |
|----------|------|-------|------------------------------------|----------|----|----|---|----|
| Sprinter | 3500 | 08-09 | 1 3/8 diameter factory replacement | 1209-120 | 63 | No | 1 | 40 |
|----------|------|-------|------------------------------------|----------|----|----|---|----|

| | | | | | | | | |
|------|------------------------|-------|--|----------|--|----|-----|----|
| 3500 | Pick-up Ram Dually 2WD | 07-08 | Rear sway bar 1 3/8" for 2WD Dually pickup only. | 1129-133 | | No | 1.5 | 80 |
|------|------------------------|-------|--|----------|--|----|-----|----|

Van/Pick-up

DODGE

| | | | | | | | | |
|------|-------------|-------|--|----------|--------|----|-----|----|
| 3500 | PICK-UP RAM | 03-06 | Rear sway bar 1 1/4 diameter 03-on (4WD) will fit single and dually. 1129-123 supersedes 1129-120. | 1129-123 | 16, 69 | No | 1.5 | 31 |
|------|-------------|-------|--|----------|--------|----|-----|----|

| | | | | | | | | |
|----------|------|-------|--|----------|--|----|---|----|
| Sprinter | 2500 | 08-12 | Rear swaybar 1 1/8 diameter factory replacement. | 1209-128 | | No | 1 | 25 |
|----------|------|-------|--|----------|--|----|---|----|

VAN/PICK-UP

DODGE

| | | | | | | | | |
|------|-------------|-------|--|-----------|--|----|-----|----|
| 2500 | Pick-up Ram | 96-02 | Poly bushing kit for front factory bar | 590052-00 | | No | 0.5 | 10 |
|------|-------------|-------|--|-----------|--|----|-----|----|

| | | | | | | | | |
|------|-------------|-------|---|----------|--|----|---|----|
| 2500 | Pick-up Ram | 99-02 | 1.5" diameter Front factory replacment. | 1129-136 | | No | 1 | 40 |
|------|-------------|-------|---|----------|--|----|---|----|

Van/Pick-up

DODGE

| | | | | | | | | |
|------|-------------|-------|--|----------|--------|----|-----|----|
| 2500 | Pick-up Ram | 03-10 | Rear sway bar 1 1/4 diameter 03-on (4WD) will fit single and dually. 1129-123 supersedes 1129-120. | 1129-120 | 16, 69 | No | 1.5 | 31 |
|------|-------------|-------|--|----------|--------|----|-----|----|

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| <u>Model</u> | <u>Sub-Assembly</u> | <u>Year</u> | <u>Comments</u> | <u>Item #</u> | <u>Notes</u> | <u>Drilling Time</u> | <u>Wt.</u> |
|--------------|---------------------|-------------|-----------------|---------------|--------------|----------------------|------------|
|--------------|---------------------|-------------|-----------------|---------------|--------------|----------------------|------------|

VAN/PICK-UP

DODGE

| | | | | | | | | |
|------|-------------|-------|---|----------|----|----|-----|----|
| 3500 | Pick-up Ram | 96-02 | Rear sway bar 1 1/4 diameter 96-02 (4WD). | 1129-122 | 17 | No | 1.5 | 31 |
|------|-------------|-------|---|----------|----|----|-----|----|

Van/Pick-up

DODGE

| | | | | | | | | |
|------|-------------|-------|--|----------|--------|----|-----|----|
| 3500 | Pick-up Ram | 03-06 | Rear sway bar 1 1/4 diameter 03-on (4WD) will fit single and dually. 1129-123 supersedes 1129-120. | 1129-120 | 16, 69 | No | 1.5 | 31 |
|------|-------------|-------|--|----------|--------|----|-----|----|

VAN/PICK-UP

DODGE

| | | | | | | | | |
|----------|-----------------------------|-------|---------------------------|----------|----|-----|-----|----|
| B200-300 | Van | 75-03 | Rear sway bar 1 diameter. | 1129-107 | 14 | Yes | 1.5 | 34 |
| B300 | (conversion van only) 1 ton | 75-03 | 1 3/8 rear sway bar | 1129-111 | 15 | Yes | 1.5 | 48 |

Van/Pick-up

DODGE

| | | | | | | | | |
|------|-------------|-------|--|----------|----|----|-----|----|
| 3500 | PICK-UP RAM | 10-12 | Rear sway bar 1 1/4 diameter (4WD) fits single only. 1129-123 supersedes 1129-120. | 1129-123 | 69 | No | 1.5 | 31 |
|------|-------------|-------|--|----------|----|----|-----|----|

VAN/PICK-UP

DODGE

| | | | | | | | | |
|----------|-------------|-------|---|----------|----|----|-----|----|
| Sprinter | 2500 | 02-07 | Rear sway bar 1 1/8 diameter | 1209-117 | 63 | No | 1 | 25 |
| 2500 | Pick-up Ram | 96-02 | Rear sway bar 1 1/4 diameter 96-02 (4WD). | 1129-122 | 17 | No | 1.5 | 31 |

FORD

| | | | | | | | | |
|------|---------------|-------|--|----------|----|----|-----|----|
| F350 | | 99-03 | Front sway bar 1 1/2 diameter (4WD) 99-03. | 1139-155 | 29 | No | 1 | 40 |
| E350 | VAN & PICK-UP | 92-10 | Front sway bar: 1 3/8 diameter. | 1139-115 | 22 | No | 1.5 | 42 |

Van/Pick-up

FORD

| | | | | | | | | |
|------|--|-------|---|----------|--|----|-----|----|
| F450 | | 08-11 | Rear bar 1.5" diameter Fits 4WD SRW & Dually Pickups. | 1139-175 | | No | 1.5 | 35 |
|------|--|-------|---|----------|--|----|-----|----|

VAN/PICK-UP

FORD

| | | | | | | | | |
|------|--|-------|---|----------|----|----|-----|----|
| F150 | | 04-06 | 1 1/8 rear bar. 4X4 only | 1139-152 | | No | 1 | 48 |
| F350 | | 99-03 | Rear sway bar 1 3/8 diameter F250 & F350 w/ factory bar only -99-03. No Dually. | 1139-153 | 28 | No | 1.5 | 34 |
| F350 | | 99-07 | Rear sway bar 1 1/2 diameter F250 & F350 (dually). | 1139-165 | 33 | No | 1 | 29 |
| F250 | | 04-07 | Front sway bar 1 3/8 diameter, coil spring only, 4x4 only | 1139-158 | | No | 1 | 48 |
| F250 | | 04-07 | Rear sway bar 1 1/2 diameter | 1139-170 | | No | 1.5 | 49 |

Van/Pick-up

Ford

| | | | | | | | | |
|------|--|----|---|----------|--|-----|---|--|
| F550 | | 11 | Front bar 1.5 diameter 2WD & 4WD cab chassis F450-F550. | 1139-179 | | Yes | 1 | |
|------|--|----|---|----------|--|-----|---|--|

VAN/PICK-UP

FORD

| | | | | | | | | |
|------|-----|-------|-------------------------------|----------|----|-----|-----|----|
| E350 | Van | 75-06 | Rear sway bar 1 3/8 diameter. | 1139-109 | 21 | Yes | 1.5 | 51 |
|------|-----|-------|-------------------------------|----------|----|-----|-----|----|

Van/Pick-up

Ford

| | | | | | | | | |
|------|------------|-------|---|----------|----|----|-----|----|
| F250 | SUPER DUTY | 08-12 | Rear Swaybar 1 3/8 diameter factory replacement 4WD and 2WD. Must replace factory bar | 1139-173 | 66 | No | 1.5 | 40 |
|------|------------|-------|---|----------|----|----|-----|----|

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

| <u>Model</u> | <u>Sub-Assembly</u> | <u>Year</u> | <u>Comments</u> | <u>Item #</u> | <u>Notes</u> | <u>Drilling</u> | <u>Time</u> | <u>Wt.</u> |
|--------------|---------------------|-------------|---|---------------|--------------|-----------------|-------------|------------|
| FORD | | | | | | | | |
| F450 | | 08-10 | Front bar 1.5 diameter 2WD & 4WD cab chassis F450-550 | 1139-171 | No | 1 | 55 | |

VAN/PICK-UP

| | | | | | | | | |
|-------------|--|-------|---|----------|----|---|----|--|
| FORD | | | | | | | | |
| F350 | | 04-07 | Front sway bar 1 3/8 diameter, coil spring only, 4x4 only | 1139-158 | No | 1 | 48 | |

Van/Pick-up

| | | | | | | | | |
|-------------|------------|-------|---|----------|----|---|----|--|
| FORD | | | | | | | | |
| F350 | Super Duty | 08-10 | 1 3/8" diameter factory replacement front swaybar super duty 4WD pickup and cab chassis SRW and dually. | 1139-174 | No | 1 | 45 | |
| F250 | Super Duty | 08-10 | 1 3/8" diameter factory replacement front swaybar super duty 2WD & 4WD pickup and cab chassis SRW and dually. | 1139-174 | No | 1 | 45 | |

VAN/PICK-UP

| | | | | | | | | |
|-------------|-----|-------|---|----------|----|-----|-----|----|
| FORD | | | | | | | | |
| F250 | | 99-07 | Rear sway bar 1 1/2 diameter F250 & F350 (dually). | 1139-165 | 33 | No | 1 | 29 |
| F250 | | 99-03 | Rear sway bar 1 3/8 diameter F250 & F350 w/ factory bar only -99-03. No Dually. | 1139-153 | 28 | No | 1.5 | 34 |
| F250 | | 99-03 | Front sway bar 1 1/2 diameter (4WD) 99-03. | 1139-155 | 29 | No | 1 | 40 |
| E350 | Van | 75-06 | Rear sway bar 1 1/8 diameter for auto chains. | 1139-134 | 24 | Yes | 1.5 | 35 |

Van/Pick-up

| | | | | | | | | |
|-------------|--|-------|--|----------|----|----|-----|----|
| FORD | | | | | | | | |
| F350 | | 08-12 | Rear Swaybar 1 3/8 diameter factory replacment 4WD and 2WD Must replace Factory Bar. | 1139-173 | 66 | No | 1.5 | 40 |

VAN/PICK-UP

| | | | | | | | | |
|-------------|--|-------|--|-----------|-----|-----|----|--|
| FORD | | | | | | | | |
| F350 | | 04-07 | Rear sway bar 1 1/2 diameter | 1139-170 | No | 1.5 | 49 | |
| F450 | | 08 | Front and rear polyurethane bushings to replace factory rubber bushings | 590055-00 | No | 1 | 5 | |
| F150 | | 09-10 | 1 1/8" Diameter rear sway bar 2WD & 4WD. | 1139-177 | Yes | 1.5 | 40 | |
| F250 | | 05-08 | Super Duty Front 1 3/8 diameter sway bar. 2WD ONLY. To replace factory bar | 1139-156 | No | 1 | 48 | |
| F350 | | 05-08 | Super Duty Front 1 3/8 diameter sway bar. 2WD ONLY.To Replace factory bar | 1139-156 | No | 1 | 48 | |

FREIGHTLINER

| | | | | | | | | |
|----------|------|-------|---|----------|----|----|---|----|
| Sprinter | 3500 | 04-07 | Rear sway bar 1 3/8 diameter | 1209-118 | 63 | No | 1 | 27 |
| Sprinter | 3500 | 08-09 | Rear Swaybar 1 3/8" diameter factory replacement. | 1209-120 | 63 | No | 1 | 40 |
| Sprinter | 2500 | 02-07 | Rear sway bar 1 1/8 diameter | 1209-117 | 63 | No | 1 | 25 |

Van/Pick-up

| | | | | | | | | |
|---------------------|------|-------|--|----------|----|---|----|--|
| FREIGHTLINER | | | | | | | | |
| Sprinter | 2500 | 08-12 | Rear swaybar 1 1/8 diameter factory replacement. | 1209-128 | No | 1 | 25 | |

NISSAN

| | | | | | | | | |
|-------|--|-------|------------------------------|----------|-----|---|----|--|
| Titan | | 07-12 | 1 1/8 diameter rear sway bar | 1189-101 | Yes | 1 | 30 | |
|-------|--|-------|------------------------------|----------|-----|---|----|--|

Application Guide Notes Key

- 1 · Modification may be required.
- 2 · Welding required.
- 3 · 1992 to mid-1995 have IPD-style bars with rubber bushings. Mid-1995 on have IPD-style bars with urethane bushings.
- 4 · 18,000 lbs. GVWR and under.
- 5 · Will not fit Newmar motorhomes.
- 6 · Not for Oshkosh X, V, M or T line chassis (check with manufacturer for your model using VIN#).
- 7 · 1991 and older require factory retro fit conversion kit.
- 8 · Will Work with air bags.
- 9 · With autochains and with and without air brake.
- 10 · Will fit 1992-99 models with 4WD. For vehicles with factory sway bar for Suburban and 4 door Tahoe/Yukon – not for 2 door models.
- 11 · Will fit 1999 models. For vehicles without factory bar. For Suburban and 4-door Tahoe/Yukon. Not for 2 door models.
- 12 · For 2000-on GMC Yukon XL and Chevy Suburban (leaf springs 2500/3500 series) not for “regular” Yukon or Tahoe (coil springs – 1500 series).
- 13 · For 2000-on Chevy/GMC 2500, 2500HD and 3500 (fits both single and dual rear wheels) pickups. Both gas and Duramax diesels. Will work with airbags.
- 14 · Fits 80-2003 ¾ ton and 1 ton vans.
- 15 · For 1975-03 Motor home chassis can be used on heavily loaded 1 ton vans.
- 16 · 2003-06 Dodge 4WD pickups 2500 and 3500 models, both single and dual rear wheels. For stock ride height vehicles. May not fit with 5th wheel hitch.
- 17 · 1996-02 4WD 2500 and 3500 pickups. Not designed for 2WD.
- 18 · For 1975-91 only. Not for E150.
- 19 · Fits 1975-2006 Motor homes and emergency vehicles. Will still work on 2005 gas E-series van cutaways.
- 20 · For E350 DRW (dual rear wheels/cutaway) chassis 1975-2003 with automatic chains. Nor for use on diesel or V-10 models.
- 21 · For 1975-2003 Ford E350 vans without chains. Type 2 Ambulance or Class B Motor home.
- 22 · 1992-2006 also fits E-Super Duty, sometimes called E450. This kit has offset endlinks for tie rod clearance. Does not fit E250 or E150.
- 23 · For 1988-91 F53 motor home chassis. Not for 1992 or newer motor homes. Also F450 pickup cab/chassis. 1986-97 to replace factory sway bar if not factory bar, additional parts will be needed (see Ford Dealer).
- 24 · For 1992 models and newer vans (Type 2 Ambulance/Class B Motor Homes) except Powerstroke diesels and V-10 models. The exhaust is in the way! Kit could be mounted if customer is willing to modify exhaust.
- 25 · For V-8 chassis and V-10 chassis with GVWR of 18,000lbs or less. The 4th digit of the VIN is L or M. GVWR is found on chassis data plate/sticker. These axle U-bolts are spaced 5" wide by 5.25" front to rear (Dana 80 axle). Will work with a tag axle if the drive axle has leaf springs.
- 26 · For 1998-on F53 with V-10 engine and GVWR greater than 18,000 lbs. The 4th digit of VIN is N. GVWR is found on chassis data plate/sticker. U-bolt spacing is 5" wide by 6.25" front to back (Dana S135 rear axle). Will work with a tag axle if the drive axle has leaf springs.
- 27 · Will work of the new 6 liter diesel engine for E450 chassis 1997-on. Mounts to axle same as factory bar and will work with chains. Replaces 1139-137. This bar has vertical forged ends.
- 28 · For 1999-2003 F250/350 pickup single rear wheels with factory sway bar (both 2WD and 4WD). Replaces factory bar. If no factory bar endlinks will be needed (#590230-00) need 1 per vehicle. Will not fit 2004 or any dual rear wheels. Bar mounts under differential, not over differential like stock sway bar.
- 29 · Front sway bar kit for 2000-04 Ford F250-F350 trucks with straight axle (all 4WD models and F450 with front leaf springs, and F550 2WD models). Replaces factory sway bar. Must have factory sway bar. Will not fit 2005-on with coil spring front suspension. Updated to exclude 1999 models. Will fit 1999 model when factory bar is present (added 1/2" hardware for 99 model year)
- 30 · Front sway bar kit for 2005-on Ford F450-F550 4WD trucks with coil spring axle. Replaces factory sway bar. Must have factory sway bar. Will only fit cabin chassis, not for pickups.
- 31 · Rear sway bar kit replaces factory sway bar. For F350 commercial cab/chassis (only Dana 80 rear end with shock bracket welded to axle). Will not fit any pickup. On F450 confirm Dana 80 axle (round axle tubes). If axle tubes are square (Dana 120) use kit #1139-161.
- 32 · Rear sway bar for 2000-08 F550 cab/chassis. Replaces factory bar. Also fits F450 with Dana 120 axle (square axle tubes).
- 33 · Rear sway bar for 1999-2007 F250 & F350 2WD and 4WD pickups with dual rear wheels and factory sway bar. Designed to replace factory sway bar. Not for lifted trucks.

- 34 · For chassis with true air brakes with air canister on the axle. Some chassis have air assist brakes or air over hydraulic brakes, these are not true air brakes.
- 35 · Rear sway bar kit for Spartan Verst, air suspension. 1996-on 1.5" diameter. Will not fit Renegade made by Harney Coach. Leveling jacks are in the way.
- 36 · For Spartan Verst air suspension. 2004-on.
- 37 · Fits Mountain Master M11 Verst Chassis.
- 38 · For FL series chassis with 8,000lbs front axle and 19.5" rims or 126" wheel height. Normally used on FL50 or FL60 series low profile trucks (most ambulance chassis). This will not work with the new Cat diesel engine introduced in 2000.
- 39 · For FL50 & FL60 ambulance chassis with Hendrickson air ride rear suspension. Will not work with chains (use 1209-104).
- 40 · For Freightliner FL50/FL60 chassis with automatic chains. Proven to fit with Onspot. Arms of bar face towards rear of truck for Hendrickson suspension only.
- 41 · For chassis up to 1998 and some 1999 and newer with long ¾" diameter. U-bolts on rear axle. Have customer or shop measure u-bolt diameter. For chassis with short 7/8" diameter U-bolts (most of 1999-on) use kit #1209-115. If rear suspension does not have U-bolts, we do not have a kit.
- 42 · For 2000-on FL50/FL60 Airliner chassis with Freightliner air suspension 10/12K-15K GVW. If truck has Hendrickson air rear suspension, use #1209-101 or #1209-104 with chains. Bar mounts towards rear of chassis. For use with autochains. Not for Class A motor homes.
- 43 · For FL series Airliner with Freightliner air suspension. Bar mount towards front of chassis. Not for use with chains. If vehicle is equipped with chains, use #1209-106.
- 44 · For Freightliner FL70 with Airliner rear suspension. Rear facing bar.
- 45 · For most 1999-2003 Freightliner XC. This kit is for chassis with short 7/8" diameter bolts on rear axle. NOTE: sometime in 2003 Freightliner suspension changed to a style with No U- bolts. Have customer/shop measure U-bolt diameter. For chassis with ¾" diameter U-bolts (mostly up to 1998) use kit #1209-105. If rear suspension does not have U-bolts (2003-on) we do not have a kit.
- 46 · Will not work on chassis with Mercedes Benz engines that have auxiliary cooling package, if standard cooling, it is okay.
- 47 · Update of kit #1259-106 now fits all years for Rear W22 Workhorse chassis. Also fits W20 chassis.
- 48 · Fits Chevy 1/2 ton SUV chassis, coilspring only.
- 49 · Will not fit with auto chains
- 50 · Only fits vehicles with gas tanks that are rear of the axle.
- 51 · Currently does not work with Super Hitch
- 52 · Check to insure there is enough factory ubolt available to accommodate the factory nut, washer and our ½" plate. If there is not enough ubolt the 590050-00 ubolt replacement kit is needed.
- 53 · If superhitch is installed the 590051-00 bracket kit is needed
- 54 · For use with Duramax diesel will not fit gas engine.
- 55 · When air bags have been added you will need the 590054-00 adapter kit which requires welding.
- 56 · For Spartan Mountain Master Verst air suspension chassis Tuthill 240AR with jacks located to the rear of the cross member.
- 57 · Will work with Kelderman air ride, Will work with Link Ultra ride.
- 58 · Chassis must have 3" square beam connecting the 2 airbags located underneath.
- 59 · Rear Leaf Spring hanger brackets may be bolted or riveted on. When riveted, install time will increase. Manufacture codes can be found under the driver side visor: EV8 = Rivets ; EV9 = Bolts.
- 60 · Will not work with air bags.
- 61 · Must have factory swaybars.
- 62 · When installing with Link UltraRide or Kelderman Air Ride kits, two B315 endlings will be need to be ordered separately.
- 63 · 2007 Model year vehicles manufactured in or after June may have 2008 Chassis. Please confirm before ordering.
- 64 · Will work with other model years that have the inverted Y front steering system with factory dampener.
- 65 · Will work with automatic tire chains.
- 66 · When no factory bar is present, customer will need to purchase factory endlings from Ford.
- 67 · For Applications Without onspot chains use 1179-110 and 590060-00.
- 68 · Chassis built before June of 2007 will require an additional axle mounting bracket kit part # 590061-00.
- 69 · Will NOT fit with Goose Neck Hitch.