



*Technical Service
Information Bulletin
June 6, 2014*

**Subject:
new metric-to-English
brake line tee for
BrakeMaster 9060 installations**

TSIB number 145

There's a new 10-millimeter metric-to-English T-fitting for BrakeMaster 9060 proportioning valve installations in motorhomes with metric brake lines.

This T-fitting (part number 7923) fits virtually all metric brake lines for this application, including Sprinter, Mercedes and late-model Ford motorhome chassis.



7923 metric-to-English brake line tee