



1-800-669-9690

SEAT ADAPTER KIT #88366 INSTALLATION INSTRUCTIONS



#6225-01 10-21

ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



Before Installation



Installation Complete

Instructions

1. Push the driver's seat as far forward as possible. Loosen with an E12 socket the two rear seat track bolts attaching the seat to the floor pan (Fig.1). Then, slide the seat all the way back.
2. Use the same E12 socket to remove the front seat track bolts (Fig.2).
3. Tilt the seat back and place the seat adapter over the mounts you just exposed. Replace the bolts (Fig.3). Push the seat as far forward as possible, ensuring that there aren't any obstructions. Then, re-tighten the rear bolts.
4. Attach the BrakeMaster to the brake pedal and to the seat adapter. Adjust the length of the air cylinder assembly per the BrakeMaster installation instructions, ensuring that the BrakeMaster is pulling back on the brake pedal so the pedal is only depressed when the brakes are engaged at the motorhome. Failure to adjust the assembled length of the BrakeMaster may result in severe brake system damage and/or complete failure of the brakes.

IMPORTANT

Once the seat adapter has been installed, carefully run the seat through its full range of motion. If it is impeded in any way, immediately stop and correct the interference. Failure to do so may result in non-warranty property damage.



WARNING

Failure to follow these instructions can result in property damage, personal injury or even death.