

Save time, save money on every install with these five tools.



Quick-Disconnect Alignment Bar (017)



Bracket Centering Bar (016)

Installer's essentials — for **ROADMASTER** tow bar brackets



QD/Guardian Alignment Bar (016-1)

Receiver Alignment Bar (018)



Fascia Trimming Template (014)

Fascia Trimming Template (014)

For any **ROADMASTER** bracket with removable extensions (XL, MX or EZ series) — insert a fascia trimming template into each receiver, fit the fascia over the bracket, and trace around each template. Then, remove the fascia and trim.

Bracket Centering Bar (016)

Always 28½" from center to center for any **ROADMASTER** bracket with left and right receiver braces — before final assembly and drilling, use this bar to make sure the left and right main receiver braces are the correct distance apart. The dimples at each end mark 28½" from center to center for the QDs.

QD/Guardian Bracket Alignment Bar (016-1)

Quickly and easily aligns your **ROADMASTER** QDs and Guardian to your **ROADMASTER** brackets. Never struggle to line up these components again. Align, tighten, done.

Receiver Alignment Bar (018)

Lines up both removable receiver braces for **ROADMASTER** XL and EZ series brackets with left and right receiver braces — after the bracket is installed, use this bar to "lever" the receiver braces up or down, so that both removable arms are at the same level.

Quick-Disconnect Alignment Bar (017)

For an easy fit for **ROADMASTER** brackets with quick-disconnects — fit this bar over the QD pins and then tweak the QD pins, so that the tow bar cross brace fits easily.



Towing and Suspension Solutions

ROADMASTER, Inc. • 6110 NE 127th Ave • Vancouver, WA 98682 • 800-669-9690 • roadmasterinc.com