

SEAT ADAPTER KIT #88335 INSTALLATION INSTRUCTIONS



5801-00

ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



Instructions

1. Push the driver's seat forward, and then remove the seat track cover and the exposed T47 Torx bolt. There is another T47 in the middle of the opposite seat rail that will also need to be removed (Fig.1).
2. Lean the seat all the way forward and then lift it up and back to release the forward seat track hooks (Fig.2).
3. Return the seat to its rearmost position. Now, place the seat adapter as shown in Figure 3, centering the seat adapter arms around it. *Note:* make certain to position the adapter so that the mounting post is directly in line to the brake pedal. The BrakeMaster air cylinder may jam or function incorrectly if the mounting post is not directly in line with the brake pedal.
4. Replace the seat, reversing step 2, and then secure the seat by reversing step 1 (Fig.4).
5. Attach the BrakeMaster to the brake pedal and to the seat adapter. Adjust the length of the air cylinder assembly per the BrakeMaster installation instructions, ensuring that the BrakeMaster is pulling back on the brake pedal so the pedal is only depressed when the brakes are engaged at the motorhome. Failure to adjust the assembled length of the BrakeMaster may result in severe brake system damage and/or complete failure of the brakes.



WARNING

Failure to follow these instructions can result in property damage, personal injury or even death.