


**TRUCTIONS** 02/20/13

KIT# 3152-1

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



ltem	Qty	Description	Part No.
1	4	5/8" x 5" BOLT	350160-00
2	4	5/8" x 5 1/2" BOLT	350161-00
3	8	5/8" LOCK WASHER	350313-00
4	8	5/8" NUT	350262-00
		3/8"FLAT WASHER	
		3/8" LOCK WASHER	
		3/8" NUT	
8	2	5/8" DRAW PINS W/ CLIP	357035-00
		QUICK LINK	
		12" SAFETY CABLE	
11	4	3/8" U-BOLT	357024-00
		1 1/4" x 0.25" WALL x 2" PIPE SPACER	
13	2	SIDE PLATE	A-002439
14	1	DRIVER SIDE RECEIVER	C-001564
15	1	PASSENGER SIDE RECEIVER	
	1		
17	1	PASSENGER SIDE ARM	C-001308



ROADMASTER, Inc. 6110

6110 NE 127th Ave. Vancouver, WA 98682

A 98682 360-896-0407

www.roadmasterinc.com

This is one of our XL series brackets, which allows the visible front portion of the bracket to be easily removed from the front of the vehicle (Fig.A and Fig.B). The bracket kit consists of a passenger and driver side main receiver brace, two side braces, two removable front bracket arms and a hardware pack. The main receiver braces mount to the frame rails, rear brace and the sway bar. The rear braces mount to the frame, the frame cross member and the side braces. The side braces mount to the main receiver braces and the removable front brackets install in the main receiver braces.

Before starting the installation, lay out the kit components in order, as they will be used. This will give you a visual idea of how the components work, and will also confirm that every-thing is present and accounted for.



fax 360-735-9300

**IMPORTANT:** All baseplates **must** be assembled with all the bolts left loose for final adjustment and positioning (before tightening) unless otherwise instructed. All bolts **must** be torqued for proper strength. If more than one bolt is used per fastening point, the diagram may only show one. Use flat washers over all slotted holes and lock washers on all fasteners.

# \Lambda WARNING

Failure to heed these warnings or follow the installation instructions may result in a voided warranty, loss of towed vehicle, personal injury or death.

- Do not weld or modify this baseplate or its components. Welding or modification will void the warranty.
- Do not use this document as a basis to design/fabricate a baseplate, as it may not show all parts or structural components.
- We strongly recommend professional installation.
- If the towed vehicle has been in an accident, it must be properly repaired before attaching the baseplate. Do not install the baseplate if any structural frame damage is found.
- The installer must use all bolts and parts supplied. If running changes were made by the vehicle manufacturer after this kit was designed, some bolts or other fasteners may no longer be the correct size. It is the installer's responsibility to verify this kit is securely fastened to the vehicle.
- Use Loctite® Red on all bolts used to secure this baseplate. Torque all bolts to the specifications found at the end of these instructions. Do not over-torque the bolts or failure may occur.
- The installer must inspect the baseplate to ensure adequate clearance, particularly around hoses, air conditioner lines, radiators, etc. or non-warranty failure may result.
- Roadmaster manufactures many styles of baseplates. If your baseplate has removable arms, they must be removed before driving the vehicle, unless the arms can be pinned or padlocked in place. If not secured, the arms could vibrate out.
- Some motorhome chassis have such a tight turning radius that you can damage your motorhome, towed vehicle, tow bar or baseplate while turning sharply. Before getting on the road, test your turning radius in an empty parking lot. Turning too sharply could

result in non-warranty damage to your towing system, motorhome and/or towed vehicle.

- Do not back up with the towed vehicle attached or non-warranty damage will occur to your towing system or vehicles.
- The safety cables must connect the towing vehicle to the towed vehicle frame to frame, with the cables crossed, with enough slack for sharp turns. See cable instructions for proper routing. Failure to do so will result in non-warranty damage and/or the loss of the towed vehicle.
- This kit is designed for use with ROADMASTER tow bars and ROADMASTER adapters only. Using this kit with other brands, without an approved ROADMASTER adapter, may result in nonwarranty damage or injury.
- Receiver extensions and out-of-level towing situations of 3 inches or more. This can cause the system to swing much higher and lower, causing excessive strain on the tow bar, baseplate and frame. That can cause the towing system to fail, causing property damage, personal injury or even death. If you must use a receiver extension or drop hitch to tow, it will reduce your receiver's weight capacity by 1/3 to avoid damaging your system. Never use more than one extension and/or drop hitch, as this will void your warranty.
- Every 3,000 miles, the owner must inspect all mounting points for cracks or fatigue, and check the fasteners for proper torque, according to the bolt torque requirements chart on the last page of these instructions.
- The owner must follow the vehicle manufacturer's instructions to prepare the vehicle for towing. Failure to do so may cause severe damage to the vehicle.
- This baseplate is only warranteed for the original installation. Installing a used baseplate on another vehicle is not recommended and will void the warranty.



#### KIT# 3152-1 02/20/13

ROADMASTER, Inc. 6110 NE 127th Ave.

Vancouver, WA 98682


A 98682 360-896-0407

fax 360-735-9300 www.roadmasterinc.com



1. *Important:* please use all supplied bolts and parts and read all instructions carefully before beginning this installation. The majority of questions you may have can be answered within the text, and proper installation will ensure safe and secure travel. Now, begin the installation. Starting with the driver side inside plate, place the plate over the side of the frame and place the 5/8" x 5" bolt through the side plate and the existing hole in the side of the frame (Fig.C, D).

2. On the other side of the frame rail, place the driver's side main receiver brace over the end of the 5/8" x 5" bolt, and secure it in place with a lock washer and nut (Fig.E).




3. Now, bolt the side plate to the main receiver brace using the 5/8" x 5½" bolts, 1¼" x 2" pipe spacers, lock washers and nuts (Fig.F). *Note*: place the pipe spacers between the main receiver brace and the side plate.

4. Next, bolt the main receiver brace to the round frame cross member using two  $3/8" \times 3\frac{1}{2} \times 4\frac{1}{2}"$  U-bolts, flat washers, lock washers and nuts (Fig.G).

5. Make sure the bracket is level (Fig.H). Tighten the U-bolts and the 5/8" bolt to the torque specifications listed at the end of these instructions.

6. Using the pre-drilled holes in the main receiver brace as a template, drill through both sides of the frame with a 5/8" drill bit (Fig.I). *Note:* center punch and drill a pilot hole first. Drill each side separately, through the pre-drilled holes.

7. Now, bolt through the side plate, frame rail and the main receiver brace using a 5/8" x 5" bolt, lock washer and nut (Fig.J).





#### 6110 NE 127th Ave. ROADMASTER, Inc.

Vancouver, WA 98682 360-896-0407

fax 360-735-9300 www.roadmasterinc.com

8. Repeat steps 1 through 7 for the passenger side.

9. Hold the air dam in place over the ends of the main receiver brace and mark from the back for trimming. Refer to the vellow marker lines in Figure K for correct trimming.

10. Insert the removable front bracket arms into the front receiver braces, and secure them in place with the supplied 5/8" draw pins and spring pins (Fig.L).

- 11. Attach the 12" safety cables with the cable connectors (Q-Links) to the front of the receiver braces (Fig.L).
- 12. Attach the ends of the safety cables to the tow vehicle's safety cables and tow bar.
- 13. Install the tow bar to the mounting bracket according to the manufacturer's instructions.





#### **BOLT TORQUE REQUIREMENTS**

Note: The torque values represented below are intended as general guidelines. Torque requirements for specific applications may vary. Roadmaster does not warrant this information to be accurate for all applications and disclaims all liability for any claims or damages which may result from its use.

#### STANDARD BOLTS

Thread Size	Grade	Torque
5/16	5	13 ft./lb.
3/8	5	23 ft./lb.
7/16	5	
1/2	5	56 ft./lb.
5/8	5	150 ft./lb.

METRIC BOLTS								
Thread Size	Grade	Plated / Unplated						
8mm-1.0	8.8	20 ft./lb. 18 ft./lb.						
8mm-1.25	8.8	19 ft./lb. 18 ft./lb.						
10mm-1.25	8.8	38 ft./lb. 36 ft./lb.						
10mm-1.5	8.8	37 ft./lb. 35 ft./lb.						

#### METRIC BOLTS

Thread Size	Grade	Plated / Unplated	
12mm-1.25	8.8	70 ft./lb. 65 ft./lb.	
12mm-1.5	8.8	66 ft./lb. 61 ft./lb.	
12mm-1.75	8.8	65 ft./lb. 60 ft./lb.	
14mm-2.0	8.8	104 ft./lb. 97 ft./lb.	

All illustrations and specifications contained herein are based on the latest information available at the time of publication approval. ROADMASTER, INC. reserves the right to make changes at any time without notice in material, specification and models or to discontinue models.