

Instructions

1. Locate the mounting post (Fig.1) that came with your BrakeMaster. If needed, order part number 450596. Now, secure the post to the center of the seat adapter using the included 3/8" x ³/₄" bolt and 3/8" lock washer. If the hole is countersunk, use the Allen head bolt and lock washer included with this kit.

2. Snap open the plastic seat track covers on each side, and remove the two 14mm (head) bolts under each seat track cover (inset, Fig.2). The mounting post is offset, to align with the brake pedal. Check the alignment of the mounting post to the brake pedal, then set the seat adapter over the holes for the seat track bolts you just removed. Re-install the factory seat mounting bolts to secure the seat adapter in place. Close the plastic seat track covers.

WARNING

Failure to follow these instructions can result in

property damage, personal injury or even death.