

## Instructions

**1.** Locate the mounting post (Fig.1) that came with your Brake-Master. If needed, order part number 450596. Now, secure the post to the center of the seat adapter using the included 3/8" x 3/4" bolt and 3/8" lock washer. If the hole is countersunk, use the Allen head bolt and lock washer included with this kit.

**2.** Remove the two 14mm front seat mounting bolts on each side of the driver's seat (Fig. 2). The mounting post on the seat adapter is slightly offset, to align with the brake pedal. Check

## Parts List

- (1)
- 3/8" lock washer (1)
- 10mm x 1.25 x 35mm bolts (2)
- 10mm lock washers (2)
- (2) 10mm flat washers

the alignment of the mounting post to the brake pedal, then set the seat adapter in place under the seat track and over the front seat bolt holes.

**3.** To secure the seat adapter, bolt it in place with a supplied 10mm x 1.25 x 35mm bolt, 10mm lock washer and 10mm flat washer on each side (Fig. 3). Tighten the two bolts.

