

SEAT ADAPTOR KIT #88262 INSTALLATION INSTRUCTIONS



Part# 85-4037-01 04-08

ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 1-800-669-9690 www.roadmasterinc.com



Instructions

1. Remove the two 14mm (head) seat track bolts (Fig.1).
2. Place the seat adaptor over the seat tracks and bolt it into place using the supplied 10mm x 1.25 x 35mm bolts, lock washers and flat washers. *Note:* the mounting post on the adaptor must be directly in line to the brake pedal (Fig.2). The BrakeMaster air cylinder may jam or function incorrectly if the mounting post is not directly in line with the brake pedal.
3. Attach the air cylinder to the adaptor.

Parts List

- (2) 10mm x 1.25 x 35mm bolts
- (2) 10mm lock washers
- (2) 10mm flat washers



WARNING

Failure to follow these instructions can result in property damage, personal injury or even death.