




STEERING STABILIZER INSTALLATION INSTRUCTIONS

KIT# RBK28

85-6173-04
11-24

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



ITEM	QTY	MATERIAL	PART
1.....	4.....	3/8" NYLON INSERT LOCK NUT.....	350255-00
2.....	2.....	1/2-13 NYLON INSERT LOCK NUT.....	350259-00
3.....	2.....	1/2" FLAT WASHER.....	350308-00
4.....	4.....	10MM FLAT WASHER.....	355710-00
5.....	1.....	U-BOLT.....	357025-00
6.....	1.....	BRACKET.....	B1039
7.....	1.....	BRACKET.....	B810
8.....	2.....	U-BOLT.....	350086-00
9.....	1.....	LOCTITE.....	200544-00




STEERING STABILIZER INSTALLATION INSTRUCTIONS

KIT# RBK28

85-6173-04
11-24

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com




1. Install the supplied axle bracket using the $\frac{1}{2}$ " hardware (Fig.1). Leave the hardware loose for now. *Note:* The axle bracket should be spaced approximately 2" from the torsion arm mount (Fig.2).
2. Loosely install the tie rod bracket using the supplied $\frac{3}{8}$ " hardware (Fig.3). Then, install the RSSC shock (sold separately) to both the tie rod and the axle bracket, securing the RSSC.

3. With both the tie rod and axle brackets loose, and maintaining the 2" distance from the torsion arm mount, rotate the axle bracket so that the RSSC is as close to level as possible. Then, secure the axle bracket and secure the tie rod bracket.

4. Rotate the steering wheel all the way to the left and re-check the installation, ensuring that the tie rod bracket does NOT contact the differential cover (Fig.3).

If it does contact, rotate both the axle and tie rod brackets downward as necessary and/or slide the axle bracket slightly closer to the torsion arm mount.

5. Test drive the vehicle to make certain that the Reflex stabilizer is adjusted properly. If the steering pulls to either side, center it by loosening the bracket U-bolts at the tie rod, and then reposition it. Place Loctite on the bolts, tighten them, and test drive it once again, repeating the process until the proper adjustment is achieved.





STEERING STABILIZER INSTALLATION INSTRUCTIONS

KIT# RBK28

85-6173-04
11-24

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



Fig.5

WARNING

Failure to follow these instructions can result in property damage, personal injury or even death.

- The installer must read the instructions and use all bolts and parts supplied. Failure to securely fasten the stabilizer could result in loss of the stabilizer, damage to the vehicle, personal injury or even death.
- There must be adequate clearance between the Steering Stabilizer and all chassis and steering parts, and any other components, or non-warranty damage to the vehicle will result. After final installation, the installer must inspect the stabilizer to ensure adequate clearance. Some minor adjustments may be needed to achieve this; always verify that the steering wheel remains centered before and after these adjustments.
- Always test drive the vehicle to confirm the steering wheel settings. If the vehicle pulls to either side, the center positioning must be adjusted. If the steering wheel does not return to the center position, the tie rod bracket may require minor adjustments. Failure to adjust the center positioning may result in a loss of vehicular control.
- After installing this Steering Stabilizer, any technician who is performing alignment or suspension work on the motorhome must loosen the tie-rod bracket to adjust the toe; the technician must also re-adjust the steering damper. Failure to adjust the center positioning may result in a loss of vehicular control.
- Regardless of year, make and model, a wide range of options for specific applications may or may not interfere with the installation. It is the installer's responsibility to make certain that equipment is not damaged once the suspension solution travels through the full range of motion. Failure to ensure adequate clearance could result in non-warranty property damage, personal injury or even death.
- If running changes were made by the vehicle manufacturer after this kit was designed, some bolts or other fasteners in the included hardware pack may no longer be the correct size. It is the installer's responsibility to verify that the stabilizer is securely fastened to the vehicle, and fitted with the correct hardware, to account for these changes. Failure to securely fasten the stabilizer could result in loss of the stabilizer, damage to the vehicle, personal injury or even death.
- Except to adjust for running changes to the vehicle, use only the parts supplied by ROADMASTER to install the stabilizer. Using substandard grade parts or parts of the wrong size may result in loss of the stabilizer, damage to the vehicle, personal injury or even death.
- Once a year, the owner must inspect the fasteners for proper tightness and/or torque, according to the bolt torque requirements chart in these instructions. Failure to securely fasten the stabilizer could result in loss of the stabilizer, damage to the vehicle, personal injury or even death.
- Do not use an air impact wrench when reinstalling bolts, as stripped threads may result.
- This stabilizer is only warranted for the original installation. Installing a used stabilizer on another vehicle is not recommended and will void the warranty.