



BASEPLATE KIT INSTALLATION INSTRUCTIONS


KIT# 342-3

07/21/04

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com

Important

Note: this bracket will not accommodate the Guardian rock shield, some models of the Tow Defender, Stowaway or the StowMaster and StowMaster All Terrain tow bars.



Item	Qty	Length	Width	Hardware	Part No.
1	4	1 3/4"	1/2"	CARRIAGE BOLT	350363-00
2	4		1/2"	LOCK WASHER	350309-00
3	4		1/2"	NUT	350258-00
4	4	35MM	10MM	10MM x 1.25MM x 35MM BOLT	356202-00
5	4		10MM	LOCK WASHER	355715-00
6	4		10MM	FENDER WASHER	355716-00
7	2			DRAW PIN/SPRING PIN	357034-00
8	2			CABLE CONNECTOR	200008-00
9	2	15"	15"	CABLE	500646-15

ROADMASTER, INC.




BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 342-3

07/21/04

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com

ITEM	QTY	PART NO.	ASSEMBLY
1.....	1.....	C-000910.....	MAIN RECEIVER BRACE WELDMENT
2.....	1.....	C-000913.....	DRIVER SIDE ARM BRACE WELDMENT
3.....	1.....	C-000914.....	PASSENGER SIDE ARM BRACE WELDMENT
4.....	2.....	A-000039.....	1/4" x 2" x 1 1/2" SQ HOLE BACKING PLATE
5.....	2.....	A-000479.....	1/4" x 3" x 1 1/2" SQ HOLE BACKING PLATE



IMPORTANT: All baseplates **must** be assembled with all the bolts left loose for final adjustment and positioning (before tightening) unless otherwise instructed. All bolts **must** be torqued for proper strength. If more than one bolt is used per fastening point, the diagram may only show one. Use flat washers over all slotted holes and lock washers on all fasteners.

WARNING

Failure to heed these warnings or follow the installation instructions may result in a voided warranty, loss of towed vehicle, personal injury or death.

- Do not weld or modify this baseplate or its components. Welding or modification will void the warranty.
- Do not use this document as a basis to design/fabricate a baseplate, as it may not show all parts or structural components.
- We strongly recommend professional installation.
- If the towed vehicle has been in an accident, it must be properly repaired before attaching the baseplate. Do not install the baseplate if any structural frame damage is found.
- The installer must use all bolts and parts supplied. If running changes were made by the vehicle manufacturer after this kit was designed, some bolts or other fasteners may no longer be the correct size. It is the installer's responsibility to verify this kit is securely fastened to the vehicle.
- Use Loctite® Red on all bolts used to secure this baseplate. Torque all bolts to the specifications found at the end of these instructions. Do not over-torque the bolts or failure may occur.
- The installer must inspect the baseplate to ensure adequate clearance, particularly around hoses, air conditioner lines, radiators, etc. or non-warranty failure may result.
- Roadmaster manufactures many styles of baseplates. If your baseplate has removable arms, they must be removed before driving the vehicle, unless the arms can be pinned or padlocked in place. If not secured, the arms could vibrate out.
- Some motorhome chassis have such a tight turning radius that you can damage your motorhome, towed vehicle, tow bar or baseplate while turning sharply. Before getting on the road, test your turning radius in an empty parking lot. Turning too sharply could result in non-warranty damage to your towing system, motorhome and/or towed vehicle.
- Do not back up with the towed vehicle attached or non-warranty damage will occur to your towing system or vehicles.
- The safety cables must connect the towing vehicle to the towed vehicle frame to frame, with the cables crossed, with enough slack for sharp turns. See cable instructions for proper routing. Failure to do so will result in non-warranty damage and/or the loss of the towed vehicle.
- This kit is designed for use with ROADMASTER tow bars and ROADMASTER adapters only. Using this kit with other brands, without an approved ROADMASTER adapter, may result in non-warranty damage or injury.
- Receiver extensions and out-of-level towing situations of 3 inches or more. This can cause the system to swing much higher and lower, causing excessive strain on the tow bar, baseplate and frame. That can cause the towing system to fail, causing property damage, personal injury or even death. If you must use a receiver extension or drop hitch to tow, it will reduce your receiver's weight capacity by 1/3 to avoid damaging your system. Never use more than one extension and/or drop hitch, as this will void your warranty.
- Every 3,000 miles, the owner must inspect all mounting points for cracks or fatigue, and check the fasteners for proper torque, according to the bolt torque requirements chart on the last page of these instructions.
- The owner must follow the vehicle manufacturer's instructions to prepare the vehicle for towing. Failure to do so may cause severe damage to the vehicle.
- This baseplate is only warranted for the original installation. Installing a used baseplate on another vehicle is not recommended and will void the warranty.



BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 342-3

07/21/04




ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com

This bracket kit is one of our MX series with removable front braces. The kit consists of a receiver brace which mounts to the side of the front frame tubes, two removable front braces and a hardware packet. Everything but the front arm braces install behind the bumper fascia (Fig. A). The front fascia and grille will have to be removed for the installation.




1. **Important:** please use all supplied bolts and parts and read all instructions carefully before beginning this installation. The majority of questions you may have can be answered within the text, and proper installation will ensure safe and secure travel. Now, begin the installation.

Starting on the top of the grille, remove four plastic fasteners (Fig.B) then pull forward on the top of the grille (Fig.C) to access four lower retainers (Fig.D,E).



2. Remove four plastic fasteners in the top of the bumper fascia (Fig.F).
3. Move under the front fascia and remove two center bolts (10mm head) (Fig.G) and two Phillips screws from each corner of the fascia (Fig.H).






BASEPLATE KIT INSTALLATION INSTRUCTIONS





KIT# 342-3

07/21/04

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



4. Remove two plastic fasteners from the splash panels on each side (Fig.I) then pull back to access the fascia fender junction (Fig.J) and remove the fender fascia Phillip screws (Fig.K).



5. Pull the ends of the fascia out slightly on each side and pull forward to remove and set aside (Fig.L).
6. Move to the ends of the bumper core and remove two bolts on each side (14mm head) (Fig.M).
7. Hold the main receiver brace in position over the bolt holes on each side and bolt through the mounting holes with the bolts removed in step 6 (Fig.N). Align the brace then tighten to hold in positon (Fig.O).
8. Now take 1/2" x 2" carriage bolts, 1 1/2" x 2" backing plates, lock washers and nuts and bolt through the lower mounting holes and the tie down plates on each side (Fig.P). Tighten these bolts also (Fig.Q).



BASEPLATE KIT INSTALLATION INSTRUCTIONS






KIT# 342-3

07/21/04

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com




9. Using the receiver brace as a drill template, drill through the upper rear mounting hole as shown on each side (Fig.R).

10. Make sure the lower mounting bolts through the tie down plates are tight, then remove the two mounting bolts installed in step 7 on each side (Fig.S).



11. Remove the remaining inner mounting bolts (14mm head) (Fig.T) holding the bumper core then remove the bumper core (Fig.U).

12. Once the frame openings are exposed, insert 1/2" x 1 3/4" carriage bolts and 1 1/4" x 3" backing plates through the mounting holes drilled in step 9 (Fig.V). Finish with lock washers and nuts (Fig.W).



13. Remount the bumper core then tighten all bolts to the torque specifications at the end of these instructions (Fig.X,Y).

14. Replace the fascia reversing steps 1 through 5.




BASEPLATE KIT INSTALLATION INSTRUCTIONS


KIT# 342-3

07/21/04

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



15. Install the front braces in the receiver tubes and secure in place with 5/8" draw pins and 3/16" spring pins (Fig.Z,AA,BB).
16. Attach the safety cables to the main receiver brace (Fig.CC).
17. Install the tow bar according to the manufacturer's instructions.



BOLT TORQUE REQUIREMENTS

Note: The torque values represented below are intended as general guidelines. Torque requirements for specific applications may vary. Roadmaster does not warrant this information to be accurate for all applications and disclaims all liability for any claims or damages which may result from its use.

STANDARD BOLTS

Thread Size	Grade	Torque
5/16.....	5.....	13 ft./lb.
3/8.....	5.....	23 ft./lb.
7/16.....	5.....	37 ft./lb.
1/2.....	5.....	56 ft./lb.
5/8.....	5.....	150 ft./lb.

METRIC BOLTS

Thread Size	Grade	Plated / Unplated
8mm-1.0	8.8	20 ft./lb. 18 ft./lb.
8mm-1.25	8.8	19 ft./lb. 18 ft./lb.
10mm-1.25	8.8	38 ft./lb. 36 ft./lb.
10mm-1.5	8.8	37 ft./lb. 35 ft./lb.

METRIC BOLTS

Thread Size	Grade	Plated / Unplated
12mm-1.25	8.8	70 ft./lb. 65 ft./lb.
12mm-1.5	8.8	66 ft./lb. 61 ft./lb.
12mm-1.75	8.8	65 ft./lb. 60 ft./lb.
14mm-2.0	8.8	104 ft./lb. 97 ft./lb.

All illustrations and specifications contained herein are based on the latest information available at the time of publication approval. ROADMASTER, INC. reserves the right to make changes at any time without notice in material, specification and models or to discontinue models.