



Towing and Suspension Solutions


854959-03 06-25

All specifications are subject to change without notice

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 800-669-9690 Fax: 360-735-9300 www.roadmasterinc.com


The plugs on ROADMASTER power cords have been wired to standard electrical codes. Before connecting the plugs, use a test light to verify that the motorhome and towed vehicle socket wiring matches the diagrams for the plugs

NOTE: Apply a clear silicone sealant around each attachment point on the plug, as well as each wire entry and set screw indentation on the socket. This will help weatherproof the plug and socket and secure the socket set screws.




front of
4-wire plug

Pin Number	Wire Color	Motorhome/ Towed Vehicle
1.....	White.....	Ground
2.....	Brown.....	Taillights
3.....	Yellow.....	Left Turn/Stop
4.....	Green.....	Right Turn/Stop




front of
4-wire socket




front of
6-wire plug

Pin Number	Wire Color	Motorhome/ Towed Vehicle
1.....	Blue.....	Brake (Not Used)
2.....	Black.....	Auxiliary (Not Used)
3.....	Green.....	Right Turn/Stop
4.....	Brown.....	Taillights
5.....	White.....	Ground
6.....	Yellow.....	Left Turn/Stop




front of
6-wire socket



front of
7-wire plug

Pin Number	Socket Code	Roadmaster wire code	Motorhome/ Towed Vehicle
1.....	White.....	White	Ground
2.....	Blue.....	Blue	Brake monitor light (electric trailer brakes)
3.....	Green.....	Brown.....	Taillights
4.....	Black.....	Black	Charge line
5.....	Red	Yellow.....	Left turn/stop
6.....	Brown.....	Green	Right turn/stop
7.....	Yellow.....	N/A*	Auxiliary/Access

* 'N/A' means this socket is not used in this wiring configuration.



front of
7-wire socket