



BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523213-4

04/07/21
KS


ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com

Ratchets
13mm socket
10mm deep socket
9/16" and 3/4" wrenches
9/16" and 3/4" sockets

Recommended Tools

T15 driver
13/32" bit and drill
Needlenose pliers
Permanent marker

Panel tool
Flathead screwdriver
Reciprocating saw
Torque wrench
Loctite© Red or Blue



ITEM	QTY	DESCRIPTION	PART NUMBER
1	2	SPRING	200146-00
2	4	3/8" x 1 1/4" BOLT	350056-00
3	4	3/8" x 1 1/2" BOLT	350057-00
4	2	3/8" x 2 1/2" BOLT	350063-00
5	2	1/2" x 1 1/2" BOLT	350095-00
6	2	1/2" x 1 3/4" BOLT	350096-00
7	4	1/2" x 2" BOLT	350097-00
8	2	#10 x 3/4" SELF DRILLING SCREW	350247-35
9	10	3/8" HEX NUT	350254-00
10	8	1/2" HEX NUT	350258-00
11	8	3/8" FLAT WASHER	350304-00
12	10	3/8" LOCK WASHER	350305-00
13	8	1/2" SAE WASHER	350308-20
14	8	1/2" LOCK WASHER	350309-00
15	2	RING	350520-00
16	2	LOCK PIN	A000008
17	1	WIRE PLUG PLATE	A003801
18	2	SIDE PLATE	A006423
19	1	DRIVER SIDE REAR BRACE	B003967
20	1	PASSENGER SIDE REAR BRACE	B003968
21	1	DRIVER SIDE LOWER BRACE	B003969
22	1	PASSENGER SIDE LOWER BRACE	B003970
23	1	DRIVER SIDE ARM	C003604
24	1	PASSENGER SIDE ARM	C003605
25	1	MAIN RECEIVER	C003606



BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523213-4

04/07/21
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com

This is one of our crossbar-style baseplates, which allows the visible front portion of the baseplate to be easily removed from the front of the vehicle (Fig.A and Fig.B).

The kit mounts to the frame of the vehicle, and consists of two side-specific braces, upper and lower braces, two removable front braces, and a hardware pack.

Before starting the installation, lay out the kit components in order, as they will be used. This will give you a visual idea of how the components work, and will also confirm that everything is present and accounted for.



IMPORTANT: All baseplates *must* be assembled with all the bolts left loose for final adjustment and positioning (before tightening) unless otherwise instructed. All bolts *must* be torqued for proper strength. If more than one bolt is used per fastening point, the diagram may only show one. Use flat washers over all slotted holes and lock washers on all fasteners.

WARNING

Failure to heed these warnings or follow the installation instructions may result in a voided warranty, loss of towed vehicle, personal injury or death.

- Do not weld or modify this baseplate or its components. Welding or modification will void the warranty.
- Do not use this document as a basis to design/fabricate a baseplate, as it may not show all parts or structural components.
- We strongly recommend professional installation.
- If the towed vehicle has been in an accident, it must be properly repaired before attaching the baseplate. Do not install the baseplate if any structural frame damage is found.
- The installer must use all bolts and parts supplied. If running changes were made by the vehicle manufacturer after this kit was designed, some bolts or other fasteners may no longer be the correct size. It is the installer's responsibility to verify this kit is securely fastened to the vehicle.
- Use Loctite® Red on all bolts used to secure this baseplate. Torque all bolts to the specifications found at the end of these instructions. Do not over-torque the bolts or failure may occur.
- The installer must inspect the baseplate to ensure adequate clearance, particularly around hoses, air conditioner lines, radiators, etc. or non-warranty failure may result.
- Roadmaster manufactures many styles of baseplates. If your baseplate has removable arms, they must be removed before driving the vehicle, unless the arms can be pinned or padlocked in place. If not secured, the arms could vibrate out.
- Some motorhome chassis have such a tight turning radius that you can damage your motorhome, towed vehicle, tow bar or baseplate while turning sharply. Before getting on the road, test your turning radius in an empty parking lot. Turning too sharply could result in non-warranty damage to your towing system, motorhome and/or towed vehicle.
- Do not back up with the towed vehicle attached or non-warranty damage will occur to your towing system or vehicles.
- The safety cables must connect the towing vehicle to the towed vehicle frame to frame, with the cables crossed, with enough slack for sharp turns. See cable instructions for proper routing. Failure to do so will result in non-warranty damage and/or the loss of the towed vehicle.
- This kit is designed for use with ROADMASTER tow bars and ROADMASTER adapters only. Using this kit with other brands, without an approved ROADMASTER adapter, may result in non-warranty damage or injury.
- Receiver extensions and out-of-level towing situations of 3 inches or more. This can cause the system to swing much higher and lower, causing excessive strain on the tow bar, baseplate and frame. That can cause the towing system to fail, causing property damage, personal injury or even death. If you must use a receiver extension or drop hitch to tow, it will reduce your receiver's weight capacity by 1/3 to avoid damaging your system. Never use more than one extension and/or drop hitch, as this will void your warranty.
- Every 3,000 miles, the owner must inspect all mounting points for cracks or fatigue, and check the fasteners for proper torque, according to the bolt torque requirements chart on the last page of these instructions.
- The owner must follow the vehicle manufacturer's instructions to prepare the vehicle for towing. Failure to do so may cause severe damage to the vehicle.
- This baseplate is only warranted for the original installation. Installing a used baseplate on another vehicle is not recommended and will void the warranty.





BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523213-4



04/07/21
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com




Important: please use all supplied bolts and parts and read all instructions carefully before beginning this installation. The majority of questions you may have can be answered within the text, and proper installation will ensure safe and secure travel.

1. On each side, remove three T15 screws attaching the top of the fascia to the core support (Fig.C).
2. On the passenger side, remove one plastic fastener attaching the filler neck of the washer bottle to the core support (Fig.D). Twist while pulling up to remove it, and set it aside for now.



3. On each side, remove three 7mm screws (Fig.E – circles) and one plastic fastener (Fig.E – arrow) attaching the bottom of the fascia to the subframe.
4. On the driver's side, remove three 7mm screws (Fig.F – circles) and one plastic fastener (Fig.F – arrow) attaching the splash shield to the subframe and core support. Repeat the process for the passenger side but it will be four 7mm screws instead. Pull toward the rear of the vehicle to remove it.
5. On each side, remove two T15 screws attaching the bottom of the fender liner to the bottom of the fascia (Fig.G). Then, pull the fender liner down and remove two 13mm bolts attaching the fascia stiffener to the frame (Fig.G – inset).






BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523213-4



04/07/21
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com





6. On each side, turn the tire inward and remove five T15 screws (circles) and one plastic fastener (arrow) attaching the fender liner to the fascia (Fig.H).

7. On each side, pull down on the fender liner, unplug the side marker light, and release the clips on the fender trim until you can access a 7mm screw (Fig.I). Remove the screw. *Note:* It may be helpful to reach behind the fender and squeeze the clips with a pair of needlenose pliers.



8. On each side, lift up on the top of the fascia (Fig.J) and then release the fascia along the fender seam (Fig.K – arrows). Unplug any remaining wiring harnesses, and set it aside for now.

9. On each side, use a utility knife or reciprocating saw to separate the lower air dam as shown, using the yellow line in Figure L as a reference. Then, use a flathead screwdriver or panel tool (Fig.M and Fig.M – inset) to release the clip and pull straight out to remove it. It will not be replaced.







BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523213-4


04/07/21
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com




10. On each side, carefully trim the upper intercooler end cap as indicated in Figure N (red lines).

11. On the driver's side only, unclip the harness (Fig.O) and computer (Fig.P) from its mount and let it hang down for now. Release the plastic plate attaching the wiring harness to the subframe. Unplug it and push it up out of the way for now.



12. On the passenger side only, disconnect the air flow sensor for the intercooler and let it hang down for now (Fig.Q).

13. Still working on the passenger side, disconnect all of the wiring harnesses and fluid lines for the washer bottle (Fig.R). *Note:* When disconnecting the fluid lines, be prepared to cap the outlet lines to eliminate fluid loss. Now, remove two 10mm nuts and one 10mm bolt attaching the washer bottle to the frame and carefully set it aside for now (Fig.S – next page).







BASEPLATE KIT INSTALLATION INSTRUCTIONS



KIT# 523213-4

04/07/21
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com




14. Starting on the driver's side, use the drawing on page 1 to locate the side-specific main receiver brace. Hold it in place as shown in Figure S and use a Sharpie or paint marker to mark the two upper mounting holes in the pinch weld for drilling (Fig.T). *Note:* The raised edge of the plate should align with the forward edge of the pinch weld (Fig.U).



15. Use a 13/32" drill bit to drill out the two holes you marked in the previous step (Fig.V).

16. Place Loctite on two of the supplied 3/8" x 1 1/4" bolts and bolt through the side-specific plate and pinch weld (Fig.W). Finish the bolts with 3/8" lock washers and 3/8" nuts.







BASEPLATE KIT INSTALLATION INSTRUCTIONS



KIT# 523213-4

04/07/21
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



17. Use the drawing to locate the driver's side-specific lower brace. Set it on top of the subframe, aligning the holes with the upper side-specific brace. Place Loctite on two 3/8" x 1 1/2" bolts and bolt the two plates together as shown in Figure X. Finish with 3/8" flat washers, lock washers and nuts.



18. Place a 3/8" flat washer and Loctite over a 3/8" x 2 1/2" bolt and bolt up through the existing hole in bottom of the subframe, through the lower mount and finish with a 3/8" flat washer, 3/8" lock washer and 3/8" nut (Fig.Y). Tighten the bolts from top to bottom, ensuring that they do not contact any critical components in the engine compartment.

19. Repeat steps 14-18 for the passenger side.

20. Place Loctite over two 1/2" x 1 3/4" bolts. With the assistance of a second person, hold the main crossmember between the mounts you just installed. In the top hole only, place one of the bolts on each side. Loosely finish each one with a small 1/2" flat washer, 1/2" lock washer, and 1/2" nut (Fig.Z).

21. Use the drawing on page 1 to locate the driver's side inner brace. Prepare two bolts by placing Loctite on two 1/2" by 2" bolts. Then, slide the inner brace between the outer brace and the crossmember. Now, bolt through the forwardmost mounts using the two prepared bolts (Fig.AA).





BASEPLATE KIT INSTALLATION INSTRUCTIONS


KIT# 523213-4

04/07/21
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



22. Place a small $\frac{1}{2}$ " flat washer and Loctite over $\frac{1}{2}$ " x $1\frac{1}{2}$ " bolt and pass the bolt inside the subframe through an existing hole, through the inner brace, and finish with a $\frac{1}{2}$ " small flat washer, $\frac{1}{2}$ " lock washer and $\frac{1}{2}$ " nut (Fig.BB).
23. Tighten the forward $\frac{1}{2}$ " hardware, and then the rear mount.
24. Repeat steps 20-23 for the passenger side.
25. Re-connect the computer and associated electronics on the driver's side by reversing step 11.
26. On the passenger side, pass the air flow sensor through the cutout in the baseplate and reconnect it by reversing step 12 (Fig.CC).



27. Reinstall the washer bottle by reversing step 13 and 2.
28. On each side, trim the outermost rib on the fascia, leaving about $\frac{1}{2}$ " of material on the outer edge (Fig.DD). Test fit the fascia, paying careful attention to where the receivers come through the fascia. The clearance is tight in this spot and the three outer $\frac{1}{2}$ " bolts may need to be loosened and adjusted up or down to allow adequate clearance for the receivers. It should be centered in the opening, as shown in Figure EE.
29. On each side, insert the removable front arm into the front receiver 90 degrees from its final towing position, depressing the spring-loaded pin against the receiver. Twist back 90 degrees until the spring-loaded pin snaps into place in the notch on the receiver, locking the arm into place in its final towing position. **Please note: It is the owner's responsibility to ensure the locking of the pins before towing. Otherwise, failure of the towing system will result.**
30. Install the tow bar to the baseplate according to the manufacturer's instructions.



BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523213-4

04/07/21
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com

IMPORTANT!

Safety cables are required by law. When towing, connect safety cables to the safety cable tabs illustrated on the first page and in Figure FF. Make certain there is adequate slack in the cables to allow a full turning radius; otherwise, damage will result. If necessary, longer cables or cable extensions are available.




Three options for attaching the wiring plug to the main receiver brace

For six-wire plugs: use the two supplied 3/4" self-tapping screws to attach the electrical plug directly to the rods on the front of the main receiver brace.

For four-wire round plugs: attach to the plug mounting plate and then use the two supplied 3/4" self-tapping screws to attach the mounting plate to the rods on the front of the main receiver brace.

For four-wire flat plugs: place the plug through the mounting plug plate, and then secure it using the supplied zip tie on the front of the plug (Fig.GG). Use the two supplied 3/4" self-tapping screws to attach the mounting plate to the rods on the front of the main receiver brace.



BOLT TORQUE REQUIREMENTS

Note: The torque values represented below are intended as general guidelines. Torque requirements for specific applications may vary. Roadmaster does not warrant this information to be accurate for all applications and disclaims all liability for any claims or damages which may result from its use.

STANDARD BOLTS

Thread Size	Grade	Torque
5/16-18	5	13 ft./lb.
3/8-16	5	23 ft./lb.
7/16-14	5	37 ft./lb.
1/2-13	5	57 ft./lb.
5/8-11	5	112 ft./lb.

METRIC BOLTS

Thread Size	Grade	Torque
6mm-1.0	8.8	6 ft./lb.
8mm-1.0	8.8	18 ft./lb.
8mm-1.25	8.8	16 ft./lb.
10mm-1.25	8.8	36 ft./lb.
10mm-1.5	8.8	31 ft./lb.

METRIC BOLTS

Thread Size	Grade	Torque
12mm-1.25	8.8	64 ft./lb.
12mm-1.5	8.8	60 ft./lb.
12mm-1.75	8.8	55 ft./lb.
14mm-2.0	8.8	88 ft./lb.

All illustrations and specifications contained herein are based on the latest information available at the time of publication approval. ROADMASTER, INC. reserves the right to make changes at any time without notice in material, specification and models or to discontinue models.