




BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523193-5

11/22/23
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com

Important Note: This baseplate will not accommodate the Guardian rock shield, some models of the Tow Defender, Stowaway or the StowMaster and StowMaster All Terrain tow bars.



ITEM	QTY	NAME	PART #
1.....	6.....	3/8" x 1" BOLT	350055-00
2.....	6.....	3/8" LOCK WASHER.....	350305-00
3.....	6.....	3/8" NUT	350254-00
4.....	6.....	1/2" x 1 3/4" BOLT	350096-00
5.....	2.....	1/2" x 7 1/2" BOLT	350112-00
6.....	8.....	1/2" NUT	350258-00
7.....	8.....	1/2" LOCK WASHER.....	350309-00
8.....	12.....	1/2" SAE WASHER	350308-20
9.....	4.....	3/4" SQ BEVELED WASHER	350349-00
10.....	2.....	1 O.D. x 1 1/4" TUBE SPACER.....	A001055
11.....	2.....	#10 x 3/4" SELF DRILLING SCREW	350247-35
12.....	1.....	WIRE PLUG PLATE.....	A003801
13.....	2.....	ARM	C002383
14.....	1.....	MAIN RECEIVER BRACE	C003173
15.....	1.....	DRIVER SIDE SIDE BRACE	C003174
16.....	1.....	PASSENGER SIDE SIDE BRACE.....	C003175



BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523193-5

11/22/23
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com

This is one of our direct-connect series baseplates, which allows the visible front portion to be easily removed from the front of the vehicle (Fig.A and Fig.B).

The baseplate consists of a main receiver brace, two removable front braces, and a hardware pack and mounts to the framing.

Before starting the installation, lay out the kit components in order, as they will be used. This will give you a visual idea of how the components work, and will also confirm that everything is present and accounted for.



Fig.A



Fig.B

IMPORTANT: All baseplates **must** be assembled with all the bolts left loose for final adjustment and positioning (before tightening) unless otherwise instructed. All bolts **must** be torqued for proper strength. If more than one bolt is used per fastening point, the diagram may only show one. Use flat washers over all slotted holes and lock washers on all fasteners.

WARNING

Failure to heed these warnings or follow the installation instructions may result in a voided warranty, loss of towed vehicle, personal injury or death.

- Do not weld or modify this baseplate or its components. Welding or modification will void the warranty.
- Do not use this document as a basis to design/fabricate a baseplate, as it may not show all parts or structural components.
- We strongly recommend professional installation.
- If the towed vehicle has been in an accident, it must be properly repaired before attaching the baseplate. Do not install the baseplate if any structural frame damage is found.
- The installer must use all bolts and parts supplied. If running changes were made by the vehicle manufacturer after this kit was designed, some bolts or other fasteners may no longer be the correct size. It is the installer's responsibility to verify this kit is securely fastened to the vehicle.
- Use Loctite® Red on all bolts used to secure this baseplate. Torque all bolts to the specifications found at the end of these instructions. Do not over-torque the bolts or failure may occur.
- The installer must inspect the baseplate to ensure adequate clearance, particularly around hoses, air conditioner lines, radiators, etc. or non-warranty failure may result.
- Roadmaster manufactures many styles of baseplates. If your baseplate has removable arms, they must be removed before driving the vehicle, unless the arms can be pinned or padlocked in place. If not secured, the arms could vibrate out.
- Some motorhome chassis have such a tight turning radius that you can damage your motorhome, towed vehicle, tow bar or baseplate while turning sharply. Before getting on the road, test your turning radius in an empty parking lot. Turning too sharply could

result in non-warranty damage to your towing system, motorhome and/or towed vehicle.

- Do not back up with the towed vehicle attached or non-warranty damage will occur to your towing system or vehicles.
- The safety cables must connect the towing vehicle to the towed vehicle frame to frame, with the cables crossed, with enough slack for sharp turns. See cable instructions for proper routing. Failure to do so will result in non-warranty damage and/or the loss of the towed vehicle.
- This kit is designed for use with ROADMASTER tow bars and ROADMASTER adapters only. Using this kit with other brands, without an approved ROADMASTER adapter, may result in non-warranty damage or injury.
- Receiver extensions and out-of-level towing situations of 3 inches or more. This can cause the system to swing much higher and lower, causing excessive strain on the tow bar, baseplate and frame. That can cause the towing system to fail, causing property damage, personal injury or even death. If you must use a receiver extension or drop hitch to tow, it will reduce your receiver's weight capacity by 1/3 to avoid damaging your system. Never use more than one extension and/or drop hitch, as this will void your warranty.
- Every 3,000 miles, the owner must inspect all mounting points for cracks or fatigue, and check the fasteners for proper torque, according to the bolt torque requirements chart on the last page of these instructions.
- The owner must follow the vehicle manufacturer's instructions to prepare the vehicle for towing. Failure to do so may cause severe damage to the vehicle.
- This baseplate is only warranted for the original installation. Installing a used baseplate on another vehicle is not recommended and will void the warranty.





BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523193-5



11/22/23
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



1. **Important:** please use all supplied bolts and parts and read all instructions carefully before beginning this installation. The majority of questions you may have can be answered within the text, and proper installation will ensure safe and secure travel. Now, on each side, remove three T15 Torx screws attaching the top of the fascia to the core support (Fig.C) and two 7mm (head) screws attaching the top of the headlights to the core support (Fig.D).

2. On each side, remove five T15 Torx screws attaching the fender liner to the fascia (Fig.E).



3. On each side, pull back the fender liner and remove the 7mm screw attach the fender to the fascia (Fig.F).

4. On each side, remove four 7mm (head) screws attaching the air dam to the bottom of the wheel well (Fig.G).






BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523193-5

11/22/23
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com




5. On each side, remove nine 7mm screws attaching the lower splash shield to the subframe and fascia (Fig.H – circles), and one 7mm screw in the middle (Fig.H – arrow). Remove the splash shield and set it aside for now.

6. On each side, pull up on the fascia to release the pin (Fig.I). Then, pull out on the corner of the fascia to remove it (Fig.J). *Note:* '22 and later models will need to have the chrome trim released as well (Fig.K). Pull out carefully to avoid breaking the clips. Unhook all wiring connectors before removing the fascia and setting it aside.



7. On each side, remove two 7mm screws attaching the lower part of the headlight to the core support (Fig.L and M). Disconnect and remove the headlights, and set them aside for now.







BASEPLATE KIT INSTALLATION INSTRUCTIONS


KIT# 523193-5

11/22/23
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



8. On '22 and later models only: On the driver's side, release one plastic fastener attaching the ambient temperature sensor to the radiator (Fig.N). Let it hang down for now. Continuing on the driver's side only, disconnect the washer bottle by removing three 10mm bolts and one 10mm nut, along with a plastic fastener attaching the line and disconnect all connectors (Fig.O). Drain the bottle or maneuver it carefully from its mount and then place it in the engine compartment.



9. On the passenger side only, loosen a 10mm (head) nut and rotate the ground wire to the side to allow clearance for the main receiver brace. Re-tighten the nut (Fig.P).

10. Working on the passenger side only, remove the 21mm subframe bolt and place the rear support brace over the mount. Replace the bolt, leaving it loose for now (Fig.Q).

11. Place a 1/2" flat washer over a 1/2" x 7 1/2" bolt, and place it through the inside mount of the rear brace. Then, place a 1 1/4" x 1" O.D. x .188 wall pipe spacer, 1/2" flat washer and beveled washer over the inside mount, and bolt up through the frame, finishing with the supplied beveled washer, 1/2" flat washer, 1/2" lock washer and 1/2" nut (Fig.R and S – next page).





BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523193-5



11/22/23
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



12. Repeat steps 10 and 11 for the driver's side, and then torque all of the installed bolts on both sides.

13. Using the three holes in the rear support brace as a template, drill 3/8" holes through the pinch weld (Fig.T). *Note:* angle the drill slightly toward the frame to ensure that the holes are not too close to the edge of the pinch weld. Then, bolt through the holes using the supplied 3/8" x 1" bolts, and finish with 3/8" lock washers, and 3/8" nuts (Fig.U).



14. Trim the air deflectors as shown in Figure V.

15. Place the main receiver brace over the rear support braces and bolt them together using the supplied 1/2" x 1 3/4" bolts, 1/2" lock washers, 1/2" flat washers and 1/2" nuts (Fig.W).

16. Tighten the bolts to the bolt torque specifications found at the end of this document.

17. Reinstall the headlights, washer bottle and the fascia, reversing steps 1 through 8. Zip tie the ambient temperature to the main receiver brace.





BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523193-5


11/22/23
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



18. For '18-'21 models: Trim the fascia on each side as shown in Figure X (driver's side). For '22 models and later: Trim as shown in Figure Y (driver's side). *Note: If your vehicle is equipped with an additional plastic air dam, you will need to either remove the entire piece as shown (Fig.Z – arrow) or trim it to allow clearance for the main receiver brace.*

19. On each side, insert the removable front arm into the front receiver 90 degrees from its final towing position, depressing the spring-loaded pin against the receiver. Twist back 90 degrees until the spring-loaded pin snaps into place in the notch on the receiver, locking the arm into place in its final towing position. **Please note: It is the owner's responsibility to ensure the locking of the pins before towing. Otherwise, failure of the towing system will result.**



20. Install the tow bar to the baseplate according to the manufacturer's instructions.

IMPORTANT!

Safety cables are required by law. When towing, connect safety cables to the safety cable tabs shown in Figure AA. Make certain there is adequate slack in the cables to allow a full turning radius; otherwise, damage will result. If necessary, longer cables or cable extensions are available.

Note: If the bracket is so equipped, the holes in the alignment tabs which are welded to the arms and main receiver braces are for padlocks only. Under no circumstances should you bolt the alignment tabs together. Bolting the alignment tabs together may result in non-warranty damage to the bracket.



BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523193-5

11/22/23
KS


ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com

Three options for attaching the wiring plug to the main receiver brace

For six-wire plugs: Use the two supplied 3/4" self-tapping screws to attach the electrical plug directly to the rods on the front of the main receiver brace.

For four-wire round plugs: Attach to the plug mounting plate and then use the two supplied 3/4" self-tapping screws to attach the mounting plate to the rods on the front of the main receiver brace.

For four-wire flat plugs: Place the plug through the mounting plug plate, and then secure it using the supplied zip tie on the front of the plug (Fig.BB). Use the two supplied 3/4" self-tapping screws to attach the mounting plate to the rods on the front of the main receiver brace.



BOLT TORQUE REQUIREMENTS

Note: The torque values represented below are intended as general guidelines. Torque requirements for specific applications may vary. Roadmaster does not warrant this information to be accurate for all applications and disclaims all liability for any claims or damages which may result from its use.

STANDARD BOLTS

Thread Size	Grade	Torque
3/8.....	5.....	13 ft./lb.
3/8.....	5.....	23 ft./lb.
7/16.....	5.....	37 ft./lb.
1/2.....	5.....	56 ft./lb.
5/8.....	5.....	150 ft./lb.

METRIC BOLTS

Thread Size	Grade	Plated / Unplated
8mm-1.0.....	8.8.....	20 ft./lb. 18 ft./lb.
8mm-1.25.....	8.8.....	19 ft./lb. 18 ft./lb.
10mm-1.25.....	8.8.....	38 ft./lb. 36 ft./lb.
10mm-1.5.....	8.8.....	37 ft./lb. 35 ft./lb.

METRIC BOLTS

Thread Size	Grade	Plated / Unplated
12mm-1.25.....	8.8.....	70 ft./lb. 65 ft./lb.
12mm-1.5.....	8.8.....	66 ft./lb. 61 ft./lb.
12mm-1.75.....	8.8.....	65 ft./lb. 60 ft./lb.
14mm-2.0.....	8.8.....	104 ft./lb. 97 ft./lb.

All illustrations and specifications contained herein are based on the latest information available at the time of publication approval. ROADMASTER, INC. reserves the right to make changes at any time without notice in material, specification and models or to discontinue models.